

iSV2-CAN Series Integrated Servo Motor

User Manual





Foreword

Thank you for purchasing Leadshine iSV2-CAN series Integrated Servo Motors. This manual will provide information on the iSV2-CAN series Integrated Servo products regarding product safety & specifications, installations & wiring, tuning & problem diagnostics.

Please contact us at tech@leadshine.com if you need further technical support.

Incorrect operation may cause unexpected accident, please read this manual carefully before using product.

- ♦ We reserve the right to modify equipment and documentation without prior notice.
- ♦ We won't undertake any responsibility with any customer's modification of product and the warranty of product will be canceled at the same time.

Safety Precautions

Please read the safety instructions carefully before using the products and pay attention to the safety signs.

Danger	Might incur death or serious injury
Caution	Might cause injury to operating personals or damage to equipment
Warning	Might cause damage to equipment
SSS	Hot surface. Do not touch
(-)	Protective Earth

Safety instructions



 \checkmark The design of the product is not to be used in mechanical system which may incur health hazard.

✓ Users should be aware of the product safety precautions during design and installations of the equipment to prevent any unwanted accident.

Upon receiving

- ✓ The use of damaged or faulty product(s) is prohibited.
- ✓ Please refer to item checklist. If the labels don't match, please do not install.



Transportation

- ✓ Please provide storage and transportation under protected conditions.
- ✓ Do not stack the products too high up to prevent toppling.
- ✓ The product should be packaged properly during transportation,
- ✓ Do not hold the product by the cable, motor shaft or encoder while transporting it.
- ✓ The product should be protected from external forces and shock.

Installation

Servo drive and Motor:

- ✓ Do not install around combustibles to prevent fire hazard.
- ✓ Avoid vibration and impact.
- ✓ Do not install products that are damaged or incomplete.

Servo drive:

- ✓ Please install in electrical cabinet with sufficient protection from outside elements.
- ✓ Reserve sufficient gap as per the installation guide.
- ✓ Make sure to have good heat sinking.
- ✓ Avoid dust, corrosive gas, conductive object or fluid and combustibles.

Servo Motor:

- ✓ Make sure installation is tight to prevent it from loosening.
- ✓ Prevent fluid from leaking into motor and encoder.
- ✓ Protect motor from impact to avoid damaging encoder.
- ✓ Motor shaft should not bear the load beyond the limits as specified.

Wiring

Warning

- ✓ Participate installation personals should have sufficient training in product installation safety.
- ✓ Please power off and wait for 10 minutes to make sure a full discharge of electricity.
- ✓ Servo drive and motor must be connected to ground.
- ✓ Connect the cables only after servo drive motor installed correctly
- ✓ Make sure the wires are properly managed and insulation layer is not torn to prevent electrocution.



- ✓ Wiring must be correctly connected to prevent damage to product(s)
- Servo motor U, V, W terminal should be connected correctly and NOT connected directly to an AC power supply.
- ✓ Capacitor, inductor or filter shouldn't be installed between servo motor and servo drive.
- Connecting wires or any non-heat resistant components should be put near to heat sink of the servo drive or motor.
- ✓ The flyback diode which is connected in parallel to output signal DC relay must not be connected in reverse.



Tuning and running

- ✓ Make sure the wirings of servo drive and servo motor are installed and fixed properly before powering on.
- ✓ On the first time tuning of the product, it is recommended to run unloaded until all the parameter settings are confirmed to prevent any damage to the product or machine.

Usage



- Please install an emergency stop button on machine to stop operation immediately if there is an accident.
- ✓ Please make sure machine is stopped before clearing an alarm.
- ✓ Servo drive must be matched with specified motor.
- ✓ Frequent restart of the servo system might incur damage to the product.
- ✓ Servo drive and motor will be hot to touch shortly after power off. Please be careful.
- ✓ Modification(s) to servo system is prohibited.

Error Handling

Warning

- ✓ Please wait for 5 minutes after powering off for the electricity to be fully discharged before uninstalling the cables.
- Participate maintenance personals should have sufficient training in maintenance and operation of this product series.



- ✓ Please handle the error before clearing an alarm.
- Keep away from machine after a restart upon alarm. Mechanical axis might suddenly move. Such hazard should be prevented during the utilization of the product.

Model Selection



- ✓ Rated torque of the servo motor should be higher than continuous designated torque when fully loaded.
- Load inertia ratio of the motor should be lower or equals to recommended value for specified models
- ✓ Servo drive must be matched with specified motor.



Warranty Information

Available for

Leadshine overseas warranty only covers Leadshine DC servo products that are obtained through Leadshine certified sales channel outside of China.

Warranty claim

- All Leadshine integrated servo products (Servo drives and motors) overseas enjoy 18-month warranty period.
- Due to unforeseen circumstances in different sales regions around the globe, we recommend users to seek technical support from directed sales channel as any warranty claim or repair services may be required.
- Please be informed that any maintenance/repair work that is outside of the warranty claim conditions might incur some charges and to be confirmed before product(s) is being sent in.
- The duration required for maintenance work to be done is to be confirmed after initial check-up but we reserve the right to prolong the repair duration if needed.
- Discontinued products within warranty period will be replaced with a product of similar specifications.

Steps to warranty claim

- 1. Visit Leadshine global site www.leadshine.com to look for local certified sales channel.
- 2. Contact designated sales channel to check if any fee might incur. May include repair fee, spare part cost or shipping cost.

Circumstances where warranty claim is not available

- Damage/Loss due to occurrence of natural or man-made disaster such as fire, flood or earthquake.
- Installation or wiring error
- If there is any modification done to the product
- Warranty label on products is torn or not existing
- > Not a product bought from Leadshine certified global network of retailers/distributors.

Before warranty claim

- Please backup device parameters before any repair work/warranty claim. Leadshine and Leadshine certified retailers/distributors will not be held responsibilities for any data loss.
- If available, please send product back in original packaging or make sure it is well packaged to prevent any damage to the product during shipping.

Leadshine Technology Co., Ltd. and its certified sales channel reserved the final right of the interpretation of the warranty information.



TABLE OF CONTENT

CHAPTER 1 INTRODUCTION	9
1.1 Product Introduction	9
1.2 Model Number Structure	
1.3 Servo Drive Technical Specification	
1.4 INTEGRATED MOTOR PORTS AND CONNECTORS	12
CHAPTER 2 INSTALLATION & WIRING	
2.1 Servo Drive Installation	13
2.1.1 Servo drive installation environment	
2.1.2 Integrated Servo Motor Installation	
2.2 INTEGRATED SERVO MOTOR BASIC INFORMATION	14
2.2.1 Speed-torque curves	
2.2.2 Integrated Servo Motor Dimension	
2.3 iSV2-CAN WIRING DIAGRAM	
2.4 INTEGRATED SERVO MOTOR PORTS	
2.4.1 CN1 I/O Signal Port	
2.4.2 CN3/CN4 Power supply & Regenerative Resistor Port	
2.4.3 CN5 CANopen Communication Port	20
2.4.4 CN7 RS232 Tuning Port	
2.4.5 ID spin dial RSC	
2.4.6 Baud rate/Terminal resistor switch SW	
2.5 CABLE SELECTION	23
2.5.1 Communication Cable	
2.5.2 Tuning Cable	23
2.6 REGENERATIVE RESISTOR SELECTION	24
CHAPTER 3 PARAMETER	
3.1 Parameter List	28
3.1.1 Servo drive parameter	
3.1.2 Motion parameter starting with object dictionary 6000	
3.2 PARAMETER FUNCTION	
3.2.1 【Class 0】 Basic Settings	
3.2.2 【Class 1】 Gain Adjustments	40
3.2.3 【Class 2】 Vibration Suppression	
3.2.4 【Class 3】 Velocity/ Torque Control	
3.2.5 【Class 4】 I/O Interface Setting	
3.2.6 Class 5 Extension settings	
3.2.7 Class 6 Other settings	
3.3 402 Parameters Function	69



CHAPTER 4 CONTROL MODE	
4.1 Profile Position Mode	81
4.1.1 Pulse	81
4.1.2 Motion settings	81
4.1.3 Monitoring settings	
4.1.4 Applications example	
4.2 Profile Velocity Mode	
4.2.1 Motion Settings	
4.2.2 Monitoring settings	
4.3 Profile Torque Mode	
4.3.1 Motion Settings	
4.3.2 Monitoring settings	
4.4 Homing mode	85
4.4.1 Motion Settings	85
4.4.2 Monitoring settings	85
4.4.3 Homing mode	
4.5 Emergency Stop	
4.5.1 Motion Settings	
4.5.2 Monitoring settings	
CHAPTER 5 APPLICATIONS	
5.1 TRIAL RUN	
5.2 Inertia Ratio measuring	
5.3 NOTCH FILTER (VIBRATION SUPPRESSION)	
5.4 Auto gain adjustment	
5.5 3 RD GAIN SWITCHING	
5.6 FRICTION COMPENSATION FUNCTION	
5.7 REGENERATIVE RESISTOR SETTINGS	
5.8 SAFETY FUNCTIONS	
5.8.1 Max. motor rotational speed limitation	
5.8.2 Max. duration for motor to stop after disabling	
5.8.3 External brake deactivation output signal BRK-OFF	
5.8.4 Servo stopping mode	
5.8.5 Emergency stop function	
5.9 Multiturn Absolute encoder	
5.9.1 Parameter settings	
5.9.2 Read absolute position	
5.9.3 Absolute Encoder Related Alarm	
CHAPTER 6 CANOPEN COMMUNICATION	
6.1 CANOPEN PROTOCOL	
6.2 CANOPEN COMMUNICATION PROTOCOL FOR ISV2 SERIES	
6.4 Predefined Connections	
6.5 OBJECT DICTIONARY	
6.5.2 Object dictionary structure	
6.5.3 Object type	



6.5.4 Access attribute
6.6 NETWORK MANAGEMENT (NMT)
6.6.1 NMT module control
6.6.2 NMT node guarding135
6.6.3 NMT Boot-up
6.6.4 NMT communication status machine136
6.7 PROCESS DATA OBJECT (PDO)
6.8 Service Data Object
6.9 Emergency Object
CHAPTER 7 WARNING AND ALARM
7.1 Servo drive alarm overview
7.2 Alarm Handling147
7.3 CANOPEN COMMUNICATION ALARM159
7.4 Alarm clearing
7.4.1 Servo Drive Alarm Clearing
Appendix A
Appendix B
Appendix C
Appendix D
Appendix E
CONTACT US

_



Chapter 1 Introduction

1.1 Product Introduction

iSV2-CAN Series DC Servo Drive is our latest generation DC servo drive that is based on CANopen DSP402 protocol. It can be easily matched to any controller that supports this protocol. Using the latest signal processing chip from Texas Instrument, the drive is compact with small volume and good reliability.

In comparison to conventional pulse controlled servo drives, our iSV2-CAN provides advantages as listed below.

1. Lengthen communication range and lower electromagnetic interference

Due to the reliance of pulse command, pulse controlled servo drives could be easily disrupted by electromagnetic interferences. CANopen communication protocol provides fault detections limitations and error handling that makes communication more reliable over long distances.

2. Greater motion control

Trajectory generation can be done within the driver under non-cyclic synchronous mode. Controller only needs to deliver target position, velocity and acceleration commands to the driver. Drivers can then achieve greater control by applying feedforward to the commands.

3. Simplify complex wiring work

Using CANopen communication protocols, the connections between master device and slave stations can be realized using only RS232 cables.

4. Reduce cost by lowering the requirement for more ports

Multiple axes control can be realized without requirement for more ports or pulse module on the master device/controller. Only a network port is needed to chain the axis controller (drivers) together in series.



1.2 Model Number Structure





1.3 Servo Drive Technical Specification

iSV2-CAN series	CAN6020V24	CAN6020V48	CAN6040V48	CAN8075V48		
Rated Current (Arms)	11	6.5	10	19		
Peak Current (Arms)	34	20	28	57		
Flange size (mm)	60 80					
Main power supply	24/48VDC					
Drive mode	SVPWM sinusoidal wave drive					
Velocity regulation ratio	5000:1					
Electronic gear ratio	1 ~ 32767/1 ~ 32767					
Matching encoders	ABZ or RS485 encoder (Tamagawa protocol)					
	4 configurable NF	PN/PNP 24V Digital Ir	puts: DI3-DI6			
Input	 Homing Switch Positive limit sv Negative limit sv 	n (HOME-SWITCH) witch (POT) switch (NOT)				
	4. Clear Alarm (A-ULR) nn (F-STOP)				
	2 configurable sir	ngle-ended NPN/PNP	24V, 8mA digital ou	Itputs		
Output	 Alarm (ALARM) Servo ready (SRDY) External brake off (BRK-OFF) Positioning completed (INP1) Reached velocity(AT-SPEED) Torque limit (TLC) Zero speed position (ZSP) Velocity coincidence (V-COIN) Position command (P-CMD) Velocity limit (V-LIMIT) 					
Alarm	Current circuit error, DC bus overvoltage, DC bus undercurrent, overcurre overcurrent on IPM, motor overload, regenerative resistor overload, enco disconnected, encoder initialization error, encoder data error, excessive position deviation, overspeed, I/O configuration error, EEPROM parameter saving CRC checksum error, positive/negative position limit valid, forced					
Indicator light	•	Red & Gr	een LED			
Tuning Software		Motion S	Studio 2			
Motion Studio 2	Configure parameters for current, position and velocity loop. Parameter uploading using .lsr parameter files. Drive and motor data monitoring using oscilloscope.					
Communication Port	RS-232,1:1; CAN,0:N(0≤N≤127), CANopen					
Load-Inertia	Smaller than 20 times motor inertia					
	Storage conditionAvoid direct sunlight. Keep away from heat generating devices, dust, oil, corrosive liquid/gas and places with strong vibration or high humidity. Prohibit combustible gas and conductive material waste.					
Environmental	Temperature	-20°C ~ + 45°C (Pleas	se allow air circulati	on if >45°C)		
requirements	Storage temperature - 20°C ~ + 65°C					
	Humidity	40-90%RH (Cond	ensation free)			
	Installation	Vertical and level to a	around			



1.4 Integrated Motor Ports and Connectors

iSV2-CAN Series Integrated Servo Motor (6020)

(6020/6040/8075)





Chapter 2 Installation & Wiring

2.1 Servo Drive Installation

2.1.1 Servo drive installation environment

Temperature	Storage: -20~+65°C (Condensation free); Installation: -20~+45°C (Please allow air circulation if >45°C)			
Humidity	Under 90%RH (Condensation free)			
Altitude	Up to 1000m above sea level			
Atmospheric pressure	86 ~ 106kPa			
Vibration	Less than 0.5G (4.9m/s2) 10-55Hz (non-continuous working)			
Atmospheric	No corrosive gas, combustibles, dirt or dust.			
IP ratings	IP20			

2.1.2 Integrated Servo Motor Installation

1. **Protection**: iSV2 series integrated servo motor is not waterproof type motors; please prevent any fluid from splashing or pouring over the motors.

2. **Temperature, humidity:** Environmental temperature should be between -25~40°C (without freezing). Temperature raise of the motor is normal under continuous operation please ensure enough cooling for motors to work at optimum rate. Humidity should be less 90%RH without condensation.

3. Vibration: Please ensure that vibration is not more than 0.5G ($4.9m/s^2$)

4. Installations:

(a) Please don't hammer on the motor or shaft while trying to remove timing pulley to prevent damage to encoder.

(b) Please use a flexible coupling to prevent excessively large torsion on the shaft.



2.2 Integrated Servo Motor basic information

2.2.1 Speed-torque curves











2.2.2 Integrated Servo Motor Dimension







iSV2 Series	LC	LL	Н	LA	LZ	ТР	RH	W
CAN6020V24H		95.7		Ø70	Ø5.5	12	16	5
CAN6020V24G	60	124.7	79					
CAN6020V48H		95.7						
CAN6020V48G		124.7						
CAN6040V48H		112.7						
CAN6040V48G		124.7						
CAN8075V48H	00	128.8	100	<i>d</i> 00	de e		21 E	6
CAN8075V48G	80	160.3	100	Ø90	Ø0.0		21.5	0



2.3 iSV2-CAN Wiring Diagram

iSV2-CAN Wiring Diagram



> iSV2-CAN series integrated servo motor doesn't have pulse or analogue input.

> Make sure data transferring cables are as short as possible. Keep CN1 cable under 3m and CN2 cable under 10m. Use shielded double winding cables to cut down on electromagnetic interference.

> If the load for DO is an inductive load such as a relay, please install freewheeling diodes on both ends of the load in parallel. Please keep in mind that if the diode is connected in reverse, it might cause damage to the drive.

> Use non-fuse breaker (NFB) to cut off power supply to the drive in case of emergency.



2.4 Integrated Servo Motor Ports

iSV2-CAN 6020/6040/8075



Connector	Label					
CN1	I/O signal port					
CN3	Main Power Supply (DC+, DC-)					
CN4	Regenerative resistor port (RB+, RB-)					
CN5	CANopen Communication port					
CN7	RS232 tuning port					
SW	Baud rate/Terminal resistor switch					
RSC	ID spin dial					
LED	Indicator LED (PWR/ALM)					



2.4.1 CN1 I/O Signal Port

Diagram	CN	Pin	Signal	Description
		1	NC	
		2	NC	ΝΔ
		3	NC	
2		4	NC	
		5	COM_IN	Common DI
		6	DI3	Emergency stop
	CN1	7	DI4	Homing switch
		8	DI5	Positive limit
		9	DI6	Negative limit
		10	DO1	Alarm output, current output <100mA
		11	DO2	Servo ready, current output <100mA
		12	COM_OUT	Common output

I/O Signal Wiring Diagram

1. DI3-DI6 supports NPN and PNP configuration. Recommended to use an external control signal power supply of 12-24VDC.

2. DO1-DO2 are single ended outputs with 100mA current output that supports NPN and PNP configuration. Recommended to use an external power supply of 24VDC. If the load is an inductive load such as a relay, please install freewheeling diodes on both ends of the load in parallel. If the diode is connected in reverse, it might cause damage to the driver.





CN1 control signal cable selection

To ensure I/O signal to not be affected by electromagnetic interference, a **shielded cable** is recommended for this application.



Cables for different analogue signals should be using isolated shielded cable while cables for digital signals should be shielded twisted pair cable. Cables for CN1 connectors should be 24-28AWG in diameter.

2.4.2 CN3/CN4 Power supply & Regenerative Resistor Port



Port	Pin	Signal	Description			
	1	DC+	DC Power Supply positive and pogative terminals			
CNS	2	DC-	De Power supply positive and negative terminals			
CNA	3	RB+	Paganarativa register positiva and pagativa terminals			
CIN4	4	RB -	Regenerative resistor positive and negative terminals			

2.4.3 CN5 CANopen Communication Port

Port	Diagram	Pin	Signal	Label
CN5		1	CANH	CANopen H terminal
		3	CANL	CANopen L terminal
		5	GND	Power supply ground
		Others	NC	10 pins are not applicable



2.4.4 CN7 RS232 Tuning Port

Port	Diagram	Pin	Signal
		1	5V
		2	тх
CN7		3	GND
		4	RX

ISV2-CAN Series Integrated Servo Motor can be connected to Motion Studio 2 for parameters tuning and data monitoring using **CABLE-PC-1**.

2.4.5 ID spin dial RSC

	Diagram	Bit	CAN address	Bit	CAN address
		0	Pr0.23 Default : 16	8	8
RCS		1	1	9	9
	345	2	2	А	10
		3	3	В	11
		4	4	С	12
		5	5	D	13
		6	6	E	14
		7	7	F	15



2.4.6 Baud rate/Terminal resistor switch SW

	Diagram	CAN_ID (High Bit)	SW4	Baud rate	SW1	SW2	Terminal resistor	SW3
		0	OFF	Pr0.24 Default: 1MHz	OFF	OFF	Disconnected	OFF
sw				500kHz	ON	OFF		
		1	ON	250kHz	OFF	ON	Connected	
				125kHz	ON	ON	(CAN)	UN



2.5 Cable Selection

2.5.1 Communication Cable

CABLE-TX*M*-iSV2	CABLE-TX*M*-iSV2-LD2
- For CANopen and Modbus RS485 communication between iSV2 devices.	- For CANopen and Modbus RS485 communication between iSV2 devices and FLD2/2FLD2 drives.

2.5.2 Tuning Cable





2.6 Regenerative Resistor Selection

The use of regenerative resistor

When the motor opposes the direction of rotation as in deceleration or vertical axis escalation, part of the regenerative energy will be delivered back to the driver. This energy will first be stored in internal capacitors of the driver. When the energy stored in the capacitors reach the maximum capacity, a regenerative resistor is required the excessive energy to prevent over-voltage.

Calculation of regenerative resistance under normal operation

Steps:

1. Determine if driver comes with a regenerative resistor. If not, please prepare a regenerative resistor with resistance value higher than might be required.

2. Monitor the load rate of the regenerative resistor using front panel (d14). Set the driver on high velocity back and forth motions with high acceleration/deceleration.

3.Please make sure to obtain the value under following conditions: Driver temperature < 60°C, d14<80(Won't trigger alarm), Regenerative resistor is not fuming, No overvoltage alarm(Err120).

Pb(*Regenerative power rating*) = *Resistor power rating x Regenerative load rate* (%)

Please choose a regenerative resistor with power rating Pr about **2-4 times the value of Pb** in considered of harsh working conditions and some 'headroom'.

If the calculated Pr value is less than internal resistor power rating, external resistor is not required.

R(Max. required regenerative resistance) = (380² - 370²)/Pr

Problem diagnostics related to regenerative resistor:

- If driver temperature is high, reduce regenerative energy power rating or use an external regenerative resistor.
- If regenerative resistor is fuming, reduce regenerative energy power rating or use an external regenerative resistor with higher power rating.
- If d14 is overly large or increasing too fast, reduce regenerative energy power rating or use an external regenerative resistor with higher power rating.
- If driver overvoltage alarm (Er120) occurs, please use an external regenerative resistor with lower resistance or connect another resistor in parallel.

Please take following precautions before installing an external regenerative resistor.

1. Please set the correct resistance value in Pr0.16 and resistor power rating Pr0.17 for the external regenerative resistor.

2. Please ensure the resistance value is higher or equals to the recommended values in table 2-3. Regenerative resistors are generally connected in series but they can also be connected in parallel to lower the total resistance.

3. Please provided enough cooling for the regenerative resistor as it can reach above 100°C under continuous working conditions.

4. The min. resistance of the regenerative resistor is dependent on the IGBT of the regenerative resistor circuit. Please refer to the table above.



Theoretical selection of regenerative resistor

Without external loading torque, the need for an external regenerative resistor can be determined as the flow chart below





Diagram below shows the acceleration and deceleration cycle periods and the regenerative torque that occurs during the process.



Steps to calculate capacity of regenerative resistor

Steps	Calculation	Symbol	Formula				
1	Servo system regenerative energy	E1	E1=(N+1)×J×V ² /182				
2	Depleted energy from loss of load system during acceleration	EL	$E_L = (\pi/60) V \times T_L \times tD$ If loss is not determined, please assume $E_L = 0$.				
3	Depleted energy due to motor coil resistance.	E _M	$E_M = (U^2/R) \times tD$ R = coil resistance, U = operating voltage If R is not determined, please assume $E_M = 0$.				
4	Energy stored by internal DC capacitors	Ec	Please refer to table 2-5				
5	Depleted energy due to regenerative resistance	Eκ	E _K =E1-(EL+EM+EC), If loss is ignored, EK=E1-EC				
6	Required power rating of regenerative resistor	Pr	Pr=E _κ /(0.5×T)				

Note:

> 0.5 in the calculation for **Pr** represent 50% load rate of regenerative resistor.

E1-EK: Energy(Joule) TL: Load torque(Nm) V: Motor velocity(rpm/min)
 Pr: Regenerative resistor power rating J: Rotor inertia (kgm²) T: Motor cycle time(s)
 N: Ratio of load inertia and rotor inertia



Recommended regenerative resistor specification for each drives

Motors	Resistance (Ω)	Power rating(W)	Min. Resistance(Ω)
ISV2-CAN6020	10	50	5
ISV2-CAN6040	10	100	5
ISV2-CAN8075	10	100	5

Note:

1. Use 10 Ω /100W resistor for test operation and make sure: Drive temperature d33<60 C, dynamic brake is not in alarm mode (Braking rate d14<80), brake resistor is not overheated, drive has no overcurrent alarm.

2. If drive temperature is too high, increase power rating of regenerative resistor or reduce drive power.

3. If brake resistor is overheated, reduce drive power or use regenerative resistor with higher resistance.

4. If d14 is too high, reduce drive power or use regenerative resistor with higher resistance and power ratings.

5. External torque might cause regenerative energy to flow back into drive. During normal operation, torque output in the same direction as rotational direction but if external torque exists, directions might oppose and in this case, regenerative resistor with higher resistance may be required.



Chapter 3 Parameter

3.1 Parameter List

• Panel Display as follows:

classify and code _____ number

 Parameter Valid mode Description HM: Valid in homing mode
 PP: Valid in profile position mode
 PV: Valid in profile velocity mode
 PT: Valid in profile torque mode
 F: Valid in all modes

Class	Label	CANopen Address	Parameter	Activation		Valid Mode			
	Model-following bandwidth	2000h	PR_000	Immediate					F
	Control Mode Settings	2001h	PR_001	After restart					F
ហ្	Real time Auto Gain 2002h PR_002 Immediate Adjusting Real time auto stiffness 2002h PR_002 Immediate						F		
netei	Real time auto stiffness adjusting	2003h	PR_003 Immediate						F
ue.	Inertia ratio 2004h PR_004 Immediate						F		
ar	Rotational direction 2006h PR_006 After restart						F		
sic F	Command pulse counts per revolution	2008h PR_008 After restart		PP	PV		HM		
Ba	1 ^{₅t} Torque Limit	2013h	PR_013	Immediate					F
[0 s;	Excessive Position Deviation Settings	2014h	PR_014	Immediate	PP			HM	
Clas	Absolute Encoder settings	2015h	PR_015	After restart					F
	Regenerative resistance	2016h	PR_016	Immediate					F
	Regenerative resistor power rating	2017h	PR_017	Immediate					F
	CAN node	2023h	PR_023	After restart					F
	CAN Baud rate	2024h	PR_024	After restart					F

3.1.1 Servo drive parameter



Class	Label	CANopen Address	Parameter	Activation		Valid Mode						
	1 st position loop gain	2100h	PR_100	Immediate	PP			HM				
	1 st velocity loop gain	2101h	PR_101	Immediate					F			
	1 st Integral Time Constant of Velocity Loop	2102h	PR_102	Immediate					F			
	1 st velocity detection filter	2103h	PR_103	Immediate					F			
	1⁵t Torque Filter Time Constant	2104h	PR_104	Immediate					F			
	2 nd Position Loop Gain	2105h	PR_105	Immediate	PP			HM				
	2 nd velocity loop gain	2106h	PR_106	Immediate					F			
	2 nd Integral Time Constant of Velocity Loop	2107h	PR_107	Immediate					F			
nts	2 nd velocity detection filter	2108h	PR_108	Immediate					F			
stme	2 nd Torque Filter Time Constant	2109h	PR_109	Immediate					F			
sujus	Velocity feed forward gain	2110h	PR_110	Immediate	PP			HM				
ass 1] Gain a	Velocity feed forward filter time constant	y feed forward 2111h PR_111 Immediate me constant 2112h PR_112 Immediate		PP			HM					
	Torque feed forward gain 2112h PR_112 Immediate		PP	PV		HM						
	Torque feed forward filter time constant	2113h	PR_113	Immediate	PP	PV		HM				
[CI	Position control gain switching mode	2115h	PR_115	Immediate					F			
	Position control gain switching level	2117h	PR_117	Immediate					F			
	Hysteresis at position control switching	2118h	PR_118	Immediate					F			
	Position gain switching time	2119h	PR_119	Immediate					F			
	Speed regulator - kr	2123h	PR_123	Immediate					F			
	Speed regulator - km	2124h	PR_124	Immediate					F			
	Speed regulator - kd	2125h	PR_125	Immediate					F			
	Speed regulator – kd filter	2126h	PR_126	Immediate					F			
	1 st position loop integral time	2128h	PR_128	Immediate					F			
	2 nd position loop integral time	2130h	PR_130	Immediate				Image:				
	Velocity feedback filter level	2134h	PR_134	Immediate					F			
	Special function register	2137h	PR_137	Immediate					F			



User Manual of iSV2-CAN Integrated Servo

Class	Label	CANopen Address	Parameter	Activation		Valid Mode			
	Adaptive filtering mode settings	2200h	PR_200	Immediate					F
u	1 st notch frequency	2201h	PR_201	Immediate					F
ressi	1 st notch bandwidth selection	2202h	PR_202	Immediate					F
dd	1 st notch depth selection	2203h	PR_203	Immediate					F
Su	2 nd notch frequency	2204h	PR_204	Immediate					F
ation	notch bandwidth selection	2205h	PR_205	Immediate					F
brä	2 nd notch depth selection	2206h	PR_206	Immediate					F
٨i	3 rd notch frequency	2207h	PR_207	Immediate					F
iss 2]	3 rd notch bandwidth selection	2208h	PR_208	Immediate					F
Cla	3 rd notch depth selection	2209h	PR_209	Immediate					F
<u> </u>	1 st damping frequency	2214h	PR_214	Immediate		_			F
	1 st damping filter	2215h	PR_215	Immediate					F
	Position command smoothing filter	2222h	PR_222	Keep stop					F
	Position command FIR filter	2223h	PR_223	Disable	PP			HM	
	Internal/External settings of velocity settings	ernal elocity 2300h PR_300 Immediate						F	
	Velocity command input inversion	2303h	PR_303	Immediate		PV			
	1 st speed of velocity setting	2304h	PR_304	Immediate		PV			
ontrol	2 nd speed of velocity setting	2305h	PR_305	Immediate		PV			
ue c	3 rd speed of velocity setting	2306h	PR_306	Immediate					F
Torq	4 th speed of velocity setting	2307h	PR_307	Immediate					F
city/	5 th speed of velocity setting	2308h	PR_308	Immediate					F
Velo	6 th speed of velocity setting	2309h	PR_309	Immediate					F
s 3]	7 th speed of velocity setting	2310h	PR_310	Immediate					F
[Clas	8 th speed of velocity setting	2311h	PR_311	Immediate					F
	Acceleration time settings	2312h	PR_312	Immediate		PV			
	Deceleration time settings	2313h	PR_313	Immediate		PV			
	Sigmoid acceleration/deceleratio n settings	2314h	PR_314	Disable		PV			



Class	Label	CANopen Address	CANopen Parameter Activation Valid Mode					
	Zero speed clamp level	2316h	PR_316	Immediate				F
	Internal/External settings of torque	2317h	PR_317	Immediate		PV		
	Torque command direction selection	2320h	PR_320	Immediate		PV		
	Velocity limit value in torque mode	2321h	PR_321	Immediate				F
	Internal torque command	2322h	PR_322	Immediate				F
	Maximum motor rotational velocity	2324h	PR_324	Immediate				F
	Input selection DI3	2403h	PR_403	Immediate				F
	Input selection DI4	2404h	PR_404	Immediate				F
	Input selection DI5	2405h	PR_405	Immediate				F
	Input selection DI6	2406h	PR_406	Immediate				F
	Output selection DO1	2410h	PR_410	Immediate				F
0 interface	Output selection DO2	2411h	PR_411	Immediate				F
	Output selection DO3	2412h	PR_412	Immediate				F
	Positioning complete range	2431h	PR_431	Immediate				F
0 interface	Positioning complete output setting	2432h	PR_432	Immediate	PP		HM	
	INP positioning delay time	2433h	PR_433	Immediate				F
	Zero speed	2434h	PR_434	Immediate				F
(1/	Velocity coincidence range	2435h	PR_435	35 Immediate				F
JSS	Reached velocity	2436h	2436h PR_436 Immediate					F
[Cla	Motor power-off delay time	2437h	PR_437	Immediate				F
	Delay time for holding brake release	2438h	PR_438	Immediate				F
[Class 5] Extended parameters [Class 4] I/O interface	Holding brake activation speed	2439h	PR_439	Immediate				F
	Emergency stop function	2443h	PR_443	Immediate	PP	PV I I PV I I F I I I		
	Driver prohibition input settings	2504h	PR_504	Immediate				F
ราอ	Servo-off mode	2506h	PR_506	After restart				F
amete	Main power-off detection time	2508h	PR_508	Immediate				F
l para	Servo-off due to alarm mode	2510h	PR_510	After restart				F
nded	Servo braking torque setting	2511h	PR_511	Immediate				F
xte	Overload level setting	2512h	PR_512	Immediate				F
Ш —	Overspeed level settings	2513h	PR_513	Immediate				F
; 5]	I/O digital filter	2515h	PR_515	Immediate				F
3SE	Position unit settings	2520h	PR_520	Disable				F
Clé	Torque limit selection	2521h	PR_521	Immediate				F
_	2 nd torque limit	2522h	PR_522	Immediate				F
	Positive torque warning	2523h	PR_523	Immediate	PP		HM	



Class	Label	CANopen Address	Parameter	Activation	Valid Mode			
	threshold							
	Negative torque warning	252/h	DD 52/	Immodiato				F
	threshold	232411	FILJZ4	Inneulate				'
	Torque warning							
	threshold alarm delay	2537h	PR_537	After restart				F
	time							_
-	3 rd lorque limit	2539h	PR_539	Immediate				F
	JUG trial run velocity	2604h	PR_604	Immediate				F
	command Desition 2rd sain valid						 	
	time	2605h	PR_605	Immediate	PP		HM	
	Desition 2rd gain scale							
	factor	2606h	PR_606	Immediate	PP		HM	
	Torque command						 	
	additional value	2607h PR_607 Immediate					F	
	Positive direction torque	sitive direction torque					-	
ຽ	compensation value	2608h	PR_608	Immediate				F
eter	Negative direction torque	2/004	DD (00	lucus e di et e				F
Ш.	compensation value	26090	PR_609	Immediate				Г
ıra	Current response	2611h PR_611 Immediate					F	
Ъ	settings						<u> </u>	
ial	Encoder zero position	2612h	PR 612	Immediate				F
Dec	torque offset limit							-
Sp	Max. time to stop after	2614h	PR 614	Immediate				F
[9]	disabling		-					-
ISS	Irial run distance	2620h	PR_620	Immediate			!	
Cla	Irial run waiting time	262IN	PR_621	Immediate				F
	No. of trial run cycles	2022N	PR_622	Immediate			 	г г
	Trial run acceleration	2020N	PR_020	Immediate				г Е
	Special function registry	202011	FR_020	Inneulate				-
		2638h	PR_638	Immediate				F
	Z Torque limit for collision							
	prevention	2656h	PR_656	Immediate				F
	Duration time for							_
	collision prevention	2657h	PR_657	Immediate				F
	Homing position (16-bit	2/504						-
	high)	2658h	PK_658	Immediate				F
	Homing position (16-bit	24506	DD 450	Immediate				
	Low)	20370	PR_009	immediate				
	Z signal holding time	2661h	PR_661	Immediate				F
	Overload threshold	2662h	PR_662	Immediate				
	Absolute multiturn data	2663h	PR 443	After restart				F
	upper limit	200311	11.003					



Class	Label	CANopen Address	Parameter	Activation	Valid Mode
	Current loop gain	2700h	PR_700	Immediate	F
	Current loop integral time	2701h	PR_701	Immediate	F
	Motor rotor initial angle compensation	2702h	PR_702	Immediate	F
	Current differential coefficient	2703h	PR_703	Immediate	F
	Death zone compensation coefficient	2704h	PR_704	Immediate	F
	Motor pole pairs	2705h	PR_705	Immediate	F
	Motor phase resistance	2706h	PR_706	Immediate	F
	Motor D/Q inductance	2707h	PR_707	Immediate	F
	Motor back EMF coefficient	2708h	PR_708	Immediate	F
St	Motor torque coefficient	2709h	PR_709	Immediate	F
ory setting	Motor rated rotational speed	2710h	PR_710	Immediate	F
	Motor maximum speed	2711h	 PR_711	Immediate	F
	Motor rated current	2712h	 PR 712	Immediate	F
act	Motor rotor inertia	2713h	 PR_713	Immediate	F
ц	Motor power rating	2714h	 PR_714	Immediate	F
; 7]	Motor model	2715h	 PR_715	Immediate	F
ase	Encoder model	2716h	PR_716	Immediate	F
Cla	Motor max. current	2717h	 PR_717	Immediate	F
	Encoder precision	2723h	PR_723	Immediate	F
	Internal regenerative energy gain	2728h	PR_728	Immediate	F
	DC bus voltage measuring filter	2729h	PR_729	Immediate	F
	Undervoltage threshold value	2730h	PR_730	Immediate	F
	Regenerative energy control mode settings	2731h	PR_731	Immediate	F
	Regenerative energy on threshold value settings	2732h	PR_732	Immediate	F
	Regenerative energy hysteresis control	2733h	PR_733	Immediate	F
	Overvoltage threshold value	2734h	PR_734	Immediate	F
	Power-on enabling delay time	2748h	PR_748	Immediate	F



3.1.2 Motion parameter starting with object dictionary 6000

Index	Sub-index	Label	Unit	Default	Min	Max	Mode
603F	0	Error code	-	0x0	0x0	0xFFFF	F
6040	0	Control word	-	0x0	0x0	0xFFFF	F
6041	0	Status word	-	0x0	0x0	0xFFFF	F
605A	0	Quick stop option code	-	2	0	7	F
605B	0	Shutdown option code	-	0	0	1	F
605C	0	Disable operation option code	-	0	0	1	F
605D	0	Halt option code	-	1	1	3	F
6060	0	Mode of Operation	-	8	1	11	F
6061	0	Mode of Operation display	-	0	0	10	F
6062	0	Position Demand Value	Command unit	0	- 2147483 648	2147483 647	PP/HM
6063	0	Position Actual Internal Value	Encoder unit	0	- 2147483 648	2147483 647	F
6064	0	Position Actual Value	Command unit	-	- 2147483 648	2147483 647	F
606B	0	Velocity Demand Value	Command unit/s	0	- 2147483 648	2147483 647	PV
606C	0	Velocity Actual Value	Command unit/s	0	- 2147483 648	2147483 647	РР/НМ
6071	0	Target Torque	0.001	0	-32768	32767	PT
6072	0	Max Torque	0.001	3000	0	65535	F
6073	0	Max Current	0.001	3000	-	65535	F
6074	0	Torque Demand	0.001	0	-32768	32767	F
6075	0	Motor Rated Current	mA	3000	0	2147483 647	F
6076	0	Motor Rated Torque	mN.m	3000	0	2147483 647	F
6077	0	Torque Actual Value	0.1%	0	-5000	5000	F
6078	0	Current Actual value	0.1%		-5000	5000	
6079	0	DC bus voltage	mV	0	0	2147483 647	F
607A	0	Target position	Command unit	0	- 2147483 648	2147483 647	PP
607C	0	Homing position offset	Command unit	0	- 2147483 648	2147483 647	НМ
	0	Number of Entries	-	2	0	2	PP
607D	1	Min. software limit	Command unit	0	- 2147483	2147483 647	PP



					648		
	2	Max. software limit	Command unit	0	- 2147483 648	2147483 647	PP
607E	0	Polarity	-	0x0	0x0	0xFF	F
607F	0	Max Profile Velocity	Command unit /s	214748 3647	0	2147483 647	PP/HM /PV
6080	0	Max Motor Speed	r/min	6000	0	2147483 647	F
6081	0	Profile Velocity	Command unit /s	10000	0	2147483 647	PP
6083	0	Profile Acceleration	Command unit /s²	10000	1	2147483 647	PP/PV/
6084	0	Profile Deceleration	Command unit /s²	10000	1	2147483 647	PP/PV
6085	0	Quick Stop Deceleration	Command unit /s²	100000 00	1	2147483 647	PP/PV/ HM
6087	0	Torque Slope	0.001/s	5000	1	1 2147483 647	
	0	Number of Entries	-	2	0	2	F
608F	1	Encoder Increments	Encoder unit	10000	1	2147483 647	F
	2	Motor Revolutions	r	1	1	2147483 647	F
6091	0	Number of Entries	-	2	0	2	F
	1	Motor Revolutions	r	1	1	2147483 647	F
	2	Shaft Revolutions	r	1	1	2147483 647	F
6092	0	Number of Entries	-	2	0	2	F
	1	Feed	Command unit/r	10000	1	2147483 647	F
	2	Shaft Revolutions	r	1	1	2147483 647	F
6098	0	Homing method	-	19	-6	37	НМ
	0	Number of Entries	-	2	0	2	F
6099	1	Speed During Search For Switch	Command unit /s	10000	0	2147483 647	НМ
	2	Speed During Search For Zero	Command unit /s	5000	0	2147483 647	НМ
609A	0	Homing acceleration /deceleration	Command unit /s²	50000 0	1	2147483 647	НМ
60C5	0	Max Acceleration	Command unit /s²	100000 000	1	2147483 647	F
60C6	0	Max Deceleration	Command unit /s²	100000 000	1	2147483 647	F
60E0	0	Positive Torque Limit	0.001	3000	0	65535	F
60E1	0	Negative Torque Limit	0.001	3000	0	65535	F
60F4	0	Following Error Actual Value	Command unit	0	- 2147483 648	2147483 647	PP/HM
60FA	0	Control Effort	Command	0	-	2147483	PP/HM



			unit /s		2147483 648	647	
60FC	0	Position Demand Internal Value	Encoder unit	0	- 2147483 648	2147483 647	РР/НМ
60FD	0	Digital Inputs	-	0x0	0x0	0x7FFFF FFF	F
	0	Number of Entries	-	2	0	2	F
60FE	1	Physical Outputs	-	0x0	0x0	0x7FFFF FFF	F
	2	Bit Mask	-	0x0	0x0	0x7FFFF FFF	F
60FF	0	Target velocity	Command unit /s	0	_ 2147483 648	2147483 647	PV
6502	0	Supported drive modes	-	0x0	0x0	0x7FFFF FFF	F

3.2 Parameter Function

• Panel Display as follows:

classify and code

 Parameter valid under following modes HM: Homing mode
 PP: Profile position mode
 PV: Profile velocity mode
 PT: Profile torque mode
 F: All modes

3.2.1 【Class 0】 Basic Settings

	Label	Model-following bandwidth			Valid Mode					F
Pr0.00	Range	0~2000	Unit	0.1Hz	Default	0	Index			2000h
	Activation	Immediate								
Model-following bandwidth, also known as model-following control (MFC), is used to control the										
position loop to improve the responsiveness to commands, speed up positioning time and										
	reduce following error. The effect is obvious especially in low and medium mechanical stiffness.									
	Value	Explanation Disable the function.								
	0									
	1 Enable the function to set bandwidth automatically, recommended for most applications. Pr0.00=Pr1.01									
	2-9	Invalid								
*Recommended settings for belt application: 30 <pr0.00<100.< th=""><th></th></pr0.00<100.<>										


	Label		Control Mod	de Setting	js	Valid Mode			F
Pr0.01	Range		0~8	Unit	-	Default	8	Index	2001h
	Activation	ì	After restar	t					
	Set value	to us	e following c	ontrol ma	odes:				
	Value		Content		Detail	S			
	0	Posit	tion	Only for	internal p	osition			
	1	Velo	city	Only for	internal v	elocity			
	2~7	Res	erved	-					
	8	CAN	open	PP/PV/P	T/HM				

D-0.02	Label	Real time A Adjusting	uto Gain		Valid Mode						F
Pru.uz	Range	0-2	Unit	_	Default	0	In	ndex		2002h	ı
	Activation	Immediate									
	Set up the	mode of the real	time auto	o gain ac	djusting.						
	Value	Content			Details						
	0	Invalid	Auto ad	justing i	nvalid						
	1	Standard	Pr0.03 v achieve switchir applicat	0.03 valid. Quick gain adjusting can be chieved by changing Pr0.03 stiffness value. Gain vitching is not used in this mode, suitable for polications with requirements for stability.							
	2	Positioning	Pr0.03 v achieved mode is position vertical load usi	r0.03 valid. Quick gain adjusting can be chieved by changing Pr0.03 stiffness value. This node is suitable for applications requiring quick ositioning. Not recommended for load mounted ertical to ground, or please compensate for the							

D=0.02	Label	Real time a adjusting	uto stiffn	ess	Mode						F
Pr0.03	Range	50 ~ 81	Unit	—	Default	70		Index			2003h
	Activation	Immediate									
	Valid when Pr0	.03 = 1,2									
		Low —	— ► Mee	chanical stif	fness	► Hig	gh				
		I orre —		Comro coir		, 11 2	-h				
		Low –		Servo gan	1	П	gn				
										1	
	81.80	•••••	•••••	•••••70.69.68	3 • • • • • • • • • • • • • • •	•••••	•••••	····51	.50		
										l	
		Low –	►	Responsiver	ness —	► Hig	gh				
				-		-					
	Lower values e vibration might	ensure better : occur, pleas	system e set acc	responsivene ordingly.	ess and med	:hanic	al sti	ffness	s but r	machi	ine



	Label	Inertia rat	io		Mode					F
Pr0.04	Range	0~1 0000	Unit	%	Default	250	Ind	ex	2004h	1
	Activation	Immediate	9							

Pr0.04=(load inertia/motor rotational inertia)×100%

Notice:

Set inertia ratio according to actual load inertia. When both are uniform, actual motor velocity loop responsiveness and gain settings will be consistent. If inertia ratio is greater than actual value, velocity loop gain settings will be higher and vice versa.

	Label	Rotational of	direction		Mode			F
Pr0.06	Range	0~1	Unit	I	Default	0	Index	2006h
	Activation	After resta	-t					
	Used to chang	e the rotation	al directi	on of tł	ne motor.			
	Set value				Details			
	0	Polarity of th	e comma	nd is no	ot inversed. Th	e directio	n of rotation is	
	0	consistent w	ith the po	larity o	f command.			
	1	Polarity of co	ommand i	s invers	sed. The directi	ion of rota	ation is opposite to	
	I	the polarity o	of comma	nd.				
	Note: Rotation	al direction of	the moto	or is re	commended t	o be set t	hrough object diction	onary 607E.
	However, Pr0.0	16 has higher	priority t	han ob	ject dictionary	607E.60)7E only takes effec	t when
	Pr0.06 = 0.							

D-0.00	Label	Command pul revolution	se coun	ts per	Mode					F
Pru.08	Range	0~8388608	Unit	P-	Default	0	Index		2008h	1
	Activation	After restart								
	Pulses per revo	lution can be se	et using	object dic	tionary 608	3F, 6091, 6	092. How	ever, Pr	0.08 ha	is
	higher priority.									

	Label	1 st Torque	e Limit		Mode				F
Pr0.13	Range	0~500	Unit	%	Default	300	Index		2013h
	Activation	Immedia	te						
	1 st torque limit is driver output cu Actual torque lin	s set accor rrent. mit is the s	ding to ra	atio perc alue of P	entage of mot	or rated ct dictio	l current. D nary 6072)o not exc	eed max

D-01/	Label	Excessiv Deviation	e Position Settings	1	Mode	PP			HM			
Pru.14	Range	0~500	Unit	0.1rev	Default	30		Index	(2014h	
	Activation	Immedia	te									
	Please set thre will be triggere	shold valu d if positiv	e for posi e deviatio	tion devia n is in ex	ation accordin cess of 3 revo	gly. Defa lutions.	ault	facto	ry sett	ing =	30, Er1	80



	Label	Absolute	Encoder	settings	Mode	PP	HM					
Pr0.15	Range	0~32767	Unit	-	Default	0	Index	2015h				
	Activation	Immediat	е									
	0: Incremental I	mode:										
	Used as an ir	ncremental	encoder	. Doesn't i	retain position (data on po	ower off. Unlimite	ed travel				
	distance.											
	1: Multiturn line	ar mode:										
	Used as a mu	ultiturn abs	olute en	coder. Ret	train position da	ata on pov	ver off. For appli	cations				
	with fixed tra	vel distanc	e and no	multiturr	n data overflow.							
	2: Multiturn rota	ary mode:										
	Used as a mu	ultiturn abs	olute en	coder. Ret	rain position da	ata on pov	wer off. Actual da	ta				
	feedback in b	etween 0-	(Pr6.63).	Unlimited	travel distance	9.						
	3: Single turn a	bsolute mo	de:				.					
	Used when tra alarm.	avel distanc	e is with	in 1 revolu	ution of the enc	oder. Data	a overflow will tr	igger				
	5: Clear multitu once alarm c	irn alarm a leared, if re	nd activa emains a	te multitu t 5 after 3	ırn absolute fur Is, please solve	nction. Wil accordin	ll switch to multi g to Er153.	turn mode				
	9: Clear multitu	ırn positior	, reset n	nultiturn a	alarm and activ	/ate multi	turn absolute fu	nction. Will				
	switch to mu	ltiturn mod	e once a	larm clea	red, if remains	at 9 after	[.] 3s, please solve	according				
	to Er153. Please disable axis before setting to 9 and home the axis before using.											
					-							

	Label	Regenerat	ive resist	tance	Mode			F
Pr0.16	Range	40~500	Unit	0hm	Default	100	Index	2016h
	Activation	Immediate	;					
	To set resistanc	e value of r	egenerat	ive resist	or			

D-0 17	Label	Regenera power rat	tive resis ing	stor	Mode					F
Pru.17	Range	20~5000	Unit	W	Default	50	Index		2017h	
	Activation	Immediat	е							
	To set power rat	ing of rege	nerative i	resistor.						
	Pr0.16 and Pr0.17	7 determine	s the thr	eshold v	alue of Er 120	. Please s	et accordingl	y or it	might	
	trigger false ala	rm or dama	age to ser	rvo drive	r.					
	Note: If external	l regenerati	ive resist	or is use	d, please set	according	to its labele	d powe	er ratin	ıg.

	Label	CANoper	node		Mod	е					F
Pr0.23	Range	0~127	Unit	_	Defa	ult	16	Inde	х		2023h
	Activation	After res	tart								
	Set ID numb	er of the node	under CA	Nopen m	ode						
	Label	CAN Bau	d rate		Mod	е					F
Pr0.24	Range	Unit	_	Defa	ult	1	Inde	х	1	2024h	
	Activation After restart										
	CANopen de	vice Baud rate	settings								
	Pr0.24	CAN Baud ra	te(kHz)	Pr0.2	24	CAN Ba	ud rate	(kHz)			
	0	1000		4		125					
	1 800			5	100		100				
	2 500			6		50					
	3	250		7		20					



3.2.2 【Class 1】 Gain Adjustments

	Label	1 st positio	n loop ga	gain Mode PP			HM						
Pr1.00	Range	0~3000 0	Unit	0.1/s	Default	320	Index	2100h					
	Activation	Activation Immediate											
	Higher position loop gain value improves the responsiveness of the servo driver and lessens												
	the positioning time.												
	Position loop ga	ain value s	houldn't e	xceed re	sponsivenes	s of the me	chanical system	and take in					
	consideration v	elocity loo	p gain, if i	not it mig	jht cause vib	ration, mecl	nanical noise and	d overtravel.					
	As velocity loop gain is based on position loop gain, please set both values accordingly.												
	Recommended range: 1.2 \leq Pr1.00/Pr1.01 \leq 1.8												

	Label	1 st velocit	y loop gai	n	Mode					F				
Pr1.01	Range	1~32767	1~32767 Unit 0.1Hz Default 180 Index 2101h											
	Activation	Immediate												
	To determine th actual inertia ra To increase pos gain must be se cause vibration	ne respons atio, velocit sition loop et at higher n.	iveness o y loop re gain and i value. Pl	f the velo sponsive mprove i lease not	ocity loop. If i ness = Pr1.01 responsivene ice that if the	nertia ratio ess of the w e velocity lo	o of Pr0.04 is hole system oop gain is to	unifoi , velo o higł	rm with city loc n, it mig	հ շբ ght				

	Label	1 st Integra of Velocit	l Time Co y Loop	onstant	Mode					F		
Pr1.02	Range	1~10000	Unit	0.1ms	Default	310	Index		2102h			
	Activation	Immediat	е									
	If auto gain adjusting function is not enabled, Pr1.02 is activated. The lower the set value, the closer the lag error at stop to 0 but might cause vibration. If the value set is overly large, overshoot, delay of positioning time duration and lowered responsiveness might occur. Set 10000 to deactivate Pr1.02.											
	Recommended range: $50000 \le Pr1.01xPr1.02 \le 150000$ For example: Velocity loop gain Pr1.01=500(0.1Hz), which is 50Hz. Integral time constant of velocity loop should be 100(0.1ms) $\le Pr1.02 \le 300$ (0.1ms)											



	Label	1 st ve	elocity	/ detectio	n filter	Μ	ode						F
Pr1.03	Range	0~10	000	Unit	I	D	efault	15		Index			2103h
	Activation	Imm	ediate	e									
	This filter i velocity fee responsive the followi	s a low pa edback dat eness will ng table.	ss filt ta. The also b	er. It bloo higher t lowere	cks high he set va d. Pr1.03	freq alue nee	uencies wl , lower frec eds to matc	nich ca quenci h velo	ause es w city	systen ill be b loop ga	n insta locke iin. Pla	abilit d and ease	y from I velocity refer to
		Set Value	Velo Filta	ocity Dete	ection F		Set Value	Velo	city [off F	Detecti	on Fil	ter را	
		Value	Free	quency(H	z)		Value			requer	icy(i12	•/	
		0	2500				16	750					
		1	2250				17			700			
		2	2100		0		18		6		650		
		3	2000				19			600			
		4	1800				20			550			
		5		160	0		21	500					
		6		150	0		22			450			
		7		140	0		23			400			
		8		130	0		24			350			
		9		120	0		25			300			
	10			110	0		26			250			
	11			100	0		27			200			
	12		950			28	8 175						
	13		900		29	150							
	14		850		30	125							
		15	800				31			100			

	Label	1 st Torqu Constant	ie Filter	r Time	Mode							F
Pr1.04	Range	0~2500	Unit	0.01ms	Default	126		Index			2104h	
	Activation	Immediate	5									
	To set torque cor filter out the high Often used to rec reduce the respo loop control. Pr1. Recommended r For example: Vel should be Pr1.01 If mechanical vib smaller the value value is too large With higher Pr1.01	mmand low of frequencies duce or elin onsiveness 04 needs to ange: 1,000, ocity loop g 221(0.01ms oration is du e, the better e, it might lo 1 value setti value setti	-pass filt es in the o ninate sor of curren o match v 000/(2π×I ain Pr1.01 s) te to serv the resp ower the r ings and ngs, incre	er, add a command me noise t loop, res elocity lo Pr1.04) =180(0.1H o driver, a onsivene responsiv no reson ease Pr1.0	filter delay tir l. or vibration c sulting in und op gain. Pr1.01×4 z) which is 18 adjusting Pr1. ess but also s veness of curr ance, reduce <u>04 value to lov</u>	ne con luring lermin BHz. Ti BHz. Ti 04 min ubject rent lo Pr1.04 wer m	moto ing v me co ght el ed to pop. valu	t to to or ope elocity onstar limina mach e; noise.	ratior y loop nt of t te the	comr n, but and orque vibra	nand a it will positio e filter ation. ons. If	and on - The f the



	Label	2 nd Positio	n Loop	Gain	Mode	PP		HM			
Pr1.05	Range	0~30000	Unit	0.1/s	Default	380	80 Index			2105h	
	Activation	Immediate	;								

	Label	2 nd velocit	y loop g	gain	Mode						F
Pr1.06	Range	1~32767	Unit	0.1Hz	Default	180 Index			2106h		
	Activation	Immediate									

Pr1.07	Label	2 nd Integra Constant Loop	al Time of Velo	city	Mode						F
	Range	1~10000	Unit	0.1ms	Default	1000	0	Index		2107h	
	Activation	Immediat	е								

	Label	2 nd ve filter	locity d	etection	Mode							F
Pr1.08	Range	0~31	Unit	-	Default	15		Index			2108h	
	Activation	Immediate										

	Label	2 nd Torqu Constant	e Filter	Time	Mode							F		
Pr1.09 F	Range	0~2500 Unit 0.01ms			Default	126		Index			2109h			
	Activation	Immediate												
	Position loop, velocity loop, velocity detection filter, torque command filter each have 2 pairs of gain or time constant (1st and 2nd).													

	Label	Velocity gain	feed	forward	Mode	PP			НМ			
Pr1.10	Range	0~1000	Unit	0.10%	Default	300		Index			2110h	
-	Activation	Immediat	te									
	Used for decreasing following error caused by low responsiveness of velocity loop. Might cause overshoot or increase in noise if set value is too high.											



	Label	Velocity filter time	feed e const	forward ant	Mode	PP	НМ	
Pr1.11	Range	0~6400	Unit	0.01ms	Default	50	Index	2111h
	Activation	Immedia	te					
	Set velocity feed for forward command. (ration to smoothen v Position deviation ur Please to refer to th Position deviation[Uir	ward low p Dften used velocity fee nder const e equation nt]= Pa	bass filt when p ed forw ant velo below. Set velo osition lo	ter to elin position c ard. pocity can pocity[<u>Uint</u>] pop gain[h	ninate high or ommand with be lowered wi <u>lz]</u> x <u>100 – Vel</u>	abnorm low res ith highe <i>ocity fee</i> 10	nal frequencies in v solution or high elec er velocity feed forv ad foward gain[%] 00	elocity feed stronic gear vard gain.

	Label	Torque gain	feed	forward	Mode	PP	PV	НМ				
Pr1.12	Range	0~1000	Unit	0.1%	Default	0		Index		21	12h	
	Activation	Immedia	te									
	Before using torque feed forward, please set correct inertia ratio. By increasing torque feed forward gain, position deviation on constant acceleration/deceleration can be reduced to close to 0. Under ideal condition and trapezoidal speed profile, position deviation of the whole motion can be reduced to close to 0. In reality, perturbation torque will always exist, hence position deviation can never be 0.											

	Label	Torque filter tim	feed ie const	forward ant	Mode	PP	PV	НМ			
Pr1.13	Range	0~6400	Unit	0.01ms	Default	0		Index		2113h	
	Activation	Immedia	te								
	Low pass filter to eliminate abnormal or high frequencies in torque feed forward command. Usually used when encoder has lower resolution or precision. Noise reduces if torque feed forward filter time constant is set higher but position deviation will increase at acceleration varied points.									n will	



		Label		Positi switch	on control ning mode	gain	Mode						F		
Pr1.15		Range		0~11	Unit	—	Default	0	Ind	ex		2115h	ı		
		Activat	ion	Imme	diate										
	Se Va	t lue	Condition		Gain swit	ching co	n dition								
	0 1		1 st gain fixe 2 nd gain fixe	d ed	Fixed on Fixed on	using 1 st g using 2 nd	gain(Pr1.00-Pr gain (Pr1.05-F	1.04) Pr1.09)							
	2		Reserved			-	-								
	3		High set to	^que	Switch to 2 ^{ine} gain when set torque command absolute value larger than (level + hysteresis)[%] Switch to 1 st gain when set torque command absolute value smaller than (level + hysteresis)[%] Hysteresis Level Acceleration Constant Deceleration Set Torque I st I s										
	4		Reserved		Reserved										
	5		High set ve	locity	Set Velocit Valid f Switch larger Switch smalle	y y to 2 nd ga than (lev to 1 st gai er than (le	on and velocity in when set ve el + hysteresis n when set ve evel-hysteresi	2nd 2nd 2nd 2nd 2nd 2nd 2nd 2nd 2nd 2nd	ol. commar n] comman in]	Ind abso	 olute v	value alue			



		Valid for position control. Switch to 2 nd gain when position deviation absolute value larger than (level + hysteresis)[pulse] Switch to 1 st gain when position deviation absolute value smaller than (level-hysteresis)[pulse]
6	Large position deviation	Set Velocity Level Hysteresis Position Deviation
7	Pending position command	Valid for position control. Switch to 2^{nd} gain if position command $\neq 0$ Switch to 1^{st} gain if position command remains = 0 throughout the duration of delay time.
8	Not yet in position	Valid for position control. Switch to 2 nd gain if position command is not completed. Switch to 1 st gain if position command remains uncompleted throughout the duration of delay time.
9	High actual velocity	Valid for position control. Switch to 2 nd gain when actual velocity absolute value larger than (level + hysteresis)[r/min] Switch to 1 st gain when actual velocity absolute value remains smaller throughout the duration of delay time than (level-hysteresis)[r/min]





*** Above 'level' and 'hysteresis' are in correspondence to Pr1.17 Position control gain switching level and Pr1.18 Hysteresis at position control switching.*

	Label	Position contro switching level	ol gain I		Mode				F
Pr1.17	Range	0~20000	Unit	Mode dependent	Default	50	Index	2117h	
	Activation	Immediate							
	Set threshold va Unit is mode dep	ue for gain swit endent.	ching t	o occur.					
	Switching condition	Unit							
	Position	Encoder pulse count							
	Velocity	RPM							
	Torque	%							
	Please set level	≥ hysteresis							



	Label	Hysteresi control sv	s at posi vitching	ition		Mode				F
Pr1.18	Range	0~20000	Unit	Mode depend	e ent	Default	33	Index		2118h
	Activation	Immediat	e							
	To eliminate the i	instability o	of gain sv	witching	. Use	ed in comb	ination	with Pr1.17	the same	e unit.
	If level< hysteres	is, drive wi	ll set int	ernally I	hyste	eresis = lev	vel.			
		I								
	Label	Position g	ain swit	ching	Мо	de				F
Pr1.19	Range	0~10000	Unit	0.1ms	Def	ault	33	Index		2119h
	Activation	Immediat	e							
	During position c loop gain, set sui For example: 1st	ontrol, to e table Pr1.19 (pr1.00) <->	ase torq value 2nd (Pr	jue chan 1.05)	ges	and vibrat	ion due	to rapid ch	nanges in	position
	2nd (F	Pr1.05)		Po	sitior	n gain]			
	1st (P	r1.00) —		sw	itchir	ng time (ms)	J			
	Result switch	t of 1	st		2nd			1st		

λ

	Labe	l	Special fu Register	Special function Register			Mode								F
Pr1.37	Rang	е	0~10000	Unit	0.1ms	5 C	Default		33		Index			2119h	
	Activ	ation	Immediat	e											
	Bit	Set value	Desc	ription		Bit	Set value			De	scription				
	0	0x0001	Disable velocity	loss alarn	n 1A1	8	0x0100	Disa	ible reg	genera	tive enei	rgy alar	m 121		
	1	0x0002	Disable overspe	ed alarm	1A0	9	0x0200	Disable phase loss alarm 0A3							
	1 0x0002 Di 2 0x0004 al		Disable excessive deviation alarm 180			10	0x0400	Res	erved						
	3	0x0008	Disable multitur alarm 157	Disable multiturn data overflow alarm 157		11	0x0800	Disable software overcurrent alarm 0E0					rm		
	4	0x0010	Disable overloa	d alarm 10	00	12	0x1000	Disa	ible en	coder	loss alar	m150			
	5	0x0020	Disable encode error at initializa	Disable encoder data saving error at initialization alarm			0x2000	Disable encoder data error alarm 151							
	6	0x0040	Disable excessi alarm 190	Disable excessive vibration			0x4000	Disbale encoder communication error alarm 170							
	7	0x0080	Disable excessi energy alarm 12	Disable excessive regenerative energy alarm 120			0x8000	Enal	ble toro	que sa	turation	alarm 1	05		



	Label		Special fu Register	unction		Mode								F
Pr1.37	Range		0~10000	Unit	0.1ms	Default		33		Index			2119h	
	Activati	on	Immediat	е								-		
	Bit		Descri	otion		Bit			Desc	ription				
	0	Positioning done signal for Status Word 0: 6062 1: INP input signal				8	Reserved							
	1	1 Reserved			9	Res	erved							
	2	Virtual I/O homing 0: Disable 1: Enable			10	Res	erved							
	3	Reserved	b			11	Res	erved						
	4	Reserved	d			12	Res	erved						
	5	Torque li 0: Inser 1: Do no	Torque limit under torque control mode 0: Insert 6071 1: Do not insert 6071			13	Reserved							
	6	Reserved			14	Res	erved							
	7	7 Reserved				15	Res	erved						

3.2.3 【Class 2】 Vibration Suppression

	Label	Adaptive settings	e filterin	g mode	Mode						F	
Pr2.00	Range	0~4	Unit	-	Default	0	Index		2	200h		
	Activation	Immedia	ate									
	Set value				Explanation	1						
	0	Adaptive fi	daptive filter: invalid Parameters related to 3 rd and 4 th notch f remain unchanged							er		
	1	Adaptive fi valid for or	lter: 1 filto nce.	er	1 adaptive filter becomes valid. 3 rd notch filter related parameters updated accordingly. Pr2.00 switches automatically to 0 once updated.							
	2	Adaptive fi remains va	Adaptive filter: 1 filter remains valid			1 adaptive filter becomes valid. 3 rd notch filter related parameters will keep updating accordingly.						
	3-4	Reserved			-							



	Label	1 st notch fre	equency	,	Mode							F
Pr2.01	Range	50~4000	Unit	Hz	Default	4000)	Index			2201h	
	Activation	Immediate										
	Set center frequency of 1 st torque command notch filter. Set Pr2.01 to 4000 to deactivate notch filter											

	Label	1 st no selectio	otch ba on	ndwidth	Mode						F		
Pr2.02	Range	0~20	Unit	-	Default	4		Index			2202h		
	Activation Immediate												
	Set notch bandwidth for 1 st resonant notch filter. Under normal circumstances, please use factory default settings. If resonance is under control, in combination with Pr2.01 and Pr2.03, Pr2.02 can be reduced to improve current loop responsiveness which allows higher mechanical stiffness settings.												

	Label	1 st notch o	depth sel	ection	Mode			F		
Pr2.03	Range	0~99	Unit	-	Default	0	Index	2203h		
	Activation	Immediat	е							
	Set notch depth Under normal c in combination responsiveness	for 1 st reso ircumstand with Pr2.01 which allo	onant not ces, pleas and Pr2. ows highe	ch filter. se use fa 02, Pr2.0 er mecha	actory defaul 3 can be red anical stiffne	t settings. If uced to imp ss settings.	f resonance is prove current	s under control, loop		
	Label	2 nd notch	frequend	cy .	Mode			F		
Pr2.04	Range	50~4000	Unit	Hz	Default	4000	Index	2204h		
	Activation	Immediat	e							
	Set center frequency of 2 nd torque command notch filter. Set Pr2.04 to 4000 to deactivate notch filter									

	Label	2 nd no selectior	tch ba 1	ndwidth	Mode						F
Pr2.05	Range	0~20	Unit	-	Default	4		Index			2205h
	Activation	Immedia	te								
	Set notch bandw Under normal ci in combination v responsiveness	vidth for 2' rcumstan vith Pr2.04 which allo	nd resona ces, pleas 4 and Pr2 ows highe	nt notch f se use fao .06, Pr2.0 er mecha	filter. ctory default se 5 can be reduce nical stiffness s	ttings ed to setting	s. If re impro gs.	esonar ove cu	nce is rrent	unde loop	er control,



	Label	2 nd notch	n depth se	election	Mode						F
Pr2.06	Range	0~99	Unit	-	Default	0	Inde	ex		2206h	1
	Activation	Immedia	te								
	Set notch depth When Pr2.06 val circumstances, with Pr2.04 and allows higher m	for 1 st rest ue is high please uso Pr2.05, Pr <u>echanical</u>	onant not er, notch e factory 2.06 can l stiffness	ch filter. depth be default so be reduce settings.	comes shallo ettings. If res ed to improve	ow, phas onance e curren	e lag red is under t loop res	uces. U control, sponsive	nder , in co eness	norma mbina s whicl	al ation h

	Label	3 rd notch	frequend	cy .	Mode						F
Pr2.07	Range	50~4000	Unit	Hz	Default	400	0	Index		2207h	
	Activation	Immediat	е								
	Set center frequ Set Pr2.07 to 40	ency of 3 rd 00 to deact	torque c ivate not	ommand tch filter	notch filter.						

	Label	3 rd not selection	ch ba	andwidth	Mode					F
Pr2.08	Range	0~20	Unit	-	Default	4	Index		2287h	
	Activation	Immediat	е							
	Set notch bandw Under normal ci	vidth for 3 rd rcumstanc	resonaı es, pleas	nt notch f se use fao	ilter. ctory default se	ttings.				

	Label	3 rd notch	depth se	lection	Mode			F
Pr2.09	Range	0~99	Unit	-	Default	0	Index	2206h
	Activation	Immedia	te					
	Set notch depth When Pr2.09 val	for 1 st reso ue is higho	onant not er, notch	ch filter. depth be	comes shallow	ı, phase la	g reduces.	

	Label	1 st dampi	ng freque	ency	Mode					F
Pr2.14	Range	0~2000	Unit	0.1Hz	Default	0	Index		2214h	
	Activation	Immedia	te							
	0: Deactivate									
	To suppress wol deceleration upo Pr2.15 to wobble Motion Studio)	bble at loa on stoppin frequenc	d end. Of g. Especi y (wobble	ten used ally effec frequen	when wobbl tive for wob cy can be de	e of flexib ble with fr termined	le structure du equencies und using tracing f	ue to Ier 10 uncti	high 0Hz. So on of	et













3.2.4 【Class 3】 Velocity/ Torque Control

	Label	Internal/Ex of velocity	cternal s settings	ettings	Mode						F
Pr3.00	Range	0~3	Unit	-	Default	1	Inc	dex		2300h	
	Activation	Immediate	;								
	Internal velocity s	ettings can	be achie	nput inter	rface.						
	Set value			Velocity							
	0	Analog velo	city comr	nand (SPR	2)						
	[1]	Internal velo	rnal velocity command: 1 st to 4 th speed (Pr3.04 to Pr3.07)								
	2	Internal velo Analog velo	ernal velocity command 1 st to 3 rd speed (Pr3.04 to Pr3.06), alog velocity command (SPR)								
	3	Internal velo	ocity com	mand 1 st to	o 8 th speed (Pr3	.00 to Pr	3.11)				

	Label		Velocity co inversion	ommand	l input	Mode			F
Pr3.03	Range		0~1	Unit	-	2303h			
	Activatio	on	Immediate	;					
	Specify t Set value	he polar	ity of the vo Motor ro	ltage app otational	plied to th directior	ne analog velo n	ocity com	mand (SPR).	
	0	Nor rever	n- "+\ 'sal "-V	/oltage" - 'oltage" -	→"Positive →"Negative	e direction" e direction"			
	1	Rever	rsal "+V "_\	oltage" → /oltage" -	► "Negativo → "Positivo	e direction" e direction"			
	While se device, n external	1 Reversal "+voltage" → "N "-Voltage" → "f hile servo driver is set on simulated vertice, motor might undergo abnormal letternal positioning device doesn't mate				y control and i ior when veloo polarity set in	n combin city comn Pr3.03	ation with exten nand signal pola	rnal positioning arity from

	Label	1 st speed of velo	city sett	ing	Mode			F
Pr3.04	Range	-10000~10000	Unit	r/min	Default	0	Index	2304h
	Activation	Immediate						
	Label	2 nd speed of vel	ocity set	ting	Mode			F
Pr3.05	Range	-10000~10000	Unit	r/min	Default	0	Index	2305h
	Activation	Immediate						
	Label	3 rd speed of velo	ocity set	ting	Mode			F
Pr3.06	Range	-10000~10000	Unit	r/min	Default	0	Index	2306h
	Activation	Immediate						
	Label	4 th speed of velo	ocity set	ting	Mode			F
Pr3.07	Range	-10000~10000	Unit	r/min	Default	0	Index	2307h
	Activation	Immediate						



	Label	5 th speed of	velocity	/ setting	Mode			F
Pr3.08	Range	-10000~1000	00 Un	nit r/mi	n Default	0	Index	2308h
	Activation	Immediate						
	Label	6 th speed of	velocity	/ setting	Mode			F
Pr3.09	Range	-10000~1000	00 Ur	nit r/mi	n Default	0	Index	2309h
	Activation	Immediate						
	Label	7 th speed of	velocity	/ setting	Mode			F
Pr3.10	Range	-10000~1000	00 Ur	nit r/mi	n Default	0	Index	2310h
	Activation	Immediate						
	Label	8 th speed of	velocity	/ setting	Mode			F
Pr3.11	Range	-10000~1000	00 Ur	nit r/mi	n Default	0	Index	2311h
	Activation	Immediate						
	Set internal velo	city command	ls, 1 st to	8 th speed				
	Label	Acceleratio	n time :	settings	Mode		PV	
Pr3.12	Range	0~10000	Unit	ms/ (1000RPM)	Default	0	Index	2312h
	Activation	Immediate						
	Label	Deceleratio	n time	settings	Mode		PV	
Pr3.13	Range	0~10000	Unit	ms/ (1000RPM)	Default	0	Index	2313h
	Activation	Immediate						
	If target velocity Pr3.12 = <i>1000/a</i> Pr3.13 = <i>1000/a</i> <i>a = x/t</i> For example: If r Pr3.12 = 1000/ <i>a</i> =	motor is to ac 20. Hence wi Velocity Initial vel (rpm)	chieve 1 hen Pr3	lsoorpm in 1500rpm in 12 = 20, m	a [unit: rpm/	/ms], ar /30=50 ieve 15 After eceleration me setting added	cceleration tin Prpm/ms 00rpm in 30s.	1e = <i>t</i> [ms]

Usually used when there is rapid acceleration or trapezoidal wave velocity command due to many different internal speed segments under velocity control mode which causes instable while motor in motion.



D-21/	Label	Sigmoid acceleratio settings	n/decelei	ration	Mode		PV			
Pr3.14	Range	0~1000	Unit	ms	Default	0	Index		2314h	
	Activation	Axis disabl	е							
	To set sigmoid a Velocity (RPM) Target velocity Vc	ts ts t ta ta ta ta ta ta ta ta ta	and decel	ts 1 1 1 1 1 1 1 1 1 1 1 1 1	turning poin	t in accord	lance to P	r3.12 and	l Pr3.13.	

	Label	Zero speed	clamp le	vel	Mode	P	V			
Pr3.16	Range	10~2000	Unit	RPM	Default	30	Index		2316h	
	Activation	Immediate								
	Velocity comman set in Pr3.23	d is forced to	o 0 when	actual	velocity is lov	wer than Pr	3.16 and	after sta	tic time	

	Label	Maximum m velocity	notor rot	ational	Mode					F
Pr3.24	Range	0~10000	Unit	r/min	Default	0	Index		2324h	۱
	Activation	Immediate								
	Maximum motor	rotational as	accorda	ance to	technical specif	ication	if set to	0		

3.2.5 【Class 4】 I/O Interface Setting

	Label	Input select	ion Dl1		Mode				F
Pr4.00	Range	0x0~0xFF	Unit	I	Default	0x0	Inde	x	2400h
	Activation	Immediate							
	Label	Input select	ion Dl2		Mode				F
Pr4.01	Range	0x0~0xFF	Unit	_	Default	0x1	Inde	x	2401h
	Activation	Immediate							
	Label	Input select	ion DI3		Mode				F
Pr4.02	Range	0x0~0xFF	Unit	_	Default	0x2	Inde	x	2402h
	Activation	Immediate							



	Label	Input select	ion DI4		Mode						F
Pr4.03	Range	0x0~0xFF	Unit	—	Default	0x16		Inde	x		2403h
	Activation	Immediate									
	Digital input DI	allocation usi	ng hexad	decimal	system						
							Set v	value			
		Input			Symbol	Norm	ally	Norr	nally	0x6	OFD(bit)
					оре	en	clo	ose			
		Invalid			—	01	ו		-		×
	Positi	ve limit switcł	า		POT	1h	1	8	1h		Bit1
	Negat	ive limit switc	h		NOT	2h		82h			Bit0
	C	lear alarm			A-CLR	41	۱	-			×
	Fo	Forced alarm			E-STOP		h	94h			×
	Ho	Home switch			ME-SWITCH	16	h	90	5h		Bit2
	• Please don't set anything other t			han liste	ed in table ab	ove.				•	

- Normally open: Valid when input = ON Normally close: Valid when input = OFF
- Er210 might occur if same function is allocated to different channels at the same time
- Channel that has no value doesn't affect driver motion.
- Front panel is of hexadecimal system.
- Pr4.00 Pr4.03 corresponds to DI1 DI4. External sensors can be connected if the parameters are all set to 0. Controller will read 60FD bit4 7 to get DI1 DI4 actual status.

	Label	Output sele	Output selection DO1								F
Pr4.10	Range	0x0~0xFF	Unit	-	Default	t	0x1	Index		2410h	
	Activation	Immediate									
	Label	Output sele	ction DO	2	Mode						F
Pr4.11	Range	0x0~0xFF	Unit	—	Default	t	0x3	Index		2411h	
	Activation	Immediate									
	Label	Output sele	ction DO	3	Mode						F
Pr4.12	Range	0x0~0xFF	x0~0xFF Unit -			t	0x4	Index		2412h	
	Activation	Immediate	mmediate								
	Digital output D	0 allocation u	using he	kadecim	nal syste	<u>m.</u>					
		Output		Syr	mbol		Se	value			
						Norma	ally open	Norma	ally close		
	Master	device contro	ol	-	-	0	Oh		-		
		Alarm		AL	_M	0)1h		81h		
	Ser	vo-Ready		S-F	RDY	0	2h		82h		
	External	ernal brake released			-OFF	0	3h		83h		
	Position	ing complete	IN	1P	0	4h		84h			
	Α	At-speed			AT-SPEED		05h		85h		
	Torque	rque limit signal			_C	06h		86h			
	Zero speed	speed clamp detection			ZSP		07h		87h		



Velocity coincidence	V-COIN	08h	88h
Servo status	SRV-ST	12h	92h
Position command ON/OFF	P-CMD	0Bh	8Bh
Velocity limit signal	V-LIMIT	0Dh	8Dh
Velocity command ON/OFF	V-CMD	0Fh	8Fh
Homing done	HOME-OK	22h	A2h

- Please don't set any other than the outputs listed in the table above.
- Normally open: Active low
- Normally close: Active high
- Front panel is of hexadecimal system.
- Pr4.10 Pr4.12 corresponds to D01 D03. If all parameters are set to 0, master device controls the outputs, object dictionary 0x60FE sub-index 01 bit16-18 corresponds to D01-D03.

	Label	Positionin range	ng	complete	Mode	PP			НМ		
Pr4.31	Range	0~10000	Unit	Command unit	Default	20		Inde	x	2431h	
	Activation	Immediat	е								
	To set position deviation range of INP1 position				ning completed	outpu	ıt sigi	nal.			

	Label	Positioning output settir	co Ig	mplete	Mode	PP		НМ				
Pr4.32	Range	0~4	Unit	-	Default	1	h	ndex		243	2h	
	Activation	Immediate										
	Output condition	ons of INP1 pos	of INP1 positioning completed output signal									
	Set value	Positioning c	itioning completed signal									
	0	Signal valid v	nal valid when the position deviation is smaller than Pr4.31									
	1	Signal valid v is smaller tha	vhen the an Pr4.3	ere is no 1	position comm	nand ar	nd po	sition dev	iatio	n		
	2	Signal valid v detection (ZS Pr4.31	vhen the P) signa	ere is no Il is ON a	position comm and the positio	nand, zo nal dev	ero-s iatior	peed clai n is small	np er tha	an		
	3	Signal valid v is smaller tha otherwise OF	vhen the an Pr4.3 F.	ere is no 1. Signal	position comn ON when with	nand ar iin the t	nd pos time s	sition dev set in Pr4	iatio 33	n		
	4	4 When there is no command, position detection starts after the delay time set in Pr4.33. Signal valid when there is no position command and positional deviation is smaller than Pr4.31.										



	Label	INP posi time	tioning	delay	Mode	PP	НМ			
Pr4.33	Range	0~15000	Unit	1ms	Default	0	Index	243	33h	
	Activation	Immediate								
	To set delay tir	ne when Pr	4.32 = 3							
	Set value	Positioning	complet	ed signa	ગ					
	0	Indefinite d	definite delay time, signal ON until next position command							
	1-15000	OFF within the time set; ON after time set. Switch OFF after receiving next position command.								

	Label	Zero spe	ed		Mode				F
Pr4.34	Range	1~2000	Unit	RPM	Default	50	Index		2434h
	Activation	Immedia	te						
	To set threshold valu Zero speed clamp de in Pr4.34 - Disregard valid for b - Hysteresis diagram o	e for zero tection (ZS the direct oth directi s of 10RPM n the right	speed SP) out tion of ons. I. Pleas side.	clamp d put sign f rotatio	etection. al valid whe n, to ZS	n motor sp (Pr4.34	eed goes un speed +10) r/min ve direction ON	Positive	e value set









	Label	Motor power	-off dela	y time	Mode			F
Pr4.37	Range	0~3000	Unit	1ms	Default	100	Index	2437h
	Activation	Immediate						
	To set dela from slidir	ay time for hol 1g.	lding bra	ike to be ac	tivated after	r motor	power off to p	prevent axis
	Label	Delay time fo release	or holding	g brake	Mode			F
Pr4.38	Range	0~3000	Unit	1ms	Default	0	Index	2438h
	Activation	Immediate						
	RK_OFF Motor Power Actual holdir brake status Motor Velocity *1: Delay tim *2: Delay tim is released of dependent o *3: Decelera whichever co *4: Pr4.37 se	e set in Pr4.38 off - OFF - ON - *2 - off - *2 - * - off - *2 - * - * - * - * - * - * - * - *	Brake re ON Brake re (BRK 1 1 1 3 Doment Bl pal is gi brake of etermine K_OFF g	RK_OFF sig ven until ac the motor. d by Pr6.14 jiven after o	nal is given tual holding or if motor	until ac braked speed g time.	tual holding brak is activated. It oes below Pra	rake is 4.39,

Delay time from the moment SRV_ON is given until BRK_OFF switch to BRK_ON, is less than 500ms.



Activation

	Label	Holding bra	ke activa	tion spee	d Mode					F
Pr4.39	Range	30~3000	Unit	RPM	Default	30	Index		2439h	I
	Activation	Immediate								
	To set the activ When SRV-OFF yet reached, BI BRK_OFF signa first.	ration speed fo signal is give RK_OFF is give al is determine	n, motor n, motor n. d by Pr6.	holding br decelera .14 or if m	ake will be a es, after it r otor speed g	octivated eaches I oes belo	l. below Pr4.3 ow Pr4.39, v	39 and P whichev	r6.14 is er com	not es
	Application: 1. After disablin given. 2. After disablin given.	g axis, Pr6.14 h g axis, Pr6.14 h	as been r as not be	eached bu	t motor spee d but motor s	d is still speed is	above Pr4. below Pr4.	39, BRK_ 39, BRK_	OFF sig OFF sig	nal nal
	Labal	F		-4:	Mada					
		Emergency			моае					F
Pr4.43	Range	0~1	Unit	-	Default	0	Index		2443h	1

0: Emergency stop is valid, servo driver will be forced to STOP and alarm occurs.
1: Emergency stop is invalid, servo driver will not be forced to STOP.

3.2.6 【Class 5】 Extension settings

Immediate

	Label	Driver setting	prohibiti s	ion input	Mode							F
Pr5.04	Range	0~2	Unit	_	Default	0	Ine	dex			2504h	1
	Activation	Activation Immediate										
	To set driver pr	ohibition	input (P	OT/NOT): If se	t to 1, no e	ffec	t or:	n hom	ing m	ode.	_	
	Set value			Expla	anation							
	0	$POT \rightarrow Pot$	ositive d	irection drive	prohibited							
		NOT \rightarrow N	egative	direction drive	prohibite	d						
	1	POT and I	DT and NOT invalid									
	2	Any single sided input from POT or NOT might car							r260			
	In homing mod	e, POT/NOT invalid, please set object dictionary 5012-04 bit0=1									_	



	Labe	l	Servo-off r	node		Mode					F
Pr5.06	Rang	е	0~5	Unit	_	Default	0	Index		2506h	۱
	Activ	ation	After resta								
	To set action for deceleration and stopping of motor										
		Value	Description	Description							
		0	Disable only	Disable only after velocity dropped below set value in Pr4.39							
	1 Disable immediately. Motor is in free stopping mode.						ping mo	de.			

	Label	Low voltage	trigger se	ttings	Mode							F
Pr5.08	Range	0-1	Unit	-	Default	1	In	dex			2508	₿h
	Activation	Immediate										
	If DC bus v select if Er	oltage is lower t r0D0 will be effe	ion of tir	ne set	in Pr	5.09,	, plea	se				
	Value	Protective mea voltage point	sure if mai									
	0	Err0D0 only oc	rr0D0 only occurs if servo drive is enabled									
	1	Err0D0 occurs	once DC bu	ıs voltage	is below set p	oint.						

If the time set in Pr5.09 is too long, Err0D0 will occur if transformer of main power supply drops between P-N. This is not related to the settings in Pr5.08.

	Label	Main power-	off detecti	on time	Mode					F
Pr5.09	Range	50~2000	Unit	ms	Default	50	Ir	ndex		2509h
	Activation	Immediate								
	To set duration	n time for dete	ction of m	ain power-c	off or low voltag	je supp	oly.			

	Label	Serv alar	ro-off due m mode	to	Mode						F		
Pr5.10	Range	0~2	Unit	-	Default	0	Index			251	0h		
	Activation	Afte	After restart										
	Value	Descript	ption										
	0	0 Dynamic brake enabled under normal or abnormal circumstances.											
	1	1 Dynamic brake enabled only under normal circumstances to prevent damage to											
		brake under high velocity and inertia situation.											
	2 Dynamic brake disabled once motor is enabled.												

	Label	Servo b	raking to	rque setting	Mode					F				
Pr5.11	Range	0~500	Unit	%	Default	0	Index			2511h				
	Activation	Immedi	ate											
	To set torque li	mit for se	servo braking mode.											
	lf Pr5.11 = 0, us	e torque l	r servo braking mode. ue limit as under normal situation.											
	Between max.	torque 60)72 and Pi	r5.11, actual toi	er valu	Je.								



	Label	Overloa setting	ad	level	Mode						F
Pr5.12	Range	0~115	Unit	%	Default	0	Index	¢		2512h	
	Activation	Immed	iate								
	lf Pr5.12 = 0, ov Use only when	erload le overloa	evel = 1159 d level de	% egrada	ation is needed.						

	Label	Overspeed	Mode							F		
Pr5.13	Range	0~10000	Unit	RPM	Default	0	Inde	ĸ			2513h	
	Activation	Immediate	<u>!</u>									
	If motor speed exceeds Pr5.13, Er1A0 might occur. When Pr5.13 = 0, overspeed level = max. motor speed x 1.2											

	Label	I/O digital f	ilter		Mode						F
Pr5.15	Range	0~255	55 Unit 0.1ms Default 10		10	Index	ĸ		2515h		
	Activation	Immediate	ļ								

Digital filtering of I/O input. Overly large value set will cause control delay.

	Label	Position unit	settings		Mode	PP		HM			
Pr5.20	Range	0~2	Unit	_	Default	2	Inde	x	2	520h	I
	Activation	Disable	able								
	Set value			Unit							
	0		Enco	oder un	it						
	1		Command								
	2		0.0)001rev							
	Command unit:	Pulse from ho	st								
	Encoder unit: P	Pulse from encoder									
	Pr5.20 only cha	0 only changes the unit use on host tra				as no rela	tion wi	ith any p	ositio	n	
	related parameters.				-						



	La	bel	Torque limit	selectio	n	Mode	PP		HM			
Pr5.21	Ra	nge	0~2	Unit	-	Default	2	Index	K	2!	521h	
	Ac	tivation	Immediate									
	_						_					
		Set value	Positive lim	it	Negati	ve limit value						
			value									
		0	Pr0.13		Pr0.13							
		1	Pr0.13		Pr5.22							
		2	60E0		60E1							
	Ro	tween max 1	toraue 6072 a	nd Pr5 2	1 actual	torque limit wi	Il tako er	naller	مبالد			

Mode 2nd torque limit Label F Unit Index 0~500 % Default 300 2522h Range Pr5.22 Activation Immediate Limited by motor max. torque. Between max. torque 6072 and Pr5.22, actual torque limit will take smaller value.

F
3h
3

	Label	Negative torqu threshold	ue warnin	g	Mode						F
Pr5.24	Range	0~300	Unit	%	Default	0		Index		2524h	
	Activation	Immediate									
	lf Pr5.24 = 0, th	reshold value =	= 95%								
	If torque small	er than rated to	orque, the	en output	= Torque con	nmand	limi	t			

	Label	Torque warn delay time	ing three	shold alarm	Mode							F
Pr5.37	Range	0~5000	Unit	Default	50	0	Index			2537h		
	Activation	Immediate										
	To set time thre Only applicable Under torque in before moving i	shold for outp for torque init itialization mo nto next step.	old for output torque to reach limit under torque initialization mode. torque initialization method -6 to -1 lization mode, motor torque reached Pr5.39 and the duration reaches Pr5.37 next step.									



3.2.7 【Class 6】 Other settings

	Label	JOG trial command	run	velocity	Mode						F
Pr6.04	Range	0~10000	Unit	r/min	Default	400		Index		2604h	
-	Activation	Immediate									
	To set velocity	for JOG trial r	un com	mand.							





	Label	Torque comn value	nand add	itional	Mode			F					
Pr6.07	Range	-100~100	Unit	%	Default	0	Index	2607h					
	Activation	Immediate			1								
	To set torque for Applicable for I Application: Wh load at that par d04, use that va	orward feed ad loaded vertical nen load move ticular point w alue as torque	Iditional v axis, cor along ver vith motor comman	value of npensat rtical ax r enable d additio	vertical axis. te constant to is, pick any po d but not rota onal value (co	rque. bint from t ting. Reco mpensatio	he whole motic rd output torqu on value)	on and stop the Je value from					
	Label	Positive directory compensation	ction torc n value	lne	Mode			F					
Pr6.08	Range	-100~100	Unit	%	Default	0	Index	2608h					
	Activation	Immediate	1										
	Label	Negative direction torque Mode F compensation value F											
Pr6.09	Range	-100~100	Unit	%	Default	0	Index	2609h					
	Activation	Immediate											
	To reduce the ef	fect of mechan	nical fricti	ion in th	e movement(s) of the a	kis. Compensat	ion values can					
	be set according	to needs for b	ooth rotat	ional di	rections.								
	Applications:												
	1. When motor is	at constant sp	beed, d04	will del	liver torque va	alues.							
	Torque value in positive direction = T1;												
	Torque value in negative direction = T2												
	Torque value in negative direction = T2 Pr6.08/Pr6.09 = T _f = $\frac{ T1 - T2 }{2}$												

	Label	Current resp	onse se	ttings	Mode			F
Pr6.11	Range	50~100	Unit	%	Default	100	Index	2611h
	Activation	Immediate						
	To set driver current loop related effective				lue ratio			

	Label	Max. time disabling	to stop	after	Mode							F	
Pr6.14	Range	0~3000	Unit	ms	Default	500	I	ndex			2614h		
	Activation	Immediate											
	To set the max After disabling reached, BRK_	. time allowed Jaxis, if motor .ON given and	me allowed for the axis to stop on emergency stop or normal axis disabling. is, if motor speed is still higher than Pr4.39 but the time set in Pr6.14 is given and holding brake activated.										



BRK_ON given time is determined by Pr6.14 or when motor speed goes below Pr4.39, whichever comes first.

Applications:

1. After disabling axis, if motor speed is still higher than Pr4.39 but the time set in Pr6.14 is reached, BRK_ON given and holding brake activated.

2. After disabling axis, if motor speed is already lower than Pr4.39 but the time set in Pr6.14 is not yet reached, BRK_ON given and holding brake activated.

	Label	Trial run di	stance		Mode					F
Pr6.20 F	Range	0~1200	Unit	0.1rev	Default	fault 10 Index		2620h		
	Activation	Immediate								
	JOG (Position c	ch motion								

	Label	Trial run wa	iting tim	e	Mode						F	
Pr6.21	Range	0~30000	Unit ms Default 300 Index					2621h				
	Activation	Immediate										
	JOG (Position c	ontrol) : Waiti	ng time	after ea	ch motion							

No. of trial run cycles Label Mode F 0~32767 Unit PCS Default 5 Index 2622h Range Pr6.22 Activation Immediate JOG (Position control) : No. of cycles

Pr6.25	Label	Trial run	accele	ration	Mode				F
Pr6.25	Range	0~10000	10000 Unit ms/(1000rpm)			200	Index		2625h
	Activation	Immediat	e						
	To set the accel	eration/de	celerat	tion time for JOG	command	betwee	n O rom to 1	000 rp	m

	Label	Trial run	mode		Mode			F
Pr6.26	Range	0~1	Unit	0	Default	1	Index	2626h
	Activation	Immediat	e					
	To set trial run	mode						

	Label	Blocked roto time	or alarm	delay	Mode					F
Pr6.57	Range	0~1000	Unit	ms	Default	400	Inde	x	2657h	
	Activation	Immediate								



	To set delay	time for blocked	rotor al	arm to	trigger					
	Label	Homing position	n (16-bit	t high)	Mode					F
Pr6.58	Range	-2147483647~ 2147483647	Unit	-	Default	0	Inde	x	2658h	1
	Activation	Immediate								
	Homing posi	tion 16-bit high								

	Label	Homing position low)	n (16-bit	:	Mode					F
Pr6.59	Range	-2147483647~ 2147483647	Unit	-	Default	0	Index	ĸ	2659h	
	Activation	Immediate								
Homing position 16-bit low										

	Label	Z signal hol	ding tim	е	Mode				F		
Pr6.61	Range	0~100	Unit	ms	Default	10	Index		2661h		
	Activation	Immediate									
	To set the holdin	ng time for Z	signal to	o mainta	in active high						
	Application:										
	1. Z signal for	⁻ 60FDH;									
	2. Z signal fo	r homing pro	cess								
	3. Z-phase fr	equency outp	out pulse	e width.	Unit = 0.1ms;						
	Please set Pr6.61 \geqslant 0.2ms if used for 3 applications as above										

Pr6.62	Label	Overload th	reshold		Mode			F
	Range	0~99	Unit	%	Default	Default 0		2662h
	Activation	Immediate						
	To set overload	alarm thresh	old					

	Label	Absolute m upper limit	ultiturn	data	Mode							F
Pr6.63	Range	0~32766	0~32766 Unit rev Default 0 Index									
	Activation	After restar	-t									
	To set upper lim When Pr0.15 = 2	To set upper limit of multiturn data with absolute encoder set as rotational mode. When Pr0.15 = 2, feedback position = 0 ~ (Pr6.63+1) * Encoder resolution										



3.3 402 Parameters Function

• Panel Display as follows:

classify and code

 Parameter Valid mode Description HM: Valid in homing mode PP: Valid in profile position mode PV: Valid in profile velocity mode PT: Valid in profile torque mode F: Valid in all modes

	i. valiu ili al	tinoues	,							
Index	Label	Error	code		Unit	-	Structure	VAR	Туре	Uint 16
603Fh	Access	RO	Mapping	TPDO	Mode	F	Range	0x0~0 xFFFF	Default	0X0
	Please refe	r to Cha	pter 9 for m	ore deta	ails on error	codes.				

	Label	Contro	ol word		Unit	-	Structure	VAR	Туре	Uint 16				
Index 6040h	Access	RW	Mapping	RPDO	Mode	F	Range	0x0- 0xFFF F	Default	0X0				
	Bit		Label				Descrip	otion						
	0		Start			1 - valid, 0 - invalid								
	1	М	ain circuit po	wer on			1 - valid, 0	- invalid						
	2		Quick sto	р		0 - valid,1 - invalid								
	3		Servo runr	ning		1 - valid, 0 - invalid								
	4-6	Ru	Inning mode	related		Related	l to each ser	vo runnir	ng mode					
	7		Fault res	et	Reset r valid, bi invalid	esettabl t7 rema	e fault alarm ins at 1, and	n. Rising e all other	edge of Bit instructior	7 is ns are				
	8		Pause	For mor mode, r	re inforr efer to (nation on ho Object Dictio	w to paus nary 6051	se in each Dh						
	9		No definit		Undefined									
	10		Reserved			Undefined								
	11-15		Reserved		Undefined									



User Manual of iSV2-CAN Integrated Servo

	Label	Status	word		Unit	-	Structure	VAR	Туре	Uint 16			
Index 6041h	Access	RO	Mapping	TPD0	Mode	ALL	Range	0x0~ 0xFF FF	Default	0x0			
	Bit		L	abel			Des	scription					
	0	Servo	ready				1 - valid, 0 - invalid						
	1	Start					1 - valio	d, 0 - inv	valid				
	2	Servo	running				1 - valio	d, 0 - inv	valid				
	3	Fault					1 - valid, 0 - invalid						
	4	Main c	ircuit power	on			1 - valio	d, 0 - inv	alid				
	5	Quick s	stop			0- valid, 1 - invalid							
	6	Servo	cannot run			valid							
	7	Warnir	ng			1 - valid, 0 - invalid							
	8	Reserv	ved				Re	served					
	9	Remot	e control				1 - valio	d, 0 - inv	valid				
	10	Arrive	d at position				1 - valio	d, 0 - inv	alid				
	11	Interna	al limit valid				1 - valio	d, 0 - inv	valid				
	12-13	Mode r	elated			Re	elated to each s	servo op	eration mo	ode			
	14	Reserv	ved			Reserved							
	15	Origin	found			1 - valid, 0 - invalid							

Index	Label	Quick	stop option o	code	Unit	-	Structure	VAR	Туре	INT 16
605Ah	Access	RW	Mapping	-	Mode	ALL	Range	0~7	Default	2

Motor stops when quick stop command is given.

PP, PV

- 0 : To stop motor through Pr5.06. Status: Switch on disable, axis disabled.
- 1 : Motor decelerates and stops through 6084. Status: Switch on disable, axis disabled.
- 2 : Motor decelerates and stops through 6085. Status: Switch on disable, axis disabled.
- 3 : Motor decelerates and stops through 60C6. Status: Switch on disable, axis disabled.
- 5 : Motor decelerates and stops through 6084. Status: Quick stop
- 6 : Motor decelerates and stops through 6085. Status: Quick stop
- 7 : Motor decelerates and stops through 60C6. Status: Quick stop

ΗМ

- 0 : To stop motor through Pr5.06. Status: Switch on disable, axis disabled.
- 1 : Motor decelerates and stops through 609A. Status: Switch on disable, axis disabled.
- 2 : Motor decelerates and stops through 6085. Status: Switch on disable, axis disabled.
- 3 : Motor decelerates and stops through 60C6. Status: Switch on disable, axis disabled.
- 5 : Motor decelerates and stops through 609A. Status: Quick stop
- 6 : Motor decelerates and stops through 6085. Status: Quick stop
- 7 : Motor decelerates and stops through 60C6. Status: Quick stop



Index	Label	Shutdown	option code		Mode				F
605Bh	Range	RW	Unit	-	Range	0~1	Default	0	
	PP, PV								
	0 : T	o stop motor	through Pr5.	06, 5.0	l6 = 0(Emerger	ncy stop), 5	.06=1(Free stop)		
	1 : M	lotor decelera	ates and stop	s thro	ugh 6084				
	НМ								
	0 : T	o stop motor	through Pr5.	06, 5.0	l6 = 0(Emerger	ncy stop), 5	i.06=1(Free stop)		
	1 : M	lotor deceler	ates and stop	s thro	ugh 609A				

Index	Label	Disable operat	ion optio	n code	Mode				F
605Ch	Range	RW	Unit - Range 0~1 Default					0	
	PP, PV							·	
	0 : To	stop motor thro	ough Pr5.	06, 5.06	= 0(Emerger	ncy stop), 5	.06=1(Free stop)		
	1 : Mo	otor decelerates	and stop	s throug	gh 6084				
	HM								
	0 : To	stop motor thro	ough Pr5.	06, 5.06	= 0(Emerger	ncy stop), 5	.06=1(Free stop)		
	1 : Mo	otor decelerates	and stop	s throug	gh 609A				

Index	Label	Halt o	ption code	-	Unit	-	Structure	VAR	Туре	INT 16
605Dh	Access	RW	Mapping	-	Mode	F	Range	1~3	Default	1
	When cont	rol wor	d – pause se	ets dece	lerating, sto	pping m	node. Also sui	table for	decelera	tion mode
	settings du	ring mo	de switching	9						
	PP, PV									
	1 : Mo	otor dec	elerates and	d stops t	through 608	4. Statu	s: Operation e	enabled,	axis enab	led.
	2 : M	otor dec	elerates an	d stops	through 608	5. Statu	s: Operation e	enabled,	, axis enab	oled.
	3 : M	otor deo	celerates an	d stops	through 60C	6. Statu	s: Operation e	enabled,	, axis enab	oled.
	НМ									
	1 : Mo	otor dec	elerates and	d stops t	through 609	A. Statu	s: Operation e	enabled,	axis enab	led.
	2 : M	otor deo	celerates an	d stops	through 608	5. Statu	s: Operation e	enabled,	, axis enab	oled.
	3 : M	otor dec	celerates an	d stops	through 60C	6. Statu	s: Operation e	enabled,	, axis enat	oled.



Index	Label	Mode	of Operation		Unit	-	Structure	VAR	Туре	Int 8
6060h	Access	RW Mapping RPDO			Mode	F	Range	-2~6	Default	1
		No.		Mode			Abbr.			
		1	Prof	file positi	on mode		PP			
		3	Pro	file veloci	ity mode		PV			
		4	pro	file Torqu	ie mode		PT			
		6		Homing n	node		HM			

Index	Label	Mode display	of Op	eration	Unit	I	Structure	VAR	Туре	Int 8
6061h	Access RW		Mapping	RPDO	Mode	F	Range	-2~6	Default	0
			No.		Mode	!	A	bbr.		
			1	I	Profile position	on mode	e l	PP		
			3		Profile veloci	ty mode	•	PV		
			4		profile Torqu	e mode		PT		
			6		Homing n	node		HM		
							<u>.</u>			

Index 6062h	Label	Position Demand Value			Unit	Comman d unit	Structure	VAR	Туре	Int 32
	Access	R O	Mapping	TPDO	Mode	PP/ HM	Range	- 214748364 8~2147483 647	Default	0
Reflects position command when servo driver is enabled.										

Index 6063h	Label	Position Actual Internal Value			Unit	Encoder unit	Structure	VAR	Туре	Int 32	
	Access	R O	Mapping	TPDO	Mode	F	Range	- 214748364 8~2147483 647	Default	0	
Reflects motor absolute position (Encoder unit)											


	Label	Pos Vali	ition Actual Je		Unit	Comman d unit	Structure	VAR	Туре	Int 32
lndex 6064h	Access	R O	Mapping	TPDO	Mode	F	Range	- 214748364 8~2147483 647	Default	0
	Reflects us	er's r	eal time ab	solute	positior	า				
	6064h*Gea	n*Gear ratio = 6063h								

Index 606BhAccessR 0MappingTPD0ModeALLRange- 214748364 8~2147483 647Default0		Label	Velo Valu	ocity Demar ue	nd	Unit	Comman d unit/s	Structure	VAR	Туре	Int 32
	Index 606Bh	Access	R O	Mapping	TPDO	Mode	ALL	Range	- 214748364 8~2147483 647	Default	0

To set the time between arrival to the output of INP (In position) signal.

	Label	Velo Valu	ocity Actual Je		Unit	Comman d unit/s	Structure	VAR	Туре	Int 32
Index 606Ch	Access	R 0	Mapping	TPDO	Mode	РР	Range	- 214748364 8~2147483 647	Default	0
	Reflects us	er's i	nternal con	nmand	velocity	r feedback va	alue			

	Label	Target	torque		Unit	0.1%	Structure	VAR	Туре	UInt 16	
Index 6071h	Access	RW	Mapping	RPDO	Mode	PT	Range	- 32768~3 2767	Default	0	
	To get target targue for protocol and cyclic targue mode										

To set target torque for protocol and cyclic torque mode.

Index	Label	Max To	orque		Unit	0.1%	Structure	VAR	Туре	UInt 16
6072h	Access	RW	Mapping	RPDO	Mode	F	Range	0~65535	Default	3000
	To set max.	torque	for servo dr	iver. Lin	nited by	motor max	k. torque.			

Index	Label	Max c	urrent		Unit	0.1%	Structure	VAR	Туре	UInt 16
6073h	Access	R0	Mapping	TPDO	Mode	F	Range	0~65535	Default	3000
	To set max.	nax. current for servo driver.								



	Label	Torque	e Demand		Unit	0.1%	Structure	VAR	Туре	Int 16
Index 6074h	Access	R0	Mapping	TPDO	Mode	F	Range	- 32768~3 2767	Default	0
	Internal co	mmand	torque							
	Label	Motor	Rated Curre	ent	Unit	mA	Structure	VAR	Type	Int 32
Index 6075h	Access	RO	Mapping	TPDO	Mode	F	Range	0~21474 83647	Default	3000
	Shows mot	tor rated	d current.							
Index	Label	Motor	Rated Torqu	e	Unit	mN.m	Structure	VAR	Туре	Int 32
6076h	Access	RO	Mapping	TPDO	Mode	F	Range	0~21474 83647	Default	3000
	Shows mot	tor rated	d torque.							
	Label	Torque	e Actual Valu	le	Unit	0.1%	Structure	VAR	Туре	Int 16
Index 6077h	Access	RO	Mapping	TPDO	Mode	F	Range	- 5000~50 00	Default	0
	Shows ser	vo drive	r actual torc	ue feed	back					
	Label	Curro			Unit	0.1%	Ctructure		Tuno	Int 1/
Index		Curre	nt Actual val	ue	Unit	U.1%	Structure	VAR	туре	
6078h	Access	R0	Mapping	TPD0	Mode	F	Range	5000~50 00	Default	0
	Shows ser	vo drive	r actual curi	rent feed	dback					
						1	1		[111
Index	Label	DC bu	s voltage	1	Unit	mV	Structure	VAR	Туре	32
6079h	Access	R0	Mapping	TPD0	Mode	F	Range	0~21474 83647	Default	0
	Shows DC	bus volt	age across l	P, N terr	ninals					
		r					r			Γ.

	Label	Tar	get positio	n	Unit	Command unit	Structure	VAR	Туре	Int 32
Index 607Ah	Access	R W	Mapping	TPDO	Mode	PP	Range	- 2147483647 ~214748364 7	Default	0
	To set the t	arget	position u	ınder p	rofile po	osition mode.				



	Label	Hor offs	ning po set	sition	Unit	Command unit	Structure	VAR	Туре	Int 32
Index 607Ch	Access	R W	Mapping	TPDO	Mode	НМ	Range	- 214748364 7~2147483 647	Default	0
	To set posit	tion c	offset to co	mpens	ate for t	he deviation of	mechanical (origin from m	otor origin	under
	homing									

	Label	Min.	software li	mit	Unit	Command unit	Structure	VAR	Туре	Int 32
Index 607Dh-01	Access	RW	Mapping	TPDO	Mode	НМ	Range	- 2147483647 ~214748364 7	Default	0

To set lower limit with calculated position and actual position using absolute position after homing.

	Label	Max.	software l	imit	Unit	Command unit	Structure	VAR	Туре	Int 32
Index 607Dh-02	Access	RW	Mapping	TPDO	Mode	НМ	Range	- 2147483647 ~214748364 7	Default	0
	To set up homing.	per lim	nit with cal	culated	position a	nd actual po	sition using a	absolute positio	on after	

Index	Label	Polar	ity		Unit	-	Structure	VAR	Туре	UInt 8
607Eh	Access	RW	Mapping	RPDO	Mode	НМ	Range	0x0 – 0xFF	Default	0x0

MOUE	3	Value
Position mode	PP HM	0: Rotate in the same direction as the position command 128: Rotate in the opposite direction to the position command
Velocity mode	PV	0: Rotate in the same direction as the position command64: Rotate in the opposite direction to the position command
ALL mode		0: Rotate in the same direction as the position command 224: Rotate in the opposite direction to the position command



Index 607Fh	Label	Max	« Profile Ve	locity	Unit	Command unit/s	Structure	VAR	Туре	UInt 32
	Access	R W	Mapping	RPDO	Mode	PP/HM/P V	Range	0~214 74836 47	Default	21474836 47
To set maximum allowable velocity, Limited by 6080										

To set maximum allowable velocity. Limited by 6080.

	Label Max Motor Speed				Unit	R/min	Structure	VAR	Туре	UInt 32
Index 6080h	Access	R W	Mapping	RPDO	Mode	F	Range	0~214 74836 47	Default	6000
To get the maximum allowable meter velocity										

To set the maximum allowable motor velocity.

Index	Label	Pro	file Velocity	у	Unit	Command unit/s	Structure	VAR	Туре	UInt 32
Index 6081h	Access	R W	Mapping	RPDO	Mode	PP	Range	0~214 74836 47	Default	10000
	To set targe	et vel	ocity. Limit	ed by 60'	7Fh.					

Index	Label	Pro	file acceler	ation	Unit	Command unit/s²	Structure	VAR	Туре	UInt 32
6083h	Access	R W	Mapping	RPDO	Mode	PP/PV	Range	1~2147 48364 7	Default	10000
	To set moto	or acc	celeration							

Index 6084h	Label	Pro	file deceler	ration	Unit	Command unit/s²	Structure	VAR	Туре	UInt 32
	Access	R W	Mapping	RPDO	Mode	PP/PV/H M	Range	1~2147 48364 7	Default	10000000
	To set moto	or deo	celeration							

Index 6085h	Label	Qui Dec	ck Stop eleration		Unit	Command unit/s²	Structure	VAR	Туре	UInt 32
	Access	R W	Mapping	RPDO	Mode	PP/PV	Range	1~2147 48364 7	Default	10000
To set the deceleration during an emergency stop										

	Label	Tore	que slope		Unit	%1/s	Structure	VAR	Туре	UInt 32
Index 6087h	Access	R W	R W W Mapping RPD0		Mode	РТ	Range	1~2147 48364 7	Default	5000
	To set value	es for	r tendency	torque co	ommand					



	Label	Enc	coder Incre	ements	5 Un	it Encod	er unit Structure		ructure	VAR Ty		е	Uln	it 32
Index 608Fh-01	Access	R O	Mapping	TPDC	Mo	le F		Ra	ange	1~2147 48364 7	Def	ault	0	
	To set en	coder	[.] resolutio	n										
		T					1		1					
	Label	Mot	tor Revolu	tions		Unit	r		Structu	e VAR		Туре	3	Dint 32
Index 6091h-01	Access	RW	Ma	ping	RPDO	Mode	F		Range	1- 2147 647	483	Defa t	ul	1
	To set ele	ectror	nic gear ra	tio nur	nerato	~								
	Label	Sha	aft Revolut	ions		Unit	r		Structu	re VAR		Туре	ÿ	Dint 32
Index 6091h-02	Access	RW	Мар	ping	RPDO	Mode	F		Range	1 2147 64	- 1483 47	Defa t	aul	1
	To set ele	ectror	nic gear ra	tio der	omina	tor								
Index	Label	Sha	aft Revolut	ions		Unit	Comm nd unit	ia t/r	Structu re	VAR		Туре		UInt 32
6092h-01	Access	RW	Map	ping	RPDO	Mode	F		Range	1~214 8364	74 47	Defau	lt	10000
	If 6092h-01(Feed constant) is not equal to 608Fh(Position encoder resolution), then: Electronic gear ratio = Encoder resolution / 6092h-01 If 6092h-01(Feed constant) is equal to 608Fh(Position encoder resolution), then: Electronic gear ratio = 6091-01 / 6092h-01													
	Label	Hor	nina meth	od		Unit	-	St	ructure	VAR	Tvo	е	Ulr	nt 8
Index							ł			+	1	-	<u> </u>	

Index	Label	Hommi	jinetnou						iype	Onto				
6098h	Access	RW	Mapping	RPDO	Mode	F	Range	-6- 37	Default	19				
	The table	below des	scribes the v	elocity,	direction an	d stoppiı	ng conditions o	of each h	ioming met	hods.				
	Ref no.	Descript	ion											
		Velocity	Direction	Stop										
	-6	Low	Negative	Wher	n torque rea	ched								
	-5	Low	Positive	Wher	When torque reached									
	-4	High	Negative	Inver	sed when to	rque rea	ached, after toi	rque is g	jone					
	-3	High	Positive	Inver	sed when to	rque rea	ached, after toi	rque is g	jone					
	-2	High	Negative	Inver	Inversed when torque reached, received 1 st Z-signal after torque is									
				gone										
	-1	High	Positive	Inver	Inversed when torque reached, received 1 st Z-signal after torque is									
				gone										
		Direction	n Decelera	ation po	int Hom	ne	Befo	re Z-sig	nal					
	1	Negative	Negative	e limit sv	witch Moto	or Z-sigr	nal Nega	ative lim	it switch fa	lling edge				
	2	Positive	Positive	limit sw	vitch Moto	or Z-sigr	nal Posi	tive limi	t switch fal	ling edge				
	3	Positive	Homing	switch	Moto	or Z-sigr	nal Falli	ng edge	on same s	ide of				
							hom	ing swit	ch					
	4	Positive	Homing	switch	Moto	Motor Z-signal		Rising edge on same side of		de of				
								homing switch						
	5	Negative	Homing	switch	Moto	or Z-sigr	nal Falli	ng edge	on same s	ide of				



				homing switch
6	Negative	Homing switch	Motor Z-signal	Rising edge on same side of
7	Positive	Homing switch	Motor Z-signal	Falling edge on same side of homing switch
8	Positive	Homing switch	Motor Z-signal	Rising edge on same side of homing switch
9	Positive	Homing switch	Motor Z-signal	Rising edge on same side of homing switch
10	Positive	Homing switch	Motor Z-signal	Falling edge on same side of homing switch
11	Negative	Homing switch	Motor Z-signal	Failling edge on same side of homing switch
12	Negative	Homing switch	Motor Z-signal	Rising edge on same side of homing switch
13	Negative	Homing switch	Motor Z-signal on other side of homing switch	Rising edge on other side of homing switch
14	Negative	Homing switch	Motor Z-signal on other side of homing switch	Falling edge on other side of homing switch
15		•		•
16				
17-32	Similar wit	th 1-14, but deceleration	on point = homing point	
33	Home in n	egative direction, Hom	ning point = motor Z-sign	al
34	Home in po	ositive direction, Hom	ing point = motor Z-signa	ગ
35-37	Set curren	t position as homing (point	

Index	Label	Spe Sea	ed During Irch For Sv	vitch	Unit	Command unit/s	Structure	VAR	Туре	UInt 32
Index 6099h-01	Access	R W	Mapping	RPDO	Mode	НМ	Range	0~214 74836 47	Default	10000
To set the speed used in homing										

Speed During Search For Zero Command Structure VAR Туре Label Unit unit/s Index 0~214 6099h-02 R RPDO Access Mapping Mode ΗМ Range 74836 Default W 47

To set the speed used in homing

Index	Label	Hon acc /deo	ning eleration celeration		Unit	Command unit/s²	Structure	VAR	Туре	UInt 32
609Ah	Access	R O	Mapping	TPDO	Mode	НМ	Range	1~2147 48364 7	Default	500000
	To set acceler	ation	and decel	eration	used in h	oming				

UInt 32

5000



Index	Label	Max	Acceleration	l	Unit	Comman d unit/s²	Structure	VAR	Туре	UInt 32
60C5h	Access	RW	Mapping	RPDO	Mode	F	Range	1~21474836 47	Default	1000000 00
	To set upp	per lin	nit of acceler	ation.						

Index	Label	Max	x Decelera	tion	Unit	Com unit/s	mand s²	Structure	VAR	Туре	UInt 32
60C6h	Access	R W	Mapping	RPDO	Mode F			Range	1~21474836 47	Default	1000000 00
	To set lov	lower limit of acceleration									
Index	Label	Posi	tive Torque	Limit	ι	Jnit	0.1%	Structure	VAR	Туре	UInt 16
60E0h	Access	RW	Mapping	р м	ode	F	Range	0~65535	Default	3000	
	To set the	e maximum torque of ser			rvo driv	er in p	ositive	direction			

Index	Label	Nega	tive Torque	Limit	Unit	0.1%	Structure	VAR	Туре	UInt 16
60E1h	Acces s	R W	Mapping	RPDO	Mode	F	Range	0~65535	Default	3000
	To set t	he ma	ximum torq	ue of ser	·vo drive	er in negative	e direction			
	Label	Follo Value	wing Error e	Actual	Unit	Comman d unit	Structure	VAR	Туре	Int 32
Index 60F4h	Acces s	R0	Mapping	TPDO	Mode	РР/НМ	Range	- 214748364 7~2147483 647	Default	0
	Shows	Shows position following error								

	Label	Cont	rol Effort		Unit	Comman d unit/s	Structure	VAR	Туре	Int 32
Index 60FAh	Access	RO	Mapping	TPDO	Mode	РР/НМ	Range	- 214748364 7~2147483 647	Default	0

Shows internal command velocity (Position loop output)

	Label	Posi [:] Inter	tion Demand mal Value		Unit	Encoder unit	Structure	VAR	Туре	Int 32
Index 60FCh	Access	R0	Mapping	TPDO	Mode	CSP/PP/ HM	Range	- 214748364 7~2147483 647	Default	0
	Shows ir	nterna	l command	position (of servo	driver.				



	Label	Digit	al Inputs	5		Unit	-		Structure	VAR	Туре	UINT 32
index 60FDh	Access	R0	Mappir	ng TPD	0	Mode	CS M	SP/PP/H	Range	- 214748364 8~2147483 647	Default	0
	The bits o	f 60FD)h objec	t are fur	ncti	ionally d	efir	ned as foll	ow:			
	Bit31	Bit	30	Bit29		Bit28		Bit27	Bit26	Bit25	Bit24	
	Z signal	Re	served	Reserve	ed	Reserv	ed	Probe 2	Probe 1	BRAKE	INP/V-	
											COIN	
											/TLC	
	Bit23	Bit	22	Bit21		Bit20		Bit19	Bit18	Bit17	Bit16	
	E-STOP	Re	served	Reserve	ed	Reserv	ed	Reserved	Reserved	I DI14	DI13	
	Bit15	Bit	14	Bit13		Bit12		Bit11	Bit10	Bit9	Bit8	
	DI12	DI1	1	DI10		DI9		DI8	DI7	DI6	DI5	
	Bit7	Bit	6	Bit5		Bit4		Bit3	Bit2	Bit1	Bit0	
	DI4	DI3	}	DI2		DI1		Reserved	HOME	POT	NOT	

Index	Label	Physical	Outputs		Unit	-	Structure	VAR	Туре	UInt 32
60FEh-01	Access	RW	Mapping RPD0		Mode	1ode F Range		0x0~0x7FF FFFFF	Default	0x0
	The bits of	60FEh obj	ect are fun	ctionall	y define	d as fo	llow:			
	Bit Sub-index	31~21	31~21 21 20			19	18	17	16	15~0
	01h	Reserve d	DO6 valid	D05 va	alid DO	4 valid	DO3 valid	DO2 valid	D01 valid	Reserved

Index	Label	Bit M	ask		Unit	-	Struct	ture	VA	R	Туре	UInt 32
60FEh-02	Access	RW	Mapping	RPDO	Mode	F	Range		0x0 FFI	0~0x7FFF FF	Default	0xFFFF0 000
	The bits of a 60FEh obj		-Eh object	are func	tionally d	efine	d as fol	low:				
	Bit 31~21 Sub-index		31~21	21	20		19	18		17	16	15~0
	02h	F	Reserved	DO6 enabled	DO5 enabled	e	DO4 nabled	DO3 enable	ed	DO2 enabled	DO1 enabled	Reserve d

Index	Label	Targ	et velocity		Unit	Comman d unit	Structure	VAR	Туре	Int 32
60FFh	Access	RW	Mapping	RPDO	Mode	PV	Range	- 2147483647~ 2147483647	Default	0
	Shows s	et targ	get velocity.	Limited	by 6080	h				

Index	Label	Supp	orted drive n	nodes	Unit	-	Structure	VAR	Туре	UInt 32
6502h	Access	R0	Mapping	TPDO	Mode	F	Range	0x0~0x7F FFFFFF	Default	0x0
	Shows th	e cont	rol modes s	upporte	d by the	servo drive				



Chapter 4 Control Mode

4.1 Profile Position Mode

4.1.1 Pulse

Pulse uses 6091H or 6092H parameters in object dictionary. Electronic gear ratio has a range of 1/1000 ~ 8000, if not Er A00 will appear. Error disappear after the parameter is set to be within the range but 402 state machine error status might still exist, please write 0x80 into control word (6040h) to deactivate the error status.

Method 1:

- Electronic gear changes the distance travelled by an axis through object dictionary
 608Fh(Position encoder resolution), 6091h(Gear ratio), 6092h(Feed constant) from a controller.
 Only valid under Pre-operation mode.
- 608Fh(Position Encoder Resolution) is encoder resolution, it is only readable.
- 6092h-01 is pulse counts per motor revolution, reset after disabling; 6091h-01/6091h-02 is updated on real time
- Electronic gear can be modified by changes 6092h-01:
 - If 6092h-01(Feed constant) is not equal to 608Fh(Position encoder resolution), then Electronic Gear Ratio = Encoder Resolution/6092h-01
 - If 6092h-01(Feed constant) is equal to 608Fh(Position encoder resolution), then Electronic Gear Ratio = 6091h-01/6091h-02
- Electronic gear ratio range: 0.001 ~ 8000

Method 2:

Electronic gear can also be set using Pr0.08 Pulse counts per motor revolution. Pr0.08 is valid when it is not equal to 0; if Pr0.08 = 0, object dictionary 6092h-01 becomes valid.

Note: 6091*h*-01, 6091*h*-02 and 6092*h*-01 will be updated to default (1, 1, 1000) if the set value exceeds the range of the object dictionary.

4.1.2 Motion settings

- Set 6060h = 1 for Profile Position mode.
- Set target position to 607Ah (Unit: pulse)
- Set max. velocity to 6081h (Unit: pulse/s)
- Set profile acceleration and deceleration to 6083h and 6084h (Unit: pulse/s²)
- Set pulse count per revolution to 6092h
- Set 6040h to corresponding value to machine status and start motion.

No.	Object Dictionary	Label	Set Value	Unit
1	6060h	Operation mode	1	-
2	6040h	Control word	As per need	-



3	607Ah	Target position	pulse
4	6081h	Profile velocity	pulse/s
5	6083h	Profile acceleration	pulse/s ²
6	6084h	Profile deceleration	pulse/s ²
7	6092h	Pulse count per rev	-

4.1.3 Monitoring settings

- To monitor 6041h for motion status
- To monitor 6064h for real time update of position during operation
- To monitor 606Ch for real time velocity feedback

No.	Object Dictionary	Label	Unit
1	6041h	Status word	-
2	6064h	Position feedback	Pulse
3	606Ch	Velocity feedback	Pulse/s

4.1.4 Applications example

No.	Command	Description
1	81 00 00 00 00 00 00 00	Reset all nodes. Only to reset specific node, please modify the 2 digits after 81 to node number (hexademical)
2	01 00 00 00 00 00 00 00	Activate remote control for all nodes. Only to activate specific node, please modify the 2 digits after 01 to node number (hexademical)
3	2b 40 60 00 06 00 00 00	Write Control word = 06h, machine status changes Switch On Disabled->Ready to Switch On
4	2b <mark>40 60</mark> 00 07 00 00 00	Write Control word = 07h, machine status changes Ready to Switch On-> Switched On Drive internal relay closes
5	2b <mark>40 60</mark> 00 0f 00 00 00	Write Control word = 0fh, machine status changes Switched On -> Operation Enable Motor enables
6	2f <mark>60 60</mark> 00 01 00 00 00	Write Operation Mode = 1h, position control mode
7	23 <mark>81 60</mark> 00 90 D0 03 00	Write Profile Velocity = 3D090h (1500rpm, default 10000ppr)
8	23 <mark>83 60</mark> 00 90 D0 03 00	Write Profile Acceleration = 3D090h (accelerates to 1500rpm in 1s, default 10000ppr)
9	23 7a 60 00 20 4E 00 00	Write Target Position = 4E20h (2 revs, default 10000ppr)
10	2b 40 60 00 4f 00 00 00	Write Control Word = 4Fh, relative motion mode
11	2b <mark>40 60</mark> 00 5f 00 00 00	Write Control Word = 5Fh, motor starts motion
12		Write Control word = 07h, machine status changes
	2b <mark>40 60</mark> 00 07 00 00 00	Operation Enable -> Switched On Motor disables
13	2b 40 60 00 06 00 00 00	Write Control word = 06h, machine status changes Ready to Switch On-> Switched On Drive internal relay closes

Note: Step 1 and step 2 frame ID = 0x0000, the rest = SDO address (0x0600+node no.)



4.2 Profile Velocity Mode

4.2.1 Motion Settings

- Set 6060h = 3 for Profile Velocity mode.
- Set target velocity to 60FFh (Unit: pulse/s)
- Set profile acceleration and deceleration to 6083h and 6084h (Unit: pulse/s²)
- Set 6040h to corresponding value to machine status and start motion.

No.	Object Dictionary	Label	Set Value	Unit
1	6060h	Operation mode	3	-
2	6040h	Control word		-
3	60FFh	Profile velocity		pulse/s
4	6083h	Profile acceleration	As per need	pulse/s ²
5	6084h	Profile deceleration		pulse/s ²

4.2.2 Monitoring settings

- To monitor 6041h for motion status
- To monitor 606Ch for real time velocity feedback

No.	Object Dictionary	Label	Unit
1	6041h	Status word	-
2	606Ch	Velocity feedback	Pulse/s

Applications example

No.	Command	Description		
1	81 00 00 00 00 00 00	Reset all nodes. Only to reset specific node, please modify the		
	81 88 88 88 88 88 88	2 digits after 81 to node number (hexademical)		
2		Activate remote control for all nodes. Only to activate specific		
	01 00 00 00 00 00 00 00	node, please modify the 2 digits after 01 to node number		
		(hexademical)		
3		Write Control word = 06h, machine status changes		
	20 40 60 00 06 00 00 00	Switch On Disabled->Ready to Switch On		
4		Write Control word = 07h, machine status changes		
	2b <mark>40 60</mark> 00 07 00 00 00	Ready to Switch On-> Switched On		
		Drive internal relay closes		
5		Write Control word = 0fh, machine status changes		
	2b <mark>40 60</mark> 00 0f 00 00 00	Switched On -> Operation Enable		
		Motor enables		
6	2f <mark>60 60</mark> 00 03 00 00 00	Write Operation Mode = 3h, position control mode		
7		Write Profile Acceleration = 3D090h (accelerates to 1500rpm		
	23 83 88 88 98 98 98 83 88	in 1s, default 10000ppr)		
8	23 <mark>ff 60</mark> 00 90 D0 03 00	Write Profile Velocity = 3D090h (1500rpm, default 10000ppr)		
9		Write Control word = 07h, machine status changes		
	2b <mark>40 60</mark> 00 07 00 00 00	Operation Enable -> Switched On		
		Motor disables		
10		Write Control word = 06h, machine status changes		
	2b <mark>40 60</mark> 00 06 00 00 00	Ready to Switch On-> Switched On		
		Drive internal relay closes		

Note: Step 1 and step 2 frame ID = 0x0000, the rest = SDO address (0x0600+node no.)

Leadshine

4.3 Profile Torque Mode

4.3.1 Motion Settings

- Set 6060h = 4 for Profile Torque mode.
- Set torque limit to 6071h (Unit: 0.1%)
- Set profile torque change rate to 6087h (Unit: 0.1%/s)
- Set velocity limit to 6080h (Unit: rpm)
- Set 6040h to corresponding value to machine status and start motion.

No.	Object Dictionary	Label	Set Value	Unit
1	6060h	Operation mode	4	-
2	6040h	Control word		-
3	6071h	Torque limit	Ac par paod	0.1% of rated torque
4	6087h	Torque change rate	As per need	0.1% of rated torque/s
5	6080h	Max velocity		rpm

4.3.2 Monitoring settings

• To monitor 6041h for motion status

No.	Object Dictionary	Label	Unit
1	6041h	Status word	-
2	606Ch	Velocity feedback	Pulse/s

Applications example

No.	Command	Description
1	81 00 00 00 00 00 00	Reset all nodes. Only to reset specific node, please modify the
	81 88 88 88 88 88 88	2 digits after 81 to node number (hexademical)
2		Activate remote control for all nodes. Only to activate specific
	01 <mark>00</mark> 00 00 00 00 00 00	node, please modify the 2 digits after 01 to node number
		(hexademical)
3	2h 10 60 00 06 00 00 00	Write Control word = 06h, machine status changes
	20 40 00 00 00 00 00	Switch On Disabled->Ready to Switch On
4		Write Control word = 07h, machine status changes
	2b <mark>40 60</mark> 00 07 00 00 00	Ready to Switch On-> Switched On
		Drive internal relay closes
5		Write Control word = 0fh, machine status changes
	2b <mark>40 60</mark> 00 0f 00 00 00	Switched On -> Operation Enable
		Motor enables
6	2f <mark>60 60</mark> 00 04 00 00 00	Write Operation Mode = 4h, torque control mode
7	22 87 60 00 14 00 00 00	Write torque change rate = 14h (torque increase to rated
	25 87 00 00 14 00 00 00	torque 20Nm*0.1% =2Nm in 1s)
8	23 <mark>80 60</mark> 00 e8 03 00 00	Write Max Velocity = 3E8h (1000rpm)
9	2B 71 60 00 64 00 00 00	Write torque value = 64h (100*0.1% = 10% of rated torque)
10		Write Control word = 07h, machine status changes
	2b <mark>40 60</mark> 00 07 00 00 00	Operation Enable -> Switched On
		Motor disables



11	2b <mark>40 60</mark> 00 06 00 00 00	Write Control word = 06h, machine status changes Ready to Switch On-> Switched On
		Drive internal relay closes

Note: Step 1 and step 2 frame ID = 0x0000, the rest = SDO address (0x0600+node no.)

4.4 Homing mode

4.4.1 Motion Settings

- Set 6060h = 6 for Homing mode.
- Set required homing mode code to 6098h. Please refer to 6.4.4 for descriptions on each homing mode.
- Set homing high velocity and homing low velocity to 6099h(0x1) and 6099h(0x2) respectively (Unit: pulse/s)
- Set profile acceleration/deceleration 609Ah as homing acceleration/deceleration (Unit: pulse/s²)
- Set 6040h to corresponding value to machine status and start motion.

No.	Object Dictionary	Label	Set Value	Unit
1	6060h	Operation mode	6	-
2	6040h	Control word		-
3	6098h	Homing mode		-
4	6099h	Homing velocity	As per need	pulse/s
5	609Ah	Homing acceleration/ deceleration		pulse/s ²

4.4.2 Monitoring settings

• To monitor 6041h for motion status

No.	Object Dictionary	Label	Unit
1	6041h	Status word	-
2	606Ch	Velocity feedback	Pulse/s

Application example

No.	Command	Description
1	81 00 00 00 00 00 00	Reset all nodes. Only to reset specific node, please modify the 2
	81 00 00 00 00 00 00	digits after 81 to node number (hexademical)
2		Activate remote control for all nodes. Only to activate specific
	01 <mark>00</mark> 00 00 00 00 00 00	node, please modify the 2 digits after 01 to node number
		(hexademical)
3	2h 10 60 00 06 00 00 00	Write Control word = 06h, machine status changes
	20 40 00 00 00 00 00 00	Switch On Disabled->Ready to Switch On
4		Write Control word = 07h, machine status changes
	2b <mark>40 60</mark> 00 07 00 00 00	Ready to Switch On-> Switched On
		Drive internal relay closes
5		Write Control word = 0fh, machine status changes
	2b <mark>40 60</mark> 00 0f 00 00 00	Switched On -> Operation Enable
		Motor enables



6	2f <mark>60 60</mark> 00 06 00 00 00	Write Operation Mode = 6h, homing mode
7	23 <mark>99 60</mark> 01 30 75 00 00	Write homing high velocity = 7530h (180rpm, default 10000ppr)
8	23 <mark>99 60</mark> 02 20 4e 00 00	Write homing low velocity = 4e20h (120rpm, default 10000ppr)
9		Write homing acceleration = 7530h (Accelerates to 180rpm in
	25 9a 00 00 30 73 00 00	1s, default 10000ppr)
10	2f <mark>98 60</mark> 00 16 00 00 00	Write homing mode = 16h (Homing mode 22)
11	2h 10 60 00 1f 00 00 00	Write Control Word = 1f, set 4 th digit of 6040h to 1, enable
	20 40 60 60 11 60 60 60	homing
12	2h 10 60 00 0f 00 00 00	Write Control Word = 0f, set 4 th digit of 6040h to 0, enable
	20 40 00 00 01 00 00 00	homing on rising edge.
13	2h 40 60 00 1f 00 00 00	Write Control Word = 1f, set 4 th digit of 6040h to 1, starts
	20 40 00 00 11 00 00 00	homing
14		Write Control word = 07h, machine status changes
	2b <mark>40 60</mark> 00 07 00 00 00	Operation Enable -> Switched On
		Motor disables
15		Write Control word = 06h, machine status changes
	2b <mark>40 60</mark> 00 06 00 00 00	Ready to Switch On-> Switched On
		Drive internal relay closes

Note: Step 1 and step 2 frame ID = 0x0000, the rest = SDO address (0x0600+node no.)

4.4.3 Homing mode

Torque limiting mode

Mode-6: Search for homing point in **negative direction** at **low velocity**. Stop after torque reaches the value set in Pr5.39 and homing done signal delivers after the time value set in Pr5.37



Mode -5: Search for homing point in **positive direction** at **low velocity**. Stop after torque reaches the value set in Pr5.39 and homing done signal delivers after the time value set in Pr5.37





Mode -4: Search for homing point in **negative direction** at **high velocity**. Move in **positive direction** after torque reaches the value set in Pr5.39, stops when torque is gone. Homing done signal delivers after the time value set in Pr5.37



Mode -3: Search for homing point in **positive direction** at **high velocity**. Move in **negative direction** after torque reaches the value set in Pr5.39, stops when torque is gone. Homing done signal delivers after the time value set in Pr5.37





Mode -2: Search for homing point in **negative direction** at **low velocity**. Move in **positive direction** after torque reaches the value set in Pr5.39, stops when torque is gone with the first **Z-signal**.



Mode -1: Search for homing point in **positive direction** at **low velocity**. Move in **negative direction** after torque reaches the value set in Pr5.39, stops when torque is gone with the first Z-signal.





Mode 1:

Diagram A: *Negative limit switch = OFF*

1. Move in **negative direction** at **high velocity** until **negative limit switch valid.**

2. Move in **positive direction** at **low velocity** and stops **after negative limit switch** and **first encoder Z-signal valid**

Diagram B: *Negative limit switch = ON*

1. Start to move at **negative limit switch position** in **positive direction** at **high velocity** until **negative limit switch invalid.**

2. Move in negative direction at high velocity until negative limit switch valid.

3. Move in **positive direction** at **low velocity** and stops **after negative limit switch** and **first encoder Z-signal valid**





Mode 2:

Diagram A: *Positive limit switch = OFF*

1. Move in **positive direction** at **high velocity** until **positive limit switch valid**.

2. Move in **negative direction** at **low velocity** and stops **after positive limit switch** and **first encoder Z-signal valid**

Diagram B: *Positive limit switch = ON*

1. Start to move at **positive limit switch position** in **negative direction** at **high velocity** until **positive limit switch invalid.**

2. Move in **positive direction** at **high velocity** until **positive limit switch valid**.

3. Move in **negative direction** at **low velocity** and stops **after positive limit switch** and **first encoder Z-signal valid**





Mode 3:

Diagram A: *Homing switch = OFF*

1. Move in **positive direction** at **high velocity** until **homing switch valid**.

2. Move in **negative direction** at **low velocity** and stops **after homing switch** and **first encoder Zsignal valid**

Diagram B: *Homing switch = ON*

1. Start to move at **homing switch position** in **negative direction** at **high velocity** until **after homing switch**.

2. Move in **positive direction** at **high velocity** until **homing switch valid**.

3. Move in **negative direction** at **low velocity** and stops **after homing switch** and **first encoder Zsignal valid**





Mode 4:

Diagram A: *Homing switch = OFF*1. Move in **positive direction** at **high velocity** until **homing switch valid**.
2. Move in **negative direction** at **high velocity** until **homing switch invalid**.
3. Move in **positive direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**

Diagram B: *Homing switch = ON*

1. Start to move at **homing switch position** in **negative direction** at **high velocity** until **after homing switch**.

2. Move in **positive direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**





Mode 5:

Diagram A: *Homing switch = OFF*

1. Move in negative direction at high velocity until homing switch valid.

2. Move in **positive direction** at **low velocity** and stops **after homing switch** and **first encoder Z-signal valid**

Diagram B: *Homing switch = ON*

1. Start to move at **homing switch position** in **positive direction** at **high velocity** until **after homing switch**.

2. Move in **negative direction** at **high velocity** until **homing switch valid**.

3. Move in **positive direction** at **low velocity** and stops **after homing switch** and **first encoder Zsignal valid**





Mode 6:

Diagram A: *Homing switch = OFF*1. Move in negative direction at high velocity until homing switch valid.
2. Move in positive direction at high velocity until homing switch invalid.
3. Move in negative direction at low velocity and stops after homing switch valid and first

encoder Z-signal valid

Diagram B: *Homing switch = ON*

1. Start to move at **homing switch position** in **positive direction** at **high velocity** until **after homing switch**.

2. Move in **negative direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**





Diagram A: Homing switch & positive limit switch = OFF

1. Move in **positive direction** at **high velocity** until **homing switch valid**.

2. Move in **negative direction** at **low velocity** and stops after **homing switch** and **first encoder Z-signal valid.**

Diagram B: *Homing switch = ON, positive limit switch = OFF*

1. Start to move at **homing switch position** in **negative direction** at **high velocity** until **after homing switch**.

2. Move in positive direction at high velocity until homing switch valid.

3. Move in **negative direction** at **low velocity** and stops **after homing switch** and **first encoder Zsignal valid**

Diagram C: *Homing switch & positive limit switch = OFF*

1. Move in **positive direction** at **high velocity** until **positive limit switch valid**.

2. Move in negative direction at high velocity until after homing switch.

3. Move in positive direction at high velocity until homing switch valid.

4. Move in **negative direction** at **low velocity** and stops **after homing switch** and **first encoder Z signal valid**





Diagram A: Homing switch & positive limit switch = OFF

1. Move in **positive direction** at **high velocity** until **homing switch valid**.

2. Move in negative direction at high velocity until after homing switch.

3. Move in **positive direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**.

Diagram B: *Homing switch = ON, positive limit switch = OFF*

1. Start to move at **homing switch position** in **negative direction** at **high velocity** until **after homing switch**.

2. Move in **positive direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**

Diagram C: *Homing switch & positive limit switch = OFF*

1. Move in **positive direction** at **high velocity** until **positive limit switch valid**.

2. Move in negative direction at high velocity until after homing switch.

3. Move in **positive direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**.





Diagram A: *Homing switch & positive limit switch = OFF*

1. Move in **positive direction** at **high velocity** until **after homing switch**.

2. Move in **negative direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**.

Diagram B: Homing switch = ON, positive limit switch = OFF

1. Start to move at **homing switch position** in **positive direction** at **high velocity** until **homing switch invalid**.

2. Move in **negative direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**

Diagram C: *Homing switch & positive limit switch = OFF*

1. Move in **positive direction** at **high velocity** until **positive limit switch valid**.

2. Move in negative direction at high velocity until homing switch valid.

3. Move in **positive direction** at **high velocity** until **after homing switch**.

4. Move in **negative direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z signal valid**





Diagram A: *Homing switch & positive limit switch = OFF*

1. Move in **positive direction** at **high velocity** until **after homing switch**.

2. Move in negative direction at high velocity until homing switch valid.

3. Move in **positive direction** at **low velocity** and stops **after homing switch** and **first encoder Z-signal valid.**

Diagram B: *Homing switch = ON, positive limit switch = OFF*

1. Start to move at **homing switch position** in **positive direction** at **high velocity** until **after homing switch**.

2. Move in negative direction at high velocity until homing switch valid.

3. Move in **positive direction** at **low velocity** and stops **after homing switch** and **first encoder Zsignal valid**

Diagram C: *Homing switch & positive limit switch = OFF*

1. Move in **positive direction** at **high velocity** until positive **limit switch valid**.

2. Move in negative direction at high velocity until homing switch valid.

3. Move in **positive direction** at **low velocity** and stops **after homing switch** and **first encoder Z signal valid**





Diagram A: *Homing switch & negative limit switch = OFF*

1. Move in negative direction at high velocity until homing switch valid.

2. Move in **positive direction** at **low velocity** and stops **after homing switch** and **first encoder Z-signal valid**

Diagram B: *Homing switch = ON, negative limit switch = OFF*

1. Start to move at **homing switch position** in **positive direction** at **high velocity** until **after homing switch**.

2. Move in negative direction at high velocity until homing switch valid.

3. Move in **positive direction** at **low velocity** and stops **after homing switch** and **first encoder Z-signal valid**

Diagram C: *Homing switch & negative limit switch = OFF*

1. Move in negative direction at high velocity until the negative limit switch valid.

2. Move in positive direction at high velocity until homing switch invalid.

3. Move in negative direction at high velocity until homing switch valid.

4. Move in **positive direction** at **low velocity** and stops **after homing switch** and **first encoder Z signal valid**





Diagram A: *Homing switch & negative limit switch = OFF*

1. Move in negative direction at high velocity until homing switch valid.

2. Move in positive direction at high velocity until after homing switch.

3. Move in **negative direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**

Diagram B: *Homing switch = ON, negative limit switch = OFF*

1. Move at **homing switch position** in **negative direction** at **high velocity** until **after homing switch**.

2. Move in **positive direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**.

Diagram C: *Homing switch & negative limit switch = OFF*

1. Move in negative direction at high velocity until negative limit switch valid.

2. Move in positive direction at high velocity until after homing switch.

3. Move in **negative direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**.





Diagram A: *Homing switch & negative limit switch = OFF*

1. Move in negative direction at high velocity until after homing switch.

2. Move in **positive direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**.

Diagram B: *Homing switch = ON, negative limit switch = OFF*

1. Start to move at **homing switch position** in **negative direction** at **high velocity** until **after homing switch**.

2. Move in positive **direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**.

Diagram C: *Homing switch & negative limit switch = OFF*

1. Move in negative direction at high velocity until negative limit switch valid.

2. Move in **positive direction** at **high velocity** until **homing switch valid**.

3. Move in negative direction at high velocity until after homing switch.

4. Move in **positive direction** at **low velocity** and stops after **homing switch valid** and **first encoder Z-signal valid**.





Diagram A: *Homing switch & negative limit switch = OFF*

1. Move in negative direction at high velocity until after homing switch.

2. Move in positive direction at high velocity until homing switch valid.

3. Move in **negative direction** at **low velocity** and stops **after homing switch** and **first encoder Zsignal valid.**

Diagram B: *Homing switch = ON, negative limit switch = OFF*

1. Start to move at **homing switch position** in **negative direction** at **high velocity** until **homing switch invalid**.

2. Move in positive direction until homing switch valid.

3. Move in **negative direction** at **low velocity** and stops **after homing switch** and **first encoder Z signal valid.**

Diagram C: *Homing switch & negative limit switch = OFF*

1. Move in negative direction at high velocity until negative limit switch valid.

2. Move in positive direction at high velocity until homing switch valid.

3. Move in **negative direction** at **low velocity** and stops **after homing switch** and **first encoder Zsignal valid.**





Mode 17:

This mode is similar to mode 1. Only difference is that homing point detection is not through Z-signal but through triggering of negative limit switch signal



Mode 18:

This mode is similar to mode 2. Only difference is that homing point detection is not through Z-signal but through switching of positive limit switch signal





Mode 19:

This mode is similar to mode 3. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal



Mode 20:

This mode is similar to mode 4. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal





Mode 21:

This mode is similar to mode 5. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal.



Mode 22:

This mode is similar to mode 6. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal.





Mode 23:

This mode is similar to mode 7. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal.



Mode 24:

This mode is similar to mode 8. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal.





Mode 25:

This mode is similar to mode 9. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal



Mode 26:

This mode is similar to mode 10. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal





Mode 27:

This mode is similar to mode 11. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal



Mode 28:

This mode is similar to mode 12. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal




Mode 29:

This mode is similar to mode 13. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal



Mode 30:

This mode is similar to mode 14. Only difference is that homing point detection is not through Z-signal but through triggering of homing switch signal





Mode 33:

The motor starts to move in **negative direction** and stops when the **Z-signal is valid**. *If the positive/negative limit switch signal or homing switch is valid during the homing process, the status word (6041h) bit 13 will be valid, indicating homing error and the motor will stop immediately.*



Mode 34:

The motor starts to move in **positive direction** and stops when the **Z-signal is valid**. *If the positive/negative limit switch signal or homing switch is valid during the homing process, the status word (6041h) bit 13 will be valid, indicating homing error and the motor will stop immediately.*



Mode 35/37:

Set the current position as homing point. Using this mode, motor doesn't have to be enabled. Set control word 6040h bit 4 from 0 to 1.





4.5 Emergency Stop

4.5.1 Motion Settings

- Set 6060h = 3 for Profile Velocity mode.
- Set 6040h to corresponding value to machine status and start motion.

No.	Object Dictionary	Label	Set Value	Unit
1	6085h	Emergency stop deceleration	-	pulse/s ²
2	6040h	Control word	As per need	-

4.5.2 Monitoring settings

• To monitor 6041h for motion status

No.	Object Dictionary	Label	Unit
1	6041h	Status word	-



Chapter 5 Applications

5.1 Trial Run



Trial Run

To test run servo products after successfully connected to Motion Studio and initial setup is done. Main power supply and motor/encoder cable need to be connected to use this function.

Trial run X
Position
Setting 1
Pr6.04 Jog Speed 300 rpm << Expand
Pr6.25 Acceleration of trial running 150 ms/1000rpm
Pr0.04 Inertia ratio 250
Press enter to modify parameters 2
Serve EnableImage: Contract of the co



5.2 Inertia Ratio measuring

Inertia measuring using Motion Studio

- 1. Start Motion Studio and maneuver to inertia ratio identification page under performance tuning. Set trial run velocity Pr6.04 and acc-/deceleration time Pr6.25, click on 'Upload' to upload parameters to servo driver.
- 2. Tick "Prohibit external enabling" and click on "servo on".
- 3. Click and hold "CCW" to start the motor. Current position will show motor cycles of revolution. Click on POS 1 to save current position as starting point. Click and hold "CW" to start the motor again. Click on POS 2 to save current position as ending point.
- 4. Set the waiting time between each cycle in Pr6.21 and no. of cycles in Pr6.22. Click on 'Run' and motor will run according to the parameters set.



5. After the calculation is done, inertia ratio will be calculated automatically and click on 'write' to enter the calculated value into Pr0.04.



6. Click on "Parameter List" to enter parameters management to check or modify Pr0.04. Then, click on "Save" to save parameters to driver.

Parameter List	O Scope Trial	Pr-Motion Functio	Self Mechanical State Error Adjusting Analysis Monitor Alarm	Tools Assistance								
4 Parame	Parameter List x											
🎻 🁌 Open Sa	Open Save As Upload Save Compare Restore											
All Parame	eters	Number	Label	AxisA	Min	Max	Defa	Unit	Enable Mode	Remarks		
Pr0.Basic S	Settings	PA0.00	Model-following bandwi	1	0	5000	1	0.1Hz	Immediately	Null		
Pr1.Gdin A	tion Suppres	PA0.02	Real time Auto Gain Adj	0x1	0x0	0xFFF	0x1		Immediately	Null		
Pr3.Velocit	ity/Torque C	PA0.03	Real time auto stiffness	70	50	81	70		Immediately	Null		
Pr4.I/O Mo	onitoring Se	PA0.04	Inertia ratio	250	0	20000	250	%	Immediately	Null		
Pr5.Extend	ded Settings	PA0.06	Command polarity inver	0	0	1	0		Poweroff Res	Null		
Pro.Specia	al Settings	PA0.07	Probe signal polarity set	3	0	3	3		Poweroff Res	Null		
FI7.1 actor	y Settings	PA0.08	Command pulse counts	0	0	67108	0		Poweroff Res	Null		
		PA0.09	1st command frequency	1	1	21474	1		Poweroff Res	Null		
		PA0.10	Command frequency m	1	1	21474	1		Poweroff Res	Null		
		PA0.11	Encoder pulse output pe	2500	1	32767	2500	P/rev	Poweroff Res	Null		
		PA0.12	Pulse output logic invers	0	0	1	0		Poweroff Res	Null		
		PA0.13	1st Torque Limit	350	0	500	350	%	Immediately	Null		
		PA0.14	Excessive Position Devia	30	0	310	30	0.1rev	Immediately	Encoder unit		
		PA0.15	Absolute Encoder settings	0	0	32767	0		Poweroff Res	Null		
		PA0.16	Regenerative resistance	100	25	500	100	Ohm	Immediately	Null		
		PA0.17	Regenerative resistor po	50	20	5000	50	W	Immediately	Null		
		PA0.19	Friction compensation s	0	0	1000	0		Immediately	Null		
			Read only			Not saved	D	ifferent fro	m default			

Please take note:

- 1. Trial run velocity and distance should be optimal to prevent any axis from bumping into objects.
- 2. It is recommended to move only in 1 direction for vertically mounted axis. Take precaution before moving the axis.
- 3. For applications with higher frictional drag, please set a minimal travel distance.

	Label	Inertia ratio	Mode									
Pr0.04	Range	lange 0~20000 Unit %		250	Index	2004h						
	Activation	Immediate										
	Pr0.04=(load inertia/motor rotational inertia)×100%											
	Notice:											

Set inertia ratio according to actual load inertia. When both are uniform, actual motor velocity loop responsiveness and gain settings will be consistent. If inertia ratio is greater than actual value, velocity loop gain settings will be higher and vice versa.

Common issues

Error	Cause	Solution
	Loose load connection	Check for mechanical failure
Inortia moscuring	Measuring distance is too short	Increase measuring distance
failure	Belt load	Please pre-set an inertia ratio when using a belt to prevent jolt due to low inertia.



5.3 Notch Filter (Vibration Suppression)

To use notch filter

Automatic notch filter

- 1. Set Pr2.00 = 1 for auto notch filter adjustment
- If Pr0.03 stiffness increases, 3rd group of notch filter (Pr2.07/Pr2.08/Pr2.09) updates automatically when driver is enabled. Pr2.00 = 0, auto adjustments stop. If resonance is suppressed, it means self-adjusting notch filter is working. If resonance occurs when mechanical stiffness increases, please use manual notch filter, set filter frequency to actual resonant frequency.

Manual notch filter

There are 2 ways to use manual notch filter.

1. After enabling self-adjusting notch filter, set the values from 3^{rd} group of filters to 1^{st} group of notch filter (Pr2.01/Pr2.02/Pr2.03), see if resonance is suppressed. If there is other resonance, set Pr2.00 = 1, then set the values from 3^{rd} group of filters to 2^{nd} group of notch filter (Pr2.04/Pr2.05/Pr2.06)

Get resonant frequency, notch filter bandwidth and depth and set it into the corresponding parameters through Motion Studio

	Label	Adaptiv settings	Adaptive filtering mode settings									F		
Pr2.00	Range	0~4	Unit	-	Default	0		Index	,		2200h			
	Activation	Immedi	ate											
	Set value		Explanation											
	0	Adaptive f	ilter: inva	alid	Parameters related to 3 rd and 4 th notch filter remain unchanged									
	1	Adaptive f valid for o	daptive filter: 1 filter alid for once. 1 adaptive filter becomes valid. 3 rd no filter related parameters updated accordingly. Pr2.00 switches automated											
	2	Adaptive f remains v	daptive filter: 1 filter 1 adaptive filter becomes valid. 3 rd notch emains valid filter related parameters will keep updating accordingly.											
	3-4	Reserved -												

	Label	1 st notch fr	equenc	у	Mode								
Pr2.01	Range	50~4000	Unit	Hz	Default	4000 Index 22							
	Activation	Immediate	Immediate										
	Set center frequ Set Pr2.01 to 400	ency of 1 st to 10 to deactiv	cy of 1 st torque command notch filter. to deactivate notch filter										



	Label	1 st notc selecti	h bandwi on	idth	Mode			F						
Pr2.02	Range	0~20	Unit	-	Default	4	Index	2202h						
	Activation	Immed	Immediate											
	Set notch bandy Under normal c control, in comb loop responsive	width for ircumsta pination w eness whi	1 st resona nces, ple vith Pr2.0 ch allow	ant notch ase use 11 and Pr <u>s higher</u>	n filter. factory defau 2.03, Pr2.02 d mechanical	ult setting can be re stiffness	gs. If resonanc duced to impr settings.	e is under ove current						
	l abel	1 st notch	donth co	lection	Mode									
Pr2.03	Range	0~99 Unit -		Default	0	Index	2203h							

Activation Immediate Set notch depth for 1st resonant notch filter. Under normal circumstances, please use factory default settings. If resonance is under control, in combination with Pr2.01 and Pr2.02, Pr2.03 can be reduced to improve current loop responsiveness which allows higher mechanical stiffness settings. Label 2nd notch frequency Mode F 50~4000 Unit Hz Default 4000 2204h Index Range Pr2.04 Activation Immediate

Set center frequency of 2nd torque command notch filter. Set Pr2.04 to 4000 to deactivate notch filter

	Label	2 nd notch selection	n bandwi n	dth	Mode							F	
Pr2.05	Range	0~20	Unit	-	Default	4	Index				2205h		
	Activation	Immediate											
	Set notch bandwidth for 2 nd resonant notch filter. Under normal circumstances, please use factory default settings. If resonance is under control, in combination with Pr2.04 and Pr2.06, Pr2.05 can be reduced to improve current loop responsiveness which allows higher mechanical stiffness settings												

	Label	2 nd notcl selectio	n depth n		Mode						F	
Pr2.06	Range	0~99 Unit		-	Default	0		Index			2206h	
	Activation	Immedia	ate									
	Set notch depth When Pr2.06 va normal circums combination wi responsiveness	n for 1 st reg Ilue is hig Stances, p th Pr2.04 S which al	sonant no her, notc lease us and Pr2. lows hig	otch filte h depth e factory 05, Pr2.0 her mec	r. becomes shal v default settin 6 can be redu hanical stiffne	low, pl Igs. If I ced to ss set	hase resoi impi tings	lag re nance rove c 5.	educes. is unde urrent	Un er c loo	ider :ontrol, in p	



	Label	3 rd notch	frequen	су	Mode							F
Pr2.07	Range	50~400 0	Unit	Hz	Default	4000 In		Index	Index		2207h	
	Activation	Immediate										
	Set center frequency of 3 rd torque command notch filter. Set Pr2.07 to 4000 to deactivate notch filter											

	Label	3 rd notch b selection	andwidt	h	Mode				F			
Pr2.08	Range	0~20	Unit	-	Default	4	Index		2287h			
	Activation	Immediat	Immediate									
	Set notch bandwidth for 3 rd resonant notch filter. Under normal circumstances, please use factory default settings.											

Pr2.09	Label	Label 3 rd notch depth selection			Mode							F
	Range	0~99	Unit	-	Default	0		Index			2206h	I
	Activation	Immedia	Immediate									
	Set notch depth for 1 st resonant notch filter. When Pr2.09 value is higher, notch depth becomes shallow, phase lag reduces.											

5.4 Auto gain adjustment

This function will measure real time mechanical properties and set gain values in accordance to mechanical stiffness. Can be used in any control mode

Conditions to implement							
Control mode	Please refer to Pr0.02 for detailed explanations. Auto gain adjustment is						
Control mode	different for each control mode.						
	 Servo driver needs to be enabled 						
	\cdot Set up input signals such as deviation counter clearing and command						
Other	input; Torque limit and other motion control parameters to enable motor to move normally without obstacles.						

Under certain conditions, external factors might affect automatic gain adjustment functions. If the conditions as listed exist or unfavorable, please disable the automatic gain adjustment function.

	Affecting conditions						
Lood in artia	 If inertia is less than 3 times or over 20 times of rotor inertia. 						
Load menta	Changes in load inertia						
Lood	 Very low mechanical stiffness 						
Load	 If gear backlash is a non-linear property 						
Motion	 Velocity less than 100r/min or continuously in low velocity mode 						



- Acc-/deceleration to 2000r/min within 1s. 。
- · Acc-/deceleration torque lower than eccentric load, frictional torque.
- \cdot Velocity < 100r/min, acc-/deceleration to 2000r/min within 1s but not longer than 50ms

To enable automatic gain adjustment:

- 1. Disable the servo driver.
- 2. Set Pr0.02 = 0x01/0x11 or 0x02/0x12. Then, set Pr0.03
- 3. Servo enabled. Run motion as normal to start measuring load properties. Related

parameters will be automatically set.

4. Increase motor responsiveness by increasing Pr0.03. Please check if there is any vibration before setting Pr0.03 to max. value.

5. Save the parameters.

Please take note:

- Please stop the motor before modifying any parameter. Pr0.02 only takes effect after saving modified parameter values into EEPROM and restarting the driver.

- After enabling the servo driver for the first time or when increasing Pr0.03, mechanical noise or vibration might occur for the first run, it is normal. If it persists, please set Pr0.03 to lower value.

Parameters that change in accordance to real time gain adjustment

There are 2 types of auto gain adjustment methods:

• **Standard mode** (Pr0.02 = 1): Basic mode, prioritizing on stability, gain switching is disabled. Actual gain auto adjustment as accordance to Pr0.03.

Gain related parameters that change as shown below.

Parameter	Label	Remarks
Pr1.00	1 st position loop gain	
Pr1.01	1 st velocity loop gain	When stiffness setting is valid
Pr1.02	1 st velocity integral time	when stimess setting is value,
	constant	match stiffnoss value
Pr1.03	1 st velocity detection filter	
Pr1.04	1 st torque filter	

Gain related that doesn't change

Parameter	Label	Reference value	Remarks
Pr1.10	Velocity feedforward	300 (0.1%)	Doesn't change
	gain constant		according to changes in
			stiffness

Positioning mode (Pr0.02 = 2): Prioritizing positioning. Usually applies on horizontal axis without variable load, ball screws with lower friction, gain switching enabled. Stiffness level of 2nd position loop gain is 1 level higher than 1st position.

No.	Parameters	Label	Remarks
1	Pr1.00	1 st position loop gain	When stiffness setting is valid
2	Pr1.01	1 st velocity loop gain	parameters will be undated to match
3	Pr1.02	1 st velocity integral time constant	stiffness value



4	Pr1.03	1 st velocity detection filter
5	Pr1.04	1 st torque filter
6	Pr1.05	2 nd position loop gain
7	Pr1.06	2 nd velocity loop gain
8	Pr1.07	2 nd velocity integral time
		constant
9	Pr1.08	2 nd velocity detection filter
10	Pr1.09	2 nd torque filter

If auto gain adjustment is valid, the parameters listed above can't be manually modified. Only when
Pr0.02 = 0, can the gain related parameters be modified manually.

5.5 3rd gain switching

Besides switching between 1st and 2nd gain, a 3rd gain switching is added to set gain at the moment of stopping to reduce positioning time.

Only available under position mode and Pr6.05 \neq 0, set Pr6.06 for 3rd gain value. When 2nd gain switches to 1st gain, it has to go through 3rd gain, switching time is set in Pr1.19.

Diagram below shows when Pr1.15 = 7.



Velocity loop integral time constant, velocity detection filter, torque filter time

constant will still be applied in 1st gain

	Label	Position 3 rd g	gain vali	id time	Mode	PP		HM				
Pr6.05	Range	0~10000	Unit	0.1ms	Default	0	Inde	Index			2605h	
	Activation	Immediate										
	To set time for When not in us	r 3 rd gain to be se, set Pr6.05	3 rd gain to be valid e, set Pr6.05=0, Pr6.06=100									
	Label	Position 3 rd gain scale factor			Mode	PP		НМ				
Pr6.06	Range	0~1000 Unit 100%			Default	100	Inde	x		2606h		
	Activation	Immediate										







5.6 Friction compensation function

This function is to compensation for changes in load to reduce the effect of friction in motion. The compensation value is directional.



Vertically loaded axis: A constant eccentric load torque is applied on the motor. By adjusting Pr6.07, positioning deviation due to different motional direction can be reduced.

Belt-driven axis: Due to large radial load with dynamic frictional torque. Positioning time delay and deviation can be reduced by adjusting Pr6.08 and Pr6.09.

	Label	Torque comm	and addi	tional	Mode				F				
Pr6.07	Range	-100~100	Unit	%	Default	0	Index	26	507h				
	Activation	tivation Immediate											
	To set torque fo Applicable for l Application: Wh load at that par d04, use that va	orward feed add oaded vertical den load move a ticular point wi alue as torque	ward feed additional value of vertical axis. aded vertical axis, compensate constant torque. In load move along vertical axis, pick any point from the whole motion and stop icular point with motor enabled but not rotating. Record output torque value fro lue as torque command additional value (compensation value)										
	Label	Positive direct compensation	tion torq n value	ue	Mode				F				
Pr6.08	Range	-100~100	Unit	%	Default	0	Index	26	508h				
	Activation	Immediate											



	Label	Negative dire	ection tor	rque Mode				F		
Pr6.09	Range	-100~100	Unit	%	Default	0	Index	1 1	2609h	
	Activation	Immediate							-1	
	To reduce the ef	fect of mechan	ical frictio	on in th	e movement(s	s) of the ax	xis. Compe	ensation v	alues c	an
	be set according	y to needs for b	oth rotati	ional di	rections.					
	Applications:									
	1. When motor is	at constant sp	eed, d04	will de	liver torque va	alues.				
	Torque value in	positive direction	on = T1;							
	Torque value in	negative direct	ion = T2							
	Pr6.08/Pr6.09 = ⁻	$T_{f} = \frac{\left T1 - T2\right }{2}$								

5.7 Regenerative resistor settings

When motor torque is acting the opposite direction of the rotational direction (i.e. Deceleration, vertical drop axis), energy will flow back into the drive. This will caused the capacitors inside the drive to increase in voltage which might cause over capacity. Regenerative resistor is required here to prevent over capacity of the capacitors.

Regenerative energy can be reduced by reducing rotational inertia, increasing deceleration time, decrease load torque or reduce max. rotational velocity.

	Label	Regenera	ative resi	stance	Mode				F			
Pr0.16	Range	40~500	Unit	0hm	Default	100	Index		2016h			
	Activation	Immediat	e									
	To set resistance value of regenerative resistor											

	Label	Regenera power ra	ative resi ting	stor	Mode					F				
Pr0.17	Range	20~500 0	Unit	W	Default	50	Index		2017h					
	Activation Immediate													
	To set power rating of regenerative resistor.													
	Pr0.16 and Pr0.17 determines the threshold value of Er 120. Please set accordingly or it might													
	trigger false alarm or damage to servo driver.													
	Note: If external regenerative resistor is used, please set according to its labeled power													
	rating.													



5.8 Safety Functions

5.8.1 Max. motor rotational speed limitation

	Label	Maximum m velocity	iotor rota	ational	Mode							F
Pr3.24	Range	0~10000	Unit	r/min	Default	0	I	ndex			2324	h
	Activation	Immediate										
Maximum motor rotational as accordance to technical specification if set to 0												

5.8.2 Max. duration for motor to stop after disabling

Set max time duration for motor to stop after disabling. If the time taken for motor to stop exceeds the duration set in Pr6.14 and motor speed is still higher than Pr4.39, holding brake will be activated. If motor doesn't have holding brake, dynamic braking will be activated to force stop the motor.

	Label	Max. time to disabling	stop af	ter	Mode						F
Pr6.14	Range	0~3000	Unit	ms	Default	500	Index		2	2614h	
	Activation	Immediate									
	To set the ma disabling. After disablin reached, BRK BRK_ON giver whichever co Applications: 1. After disabl reached, BRK 2. After disabl is not yet read	x. time allowe g axis, if moto _ON given and n time is deter mes first. ing axis, if mo _ON given and ling axis, if mo ched, BRK_ON	tor speed mined b tor speed holding tor spee given a	e axis to is still g brake by Pr6.14 ed is sti g brake ed is alı nd hold	o stop on emer higher than Pr activated. 4 or when mot utivated. ready lower th ing brake activ	rgency s 4.39 but or speed Pr4.39 b an Pr4.3 vated.	top or r the tim d goes b ut the ti 39 but th	iorma e set pelow me se	l axis in Pr Pr4.3 et in F e set	5 6.14 is 39, Pr6.14 in Pr	; is 6.14



5.8.3 External brake deactivation output signal BRK-OFF

Please refer to Pr4.11 to set up the I/O output function parameters. When enabled and timing conditions are fulfilled, the set I/O output will deliver ON signal.

	Label	Motor power	-off dela	y time	Mode					F
Pr4.37	Range	0~3000	Unit	1ms	Default	100	Index	2	2437h	
	Activation	Immediate								
	To set dela from slidir	ay time for hol ng.	ding bra.	ke to be act	ivated after	· motor	power off to p	reven	t axis	
	Label	Delay time fo release	or holding	g brake	Mode					F
Pr4.38	Range	0~3000	Unit	1ms	Default	0	Index	2	2438h	
	Activation	Immediate								
	remain at cu be fully relea SRV_ON BRK_OFF Motor Power Actual holdir brake status Motor Velocity *1: Delay tim is released of dependent o	Brake off aset in Pr4.38 or BRK_ON sig n the holding	Brake re (BRK BRAKE RE (BRK 1 1 1 3 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	et in motion eleased _ON) On Released RK_OFF sign ven until act the motor.	Off *2 *2 Bra *3 t bal is given tual holding	until ac	tual holding b is activated. It	rake is		
	is released o dependent o *3: Decelera whichever co	or BRK_ON sig n the holding tion time is de omes first. BR	nal is gi brake of termine K_OFF g	ven until act the motor. d by Pr6.14 d jiven after d	tual holding or if motor s eceleration) brake speed g time.	is activated. It joes below Pr4	is 1.39,		

*4: Pr4.37 set time value.

Delay time from the moment SRV_ON is given until BRK_OFF switch to BRK_ON, is less than 500ms.



	Label	Holding bra speed	ke activ	ation	Mode							F
Pr4.39	Range	30~3000	Unit	RPM	Default	30	I	Index			2439h	1
	Activation	Immediate										
	To set the activ When SRV-OFF is not yet reach BRK_OFF signa comes first. Application: 1. After disabling given. 2. After disabling given.	ation speed for signal is give hed, BRK_OFF l is determine axis, Pr6.14 ha	or which en, moto is giver ed by Pr as been r as not be	n holding bra or decelerat n. 6.14 or if mo eached but m en reached b	ake will be es, after it otor speed notor speed out motor sp	e activ reach goes is stil	ated. nes b belo l abov s belo	elow w Pr4 ve Pr4 w Pr4	Pr4.3 i.39, v i.39, B i.39, B	9 and vhich RK_0 RK_0	d Pr6. iever FF sig FF sig	14 Inal

5.8.4 Servo stopping mode

	Label	Servo-off	mode		Mode						F				
Pr5.06	Range	0~5	Unit	—	Default	0	Index		2	506h	1				
	Activation	After resta	art												
	To set servo driver disable mode and status.														
	Set value														
	0	Driver disabl	.es after	in											
		Pr4.39													
1 Driver disables immediately, axis in free stopping mode															

	Label	Dynam mode	ic braking	9	Mode							F
Pr5.10	Range	0~2	Unit	-	Default	0	Ir	ndex			251	10h
Activation After restart												
	Set value		Explanation									
	0	Holding brake valid under normal and abnormal circumstances										
	1	Holding brake valid only under normal circumstance. To prevent damage										
		to holding brake due to high velocity, large inertia under abnormal circumstances)										



5.8.5 Emergency stop function

Emergency stop is used when an alarm occurs or a servo prohibition signal is received when servo driver is enabled.

Method 1: Set up Pr4.43 to enable the function

	Label	Emerger	ncy stop	func	tion	Mode								F
Pr4.43	Range	0~1	Uni	it	-	Default		0		Index	ĸ		2443h	1
	Activation	Immedia	ite											
	0: Emergency 1: Emergency	stop is vali stop is inva	id, servo Ilid, servo	driver o drive	r will be er will n	e forced to S not be forced	TOI d to	P an STC	d aları)P.	m occ	urs.			
	Label	Driver setting	prohibiti s	ion in	put	Mode							F	
Pr5.04	.04 Range Activation		Unit	_		Default	0	Inc	dex			2504H	1	
	Activation	Immed	iate											
	To set driver	prohibitio	n input (POT/N	NOT): If	set to 1, no	o ef	fect	t on he	oming	j mo	de.		
	Set value				Expl	lanation								
	0	$POT \rightarrow Pot$	ositive d	lirecti	on driv	e prohibite	ed							
	NOT \rightarrow Negative direction drive prohibited													
	1	POT and	NOT inva	alid										
	2	Any singl	e sided	input	from F	POT or NOT	mi	ght	cause	e Er26	50			
	In homing mo	de, POT/N	IOT inval	lid, pl	ease s	et object di	cti	onai	ry 501:	2-04	bit0=	:1		

Method 2: Using 605Ah object dictionary through master device to activate this function.

	Label	Servo b	oraking to	orque setting	Mode							F		
Pr5.11	Range	0~500	Unit	%	Default	0	In	ndex			251	1h		
	Activation	Immedi	ate											
	To set torque limit for servo braking mode.													
If Pr5.11 = 0, use torgue limit as under normal situation.														
	Between max. torque 6072 and Pr5.11, actual torque limit will take smaller value.													



5.9 Multiturn Absolute encoder

Multiturn absolute encoder records the position and the revolution counts of the motor. When driver is powered-off, multiturn absolute encoder will backed up the data using battery and after powering on, the data will be used to calculated absolute mechanical position and there is no need for a mechanical homing process. Use widely in robotic arms and CNC machines.

If it is the first time using the encoder, please home the mechanical axis and initialize the absolute position of the encoder to zero. Set up a homing point and only home when there is an alarm. Please stop the axis before reading any position data to prevent inaccuracy.

5.9.1 Parameter settings

	Label	Absolute settings	Encode	-	Mode	PP		НМ							
Pr0.15	Range	0~3276 7	Unit	-	Default	0	Inde	x		2015h					
	Activation	Immedia	te												
	0: Incremental	mode:													
	Used as an i	ncrementa	al encode	er. Doesn	't retain positi	on data	on pow	er off. l	Unlir	nited					
	travel distan	ice.													
	1: Multiturn linear mode : Used as a multiturn absolute encoder. Retrain position data on power off. For														
Used as a multiturn absolute encoder. Retrain position data on power off. For applications with fixed travel distance and no multiturn data overflow.															
applications with fixed travel distance and no multiturn data overflow.															
2: Multiturn rotary mode:															
Used as a multiturn absolute encoder. Retrain position data on power off. Actual data															
feedback in between 0-(Pr6.63). Unlimited travel distance.															
	3: Single turn a	absolute m	iode:												
	Used when tr alarm.	avel distai	ice is wi	thin I rev	olution of the	encoder	. Data d	overflow	w wi	ll trigg	er				
	5: Clear multite	urn alarm	and activ	vate mult	iturn absolute	functio	n. Will s	switch t	o m	ultiturr	า				
	mode once a	alarm clea	red, if re	mains at	5 after 3s, ple	ase solv	ve acco	rding to	b Er1	53.					
	9: Clear multitu	urn positio	n, reset	multiturn	alarm and ac	tivate m	nultiturr	n absolı	ute f	unctio	n.				
	Will switch t	o multitur	n mode d	once aları	m cleared, if r	emains	at 9 aft	er 3s, p	leas	e solve	e				
	according to	Er153. Ple	ase disa	ble axis I	before setting	to 9 and	d home	the axis	s bei	fore					
	using.														



5.9.2 Read absolute position

1、Steps:

1) First, select a motor with multiturn absolute encoder, install battery and confirm whether the driver version supports the specific motor;

2) Set Pr0.15 = 1. If it is the first time of installation, Err153 will occur because battery is newly installed and position data is invalid. Please home the axis and initialize the absolute position of the encoder to zero.

3) When absolute homing point is set and there is no fault with the battery, the alarm will be cleared

4) Finally, the user can read the absolute position. Position won't be lost even if the driver is powered off.





2、Read absolute position

When the rotor turns in clockwise direction, the revolution count will be negative; turns in counter clockwise direction, the count will be positive. No. of revolutions will be from -32767 to +32767. If the count number reaches +32767 in counter clockwise direction, the count will revert back to -32768, -32767 and vice versa for clockwise direction.

As for position data, it depends on the precision of the encoder. For 17 bit = 0-131071, 23 bit = 0-8388607



Read data from 6064h object dictionary

Please read data only when the motor is fully stopped or it might cause calculation errors. Please repeat this step for at least twice to make sure the result is uniform.

3、Clear multiturn position

Before clearing multiturn position, axis needs to be homed. After clearing multiturn position, revolution count = 0 but absolute position remains unchanged and Err153 alarm will be cleared.

Please make sure the homing point is within the range of 1 revolution of the rotor. Installation and setup of the homing point can be set with the use of auxiliary function D21 on the front panel.

By setting Pr0.15 to 9, multiturn position will be cleared.

Please take notice of motor position during power on. Range of motion of a motor depends on the position of the motor during power on (23-bit absolute encoder as example).



5.9.3 Absolute Encoder Related Alarm

The alarm can determine if absolute value encoder is valid. If battery power is low, not a motor with absolute encoder, encoder error etc. occurs, user can find out about the error from alarm output or on the front panel. Controller will stop any operation until alarm is cleared.

Alarm output:

Err153 will be shown on front panel or by I/O ALM signal and from controller.

Err153 might occur,

(1) If absolute encoder is used for the first time and due to installation of new batteries Axis needs to be homed and multiturn data needs to be cleared.

(2) If battery voltage is lower than 3.2v. Replace battery and restart the motor.

(3) If battery voltage is lower than 2.5v or battery power was cut off. Replacing the battery won't clear the alarm. Axis needs to be homed and multiturn data needs to be cleared.

4、 Alarm processing flow chart





Chapter 6 CANopen Communication

6.1 CANopen Protocol

CAN(Control Area Network) defines the physical and data layer but not the application layer. It needs a higher layer protocol to defined the specific function of each CAN telegram. CANopen is a higher level protocol based on CAN with CiA (CAN-in-Automation) defines the standard protocol. With CANopen, CANopen devices from different manufacturers can be linked together using CAN network.



In the OSI model shown below, the relation between CAN standard and CANopen is as shown below.



6.2 CANopen communication protocol for iSV2 series

CANopen communication protocol standards for iSV2-CAN

- CAN 2.0A standard
- CANopen standard protocol DS301 V4.02
- CANopen standard protocol DSP402 V2.01

CANopen services supported on iSV2-CAN series

- NMTslave
- Device monitoring services: Heartbeart, node guarding
- PDO: every slave station can be configured with max. of 4 TxPDO and 4 RxPDO
- PDO delivery: Event trigger, time trigger, synchronous cycle, synchronous non-cycle
- SDO
- Emergency Protocol

6.4 Predefined Connections

To reduce networking on CANopen drives, CANopen defines regulatory CAN-ID allocation table. CAN-ID is applicable under Per-Op mode, can modify through dynamic allocation. Corresponding CAN-ID has to be provided by the master device (controller).

CAN-ID allocation table is based on 11 bit CAN-ID, including 4 function bits and 7 Node-ID as shown below.

F	uncti	on bit	t			Ν	ode-ll	D		
10	9	8	7	6	5	4	3	2	1	0

Node-ID ranges from 1-127 (0 is not applicable)

Predefined connection includes 4 receiving PDO (RxPDO), 4 transmitting PDO (TxPDO), 1 SDO (2 CAN-ID), 1 urgent object and 1 Node error control ID. Unverified NMT module control service is also supported, SYNC and Time Stamp object broadcast is as table below.

CANopen predefined slave/master connection broadcast object				
Object	Function code	COB-ID	Object dictionary index	
NMT module control	0000	0x000	—	
SYNC	0001	0x080	1005H,1006H,1007H	
Time Stamp	0010	0x100	1012H,1013H	
CANopen slave/master connection equal object				
Object	Function code	COB-ID	Object dictionary index	
Urgent	0001	0x080+Node-ID	1024H,1015H	
TXPDO1(Transmit)	0011	0x180+Node-ID	1800H	
RXPDO1(Receive)	0100	0x200+Node-ID	1400H	
TXPDO2(Transmit)	0101	0x280+Node-ID	1801H	
RXPDO2(Receive)	0110	0x300+Node-ID	1401H	



TXPDO3(Transmit)	0111	0x380+Node-ID	1802H
RXPDO3(Receive)	1000	0x400+Node-ID	1402H
TXPDO4(Transmit)	1001	0x480+Node-ID	1803H
RXPDO4(Receive)	1010	0x500+Node-ID	1403H
SDO(Server	1011		1200
Transmission)	1011	0x580+10008-10	1200H
SDO(Client	1100		1200
Transmission)	1100	0x000+10002-10	1200H
NMT error control	1110	0x700+Node-ID	1016H~1017H

Note:

1. PDO/SDO Transmit/Receive is from the perspective of CAN slave node

2. NMT error control includes Node Guarding, Heartbeat and Boot-up protocol.

ID address allocation corresponds to predefined master/slave connections because every equal ID different, hence only 1 master device can be connected to max. of 127 slave stations. 2 slave nodes connected together have no communications.

Example: Slave node no. 4 COB-ID of TxPDO2 : 280h+4 = 284h

6.5 Object Dictionary

Object dictionary is a sequenced object set; every object uses a 16-bit index to search for address. To be able to request for any bit in the data, 8-bit sub-index is defined. Please refer to the table below.

Index	Object
0000H	Non-applicable
0001H——001FH	Standard data type, such Bool, Integer16 etc.
00201 00251	Complex data type, such as PDO communication parameters
0020n——003Fn	(PDOCOmmpar)
0040H——005FH	Manufacturer data type
0060H——007FH	Device profile standard data type
0080H——009FH	Device profile complex data type
00A0H——0FFFH	Reserved
1000H——1FFFH	Communication profile, such as device type, no. of PDO, etc.
2000H——5FFFH	Manufacturer specific profile
6000H——9FFFH	Standard device profile, such as DSP 402 object dictionary
A000H——FFFFH	Reserved

Every node in the CANopen network has an object dictionary that includes device descriptions and its parameters.

Object dictionary of node is described in Electronic Data Sheet EDS which can be regulated as accordingly. Node needs only to be able to provide the object required in object dictionary in optional and configurable function object.

CANopen includes many other profiles:

Communication profile – describes main form of object dictionary and communication profile objects. Also describes CANopen communication objects. Applicable for all CANopen devices



Device profile - describes functions, label, index/sub-index and data type of an object in object dictionary. The objects have to be write only, read only or read/write. Device profile determines if the object is selectable. If required object is more than is provided in device profile, enough room is left for manufacturer to define specific function object. Communication parameter in device profile is the same for all CANopen devices. Device related in object dictionary is different for different devices.

6.5.2 Object dictionary structure

Basic structure of object dictionary is defined in DS 301 as below						
	Index	Object	Label	Туре	Attribute	Selectable

6.5.3 Object type

"Object" in the table in 8.5.2 for ISV2-CAN is as below:

Object	Object code	Description
NULL	0	No data
DOMAIN	2	Mass data, such as operable programs
VAR	7	Variable such as BOOL, INT8
ARRAY	8	Array (Same type of data)
RECORD	9	Record (Different type of data)

6.5.4 Access attribute

Attribute	Description
RW	Read/Write
WO	Write only
RO	Read only
CONST	Constant, Read only



6.6 Network Management (NMT)

NMT provides network managing services which realized through master/slave communication mode.

6.6.1 NMT module control

Only NMT master node can transmit NMT control module telegram, all slave nodes must support NMT module control service, NMT module control doesn't have to answer.

NMT master node		
	Dute O	Dv+

COB-ID	Byte 0	Byte 1
0x000	Command word	Node-ID

When Node-ID = 0, all NMT slave nodes will be searched for address. Command word value and NMT relations is as below.

Command word	NMT Services
1(01H)	Activate remote nodes
2(02H)	Deactivate remote nodes
128(80H)	Pre-op
129(81H)	Reset nodes
130(82H)	Reset communication

6.6.2 NMT node guarding

NMT master node can monitor the status of each node through this service. Remote frame transmitted by the master node is as below.

NMT master node >> NMT slave node



Reply from NMT slave node

NMT slave node > NMT master node		
COB-ID Byte 0		
0x700+Node-ID Bit 6:0 Status		

.

Data including trigger bit (bit 7) must switch between "1" and "0" during each node guarding. Set as "0" on the first trigger of node guarding. Bit 0 to 6 represents node status.

Bit	Status
0(00H)	Initialize
1(01H)	Not connected
2(02H)	Connected
3(03H)	Ready
4(04H)	Stop
5(05H)	Operation
127(7FH)	Pre-operation



Heartbeart is defined as a node that can be configured as operational duty cycle.

Heartbeat producer> Consumer		
COB-ID	Byte 0	
0x700+Node-ID	Status	
Status code	Status	
0	Boot-up	
4	Stop	
5	Operation	
127	Pre-Op	

6.6.3 NMT Boot-up

NMT sends Boot-up telegram from node to NMT master to inform that it has switched from initialization status to Pre-Op status.

|--|

COB-ID	Byte 0
0x700+Node-ID	0

6.6.4 NMT communication status machine



(1) Power on, automatically enter initialization mode.

(2) Enter Pre-Operation mode

(3)(6) Activate remote node



(4)(7) Enter Pre-Operation mode
(5)(8) Deactivate remote node
(9)(10)(11) Reset node
(12)(13)(14) Reset communication
(15) Automatically enter reset application mode

(16) Automatically enter reset communication mode

Enter Pre-Operation after device initialization (Initialization, reset application and reset communication) is done. In this mode, device parameter and ID can be configured using this SDO. Then, node enters directly into operation mode.

6.7 Process Data Object (PDO)

PDO uses producer/consumer mode, PDO data transmission is usually 1-to-1 or 1-to-N. Every PDO message includes transmit PDO (TxPDO) and receive PDO (RxPDO), transmission method is defined using PDO communication parameter index (1st set receive PDO is set in index 1400h, 1st set transmit PDO is set in index 1800h).

All PDO transmission data has to be reflected on corresponding index through object dictionary. Using 1600h and 1A00h object in DSP 402 as example:

Master device sends data to slave station PDO



PDO1 data value Data 0, Data 1, Data 2, Data 3, Data 4, Data 5, Data 6, Data 7, 0x11, 0x22, 0x33, 0x44, 0x55, 0x66, 0x77, 0x88,

	Index	Sub	Definition	Value	R/W	Size
		-			-	110
(0x1600	0	0. Number	1	R/W	08
	0x1600	1	1. Mapped Object	0x604000 <u>10</u>	R/W	U32
PDO1 Map	0x1600	2	2. Mapped Object		R/W	U32
	0x1600	3	3 Mapped Object		R/W	U32
	0x1600	4	4. Mapped Object	0	R/W	U32
0x60400010	0x6040	0	0. Control word	0x2211	R/W	∢ U16 (2 Byte)



Diagram shows in a more detailed description of the relationship between PDO parameters (1400h) and PDO image (1600h), PDO data transmission (Node 2 as example). Arrow represents data flow direction from master device.





Master device receives data from slave station



PDO1 data value Data 0, Data 1, Data 2, Data 3, Data 4, Data 5, Data 6, Data 7, 0xF3, 0x00,

	Index	Sub	Definition	Value	R/W	Size
		$\left \right\rangle$				
	0		0 Number	4		110
(0x1A00		0. Number	0x60410010	R/W	08
PDO1 Map	0x1A00	2	Mapped Object Mapped Object	0,004100 <u>10</u>	R/W	1132
	0x1A00	3	3. Mapped Object	0	R/W	U32
	0x1A00	4	4. Mapped Object	0	R/W	U32
)						
	0x6041	0	Stalusword	0xF3	R/W	U 16

Diagram shows in a more detailed description of the relationship between PDO parameters (1800h) and PDO image (1A00h), PDO data transmission (Node 2 as example). Arrow represents data flow direction from slave station.



6.8 Service Data Object

SDO is used to access object dictionary of a device. Access side is referred to as client, CANopen device which provides required services with accessed object dictionary is referred to as server. Clients' CAN telegram and servers' replies CAN telegram includes 8-byte data. Every request from client is met with reply from the server.

Basic structure is as shown below:

Client Server Client						
Byte O	Byte 1:2	Byte 3	Byte 4:7			
SDO command word	Object index	Object sub-index	Data			

For example, write value 0x20F0 into index 1801h, sub-index 3 with ID no.2 using SDO

Client ⊏	===> Se	erver						
COB-ID	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
602	2B	01	18	03	FO	20	00	00
Server 💳 Client								
582	60	01	18	03	00	00	00	00

Using SDO, read object dictionary of index 1801h and sub-index 3 object data.

Client 🗆	==> S€	erver						
COB-ID	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
602	40	01	18	03	00	00	00	00
Server 💳 > Client								
582	4B	01	18	03	FO	20	00	00

SDO client or server will stop SDO transmission using the telegram format as below

Client──>	Server 💳 > Client	

Bit	7	6	5	4	3	2	1	0
	1	0	0	-	-	-	-	-

In SDO transmission stop telegram, data byte 0 and 1 represent object index, byte 2 represents subindex, byte 4-7 include 32-bit stop code, which describes the reason for stopping transmission



6.9 Emergency Object

Emergency object is triggered when there is an occurrence of severe error from device internal. This will be sent to other devices with highest priority. Applicable for alarms which interrupt and stop operation.

An emergency telegram is made up of 8 bytes with format as below:

Transmitting end ———————————————————————————————————							
COB-ID	Byte 0:1	Byte 2	Byte 3:7				
0x080+Node-	Emergency error	Error registry	Manufacturer's				
ID	code	(1001h)	specific				

Recently appeared error will be stored in object dictionary (index 1003h); user can read these information using; 2ISV2 series servo drive will not store these error messages once powered off. Current error type will be stored in object dictionary error registry (index 1001h).

Device can reflect internal error in status word and check for current error type.

Error Registry	Error type
0	General error
1	Current
2	Voltage
3	Temperature
4	Communication
5	Device profile error
6	Reserved
7	Manufacturer's specific error



Chapter 7 Warning and Alarm

7.1 Servo drive alarm overview

Green LED: Power ON/Motor enable

ON for once: Power ON Always ON: Motor Enable Blinking: Motor Disable OFF: Power OFF

Red LED: Alarm indicator (Motor stops when alarm indicator is ON)

	Blink for 5s/cycle (Please refer to the table below)							
Error	OFF: Blink	Alarm cleared Sequence	Frror					
0E1/ 0E0	15		Hardware/so ftware overcurrent					
0C0/ 0D0	25		Under- /overvoltage					
81B	35	0.5s0.5s	CANopen communicati on timeout					
0A3	4S		Motor phase missing					
150/ 151	55		Encoder error					
100	6S		Overload					
180	75		Excessive position deviation					
0F0	8S		Over- temperature					
1A0/ 1A1	1S1L	0.5s0.5s 1.5s 5s 0.5s0.5s 1.5s	Motor loses speed					
0A0/ 0A1	1S2L	0.5s0.5s 1.5s 5s 0.5s0.5s 1.5s	Hardware initialization error					
240	1S3L		Parameter saving error					
	1S4L		Other error					

S: Short, L: Long. 1S4L represents 1 short blink and 4 long blinks



5202	80	871	Mode not supported under synchronous mode
5441	80	570	IO emergency stop
5510	80	802	RAM full
5511	80	803	RAM over boundary
5530	80	240	EEPROM parameters saving error
5531	80	241	EEPROM hardware error
5532	80	242	Error saving alarm history record
5533	80	243	Error occurred when saving vendor parameters
5534	80	244	Error occurred when saving communication parameters
5535	80	245	Error occurred when saving parameter 402
5536	80	246	Data saving error during power-off
5550	80	850	ESC EEPROM is inaccessible
5551	80	851	ESI file saving error
5552	80	852	Linking failed
FF01	80	860	CANopen frame lost per unit time exceeds limit
6201	80	806	Saved ESI file does not match driver firmware
6202	80	805	F0E firmware update failed
6203	80	814	Firmware invalid
6321	80	210	I/O input configuration repeated
6322	80	211	I/O input parameter out of range
6323	80	212	I/O output parameter out of range
6329	80	090	FPGA parameter writing error
7122	80	5F0	Motor model error
7321	80	150	Encoder disconnected
7322	80	151	Encoder communication error



7323	80	152	Encoder initial position error
7324	80	170	Multiturn encoder error / Encoder parameter settings error
7325	80	153/154	Encoder data overflow
7326	80	155	Encoder overheated
7327	80	156	Encoder count error
7328	80	157	Encoder disconnected
7329	80	260	Position limit alarm, position limit valid during alarm
7701	80	120	Regenerative energy overload
7702	80	121	Regenerative resistor error
8110	10	901	CANopen overload alarm
8120	10	902	Passive error
8130	10	903	Heartbeat/Node guarding timeout
8140	10	904	Disconnection recovered
8141	10	905	Disconnected
8150	10	906	ID clash
8201	10	801	Unknown communication error
8207	10	807	PDO mapping object not exist
8208	10	808	PD0 mapping object error
8210	10	82B	Due to length error, PDO not processed /processing timeout
8211	10	818	Due to length error, TPDO not processed /processing timeout
8212	10	819	Due to length error, RPDO not processed /processing timeout
8213	10	813	BOOT not supported
8215	10	815	Invalid mailbox configuration under boot state
8216	10	816	Pre-Op status is invalid for the mailbox configuration
8217	10	817	Invalid SyncManager configuration
821B	10	81B	SyncManager2 watchdog timer timeout


821C	10	81C	Invalid SyncManager type
821D	10	81D	Invalid output configuration
821E	10	81E	Invalid input configuration
821F	10	81F	Watchdog configuration invalid
8220	10	820	PD0 length over limit
8224	10	824	TPDO mapping invalid
8225	10	825	RPD0 mapping invalid
8226	10	826	Configuration non-consistent
8310	2	101	Motor overloaded
8311	2	100	Driver overloaded
8305	2	105	Torque over limit
8401	20	190	Motor vibration too strong
8402	20	1A0	Overspeed
8403	20	1A1	Velocity out of control
8503	20	1B1	Incorrect electronic gear ratio
8611	20	180	Excessive Position Deviation
8610	20	181	Position following error
8612	20	1B0	Excessive position increment
871A	10	81A	Synchronization error
8727	10	827	Free running mode is not supported
8728	10	828	Sync mode not supported
872C	10	82C	Invalid inputs and outputs
872D	10	82D	Fatal synchronization error
872E	10	82E	No synchronization error
8730	10	830	Invalid Distributed Clock synchronization settings
8732	10	832	Distribution Clock phase-locked loop failure
8733	10	833	DC sync IO error



8734	10	834	DC sync timeout
8735	10	835	Distribution Clock cycle time is invalid
8736	10	836	SYNC0 cycle time invalid
8737	10	837	SYNC1 cycle time invalid
873A	10	73A	SyncManager2 lost
873B	10	73B	SYNC0 lost
873C	10	73C	Excessive Distributed Clock error

When error occurs, drive will take protection measures and stops the motor. Error code will be shown on tuning software or master device (controller) can read corresponding error code from object dictionary. Please refer to the table below.

603F (HEX)	1001 (HEX)	Alarm code(HEX)	Alarm
2211	2	0E0	Software overcurrent
2212	2	0E1	Hardware overcurrent
3130	4	0D1	Phase missing
3150	4	0A0	Phase A circuit current detection error
3151	4	0A1	Phase B circuit current detection error
3152	4	0A2	Analog input 1 circuit error
3153	4	0A3	Motor power cable not connected
3154	4	0A4	Analog input 2 circuit error
3160	4	270	Excessive analog input 1
3161	4	271	Excessive analog input 2
3162	4	272	Excessive analog input 3
3201	4	0A5	DC bus base voltage error
3205	4	0B0	Control circuit voltage too low
3206	4	0B1	Control circuit voltage too high
3211	4	0C0	DC bus voltage too high
3221	4	0D0	DC bus voltage too low



3222	4	0D2	Main power supply disconnected
4201	8	0A6	Temperature base sampling error
4210	8	0F0	Drive over-temperature
5201	80	870	Servo unable to enable under current mode

7.2 Alarm Handling

**When error occurs, please solve accordingly. Then, restart.

Error	Main	Sub	Display: "Er 090"		
code	09	0~F	Content: FPGA communication error		
Cause			Diagnosis	Solution	
Driver fault			/	Replace driver	

Error	Main	Sub	Display: "Er 0A0""Er 0A1" Content: Circuit current detection error		
code	0A	0~1			
Cause Diag			Diagnosis	Solution	
Motor power cable wiring error		le wiring	Verify motor power cable wiring	Make sure U,V,W terminal wired properly	
Main power supply undervoltage		ly	Verify L1,L2,L3 terminal voltage	Increase main power supply voltage	
Driver fa	ault		/	Replace driver	

Error	Main	Sub	Display: "Er 0A2", "Er 0A4"		
code	0A	2/4	Content: Analog input circuit error		
Cause			Diagnosis	Solution	
Analog input wiring		ng	Verify analog input wiring	Make analog input wiring is correct	
Driver f	ault		/ Replace driver		

Error	Main	Sub	Display: "Er 0A3" Content: Motor power cable not connected		Display: "Er 0A3"	
code	0A	3				
Cause	Cause Diagnosis		Diagnosis	Solution		
Motor p connect	ower cab ed	le not	Verify motor power cable wiring	Measure resistance values between U, V, W terminals , make sure the values are almost equal. If not, might be due to damaged motor or motor winding open circuit.		
Motor fa	ault		/	Replace motor		
Driver f	ault		/	Replace driver		



Error	Main	Sub	Display: "Er 0A5"	
code 0A 5 Content: DC bus circuit error				
Cause			Diagnosis	Solution
Driver fault			1	Replace driver

Error	Main	Sub	Display: "Er 0A6"	
code	0A	5 Content: Temperature detection circuit er		on circuit error
Cause			Diagnosis	Solution
Driver fault			/	Replace driver

Error	Main	Sub	Display: "Er 0b0" Content: Control circuit power supply low		
code	Ob	0			
Cause Diagnosis			Diagnosis	Solution	
Control circuit power supply too low		oower	Check if wiring is correct; Check the voltage on power supply input	Fix wiring error	
Power supply capacity		apacity	/	Replace power supply or use	
low				independent power supply for	
				control circuit	

Error	Main	Sub	Display: "Er 0c0" Content: DC bus overvoltage		
code	0c	0			
Cause Diagno			Diagnosis	Solution	
Main power supply overvoltage		oply	Verify L+,L- terminal voltage	Decrease main power supply voltage	
Driver fault			/ Replace driver		

Error	Main	Sub	Display: "Er 0d0"			
code	Od	0	Content: DC bus undervoltage			
Cause			Diagnosis Solution			
Main power supply undervoltage		ly	Verify L-,L+ terminal voltage	Increase main power supply voltage		
Driver fault			/	Replace driver		

Error	Main	Sub	Display: "Er Od2"				
code	Od	2	Content: No main power supply detected				
Cause			Diagnosis	Solution			
No main power supply			Verify L1,L2,L3 terminal voltage	 Increase main power supply voltage Secure connections 			
Driver fault			/ Replace driver				



Error	Main	Sub	Display: "Er 0E0"			
code	0E	0	Content: Overcurrent			
Cause			Diagnosis	Solution		
Driver power output short circuit			Verify if there is short circuit between UVW terminals, or shorted to PG.	 Make sure there is no circuit. Make sure motor is not damaged 		
Motor w	iring erro	or	Verify motor wiring	Reconnect motor wiring		
IGBT module short circuit			Disconnect motor output cable. Then, enable servo driver to check for overcurrent	Replace driver		
Excessive motor load			Verify if motor torque output is too high	1. Reduce load 2. Add a gearbox		
Excessive acceleration and deceleration			Verify if acceleration and deceleration duration time are too low	Increase acceleration and deceleration duration time		
Motor wiring short circuit			Connect motor power cable to driver power output. Verify if resistance value of UVW to PE is equal and if there is short circuit	Replace motor		

Error	Main	Sub	Display: "Er 0E1"			
code	0E	1	Content: Intelligent Power Module (IPM) overcurrent			
Cause			Diagnosis	Solution		
Driver power output short circuit			Verify if there is short circuit between UVW terminals, or shorted to PG.	 Make sure there is no circuit. Make sure motor is not damaged 		
Motor w	iring erro	or	Verify motor wiring	Reconnect motor wiring		
IGBT module short circuit		rt	Disconnect motor output cable. Then, enable servo driver to check for overcurrent			
IGBT module undervoltage			/	Replace driver		
Excessive motor load			Verify if motor torque output is too high	1. Reduce load 2. Add a gearbox		
Excessive acceleration and deceleration		ration	Verify if acceleration and deceleration duration time are too low	Increase acceleration and deceleration duration time		
Motor wiring short circuit			Connect motor power cable to driver power output. Verify if resistance value of UVW to PE is equal and if there is short circuit	Replace motor		



Error	Main	Sub	Display: " <mark>Er 0F0</mark> "		
code	OF	0	Content: Driver overheated		
Cause			Diagnosis	Solution	
Temperat module e limit	ure of p xceedeo	ower I upper	Measure the temperature of driver radiator.	 Improve cooling condition. Please check installation guide; Replace driver and motor with higher power rating; Increase duration time for acceleration and deceleration; Decrease load 	

Error code	Main	Sub	Display: "Er 100"	
	10	0	Content: Motor overloaded	
Cause		Diagno	osis	Solution
Load too heavy		Verify if actual load exceeds maximum value allowed		1. Decrease load 2. Adjust limit values
Strong mechanical vibration		Look for mechanical vibration from machine system		 Adjust gain value of control loop Increase duration time for acceleration and deceleration
Motor or encoder cable wiring error		Verify motor and encoder wiring		1. Reconnect wiring 2. Replace motor and encoder cable
Holding bi engaged	rake	Verify l	holding brake terminal voltage	Cut off holding brake

Error	Main	Sub	Display: "Er 101"	
code	10	1	Content: Drive overload	
Cause			agnosis Solution	
Motor power supply connection incorrect		y ct	Verify UVW wiring	Make UVW wiring is correct
Motor mismatched			Motor rated current is higher than drive max. output current	Change motor with lower current rating or drive with higher current output

Error code	Main	Sub	Display: "Er 102"	
	10	2	Content: Motor rotor blocked	
Cause Di		Diagno	osis Solution	
Motor rotor blocked		Look for mechanical blockages		Check the machinery
Motor rotor blocking time threshold value too low		Verify	value of Pr6.57	Adjust value of Pr6.57



Error	Main	Sub	Display: "Er 120"		
code	12	0	Content: Regenerative resistor overvoltage		
Cause			Diagnosis	Solution	
Regenerat	tive ene	rgy	1. Verify if velocity is too	1. Decrease motor rotational velocity;	
exceeded	capacity	y of	high	2. Decrease load inertia;	
regenerative resistor		stor	2. Verify if load is too large	Add an external regenerative resistor;	
Power sup	Power supply voltage		1. Verify if power supply 1. Decrease power supply voltage		
too high			voltage is within the rated	2. Increase regeneration resistance	
			range.	value(add external regenerative resistor)	
			2. Interval regenerative		
			resistor value is too low		
Unstable	oower s	upply	Verify if power supply	Add a surge suppressor to main power	
voltage			voltage is stable	supply.	
Regenerative energy		rgy	/ 1. Add an external regenerative resiste		
discharge	circuit			2. Replace driver	
damaged					

Error	Main	Sub	Display: "Er 121"	Display: "Er 121"	
code	12	1	Content: Holding brake error		
Cause			Diagnosis	Solution	
Holding	brake	circuit	Regenerative resistor disconnected	Replace regenerative resistor	
damaged			Holding brake IGBT damaged	Replace driver	

Error	Main	Sub	Display: "Er 122"	
code	12	2	Content: Regenerative resistor value too low	
Cause			Diagnosis	Solution
External regenerative resistor value is less than the minimum value allowed by the drive		ative ess n value ve	/	Replace the regenerative resistor with the right resistance value which meets the specification of the driver

Error	Main	Sub	Display: " <mark>Er 150</mark> "					
code	15	0	Content: Encoder disconnected					
Cause			Diagnosis	Solution				
Encoder cable disconnected			Verify encoder cable connection	Make sure encoder cable properly connected				
Encoder cable wiring error		ring	Verify if encoder wiring is correct	Reconnect encoder wiring				
Encoder damaged		1	/	Replace motor				
Encoder measuring circuit damaged			/ Replace driver					



Error	Main	Sub	Display: "Er 151"			
code	15	1	Content: Encoder communication error			
Cause			Diagnosis	Solution		
Encoder wire shielding layer is missing			Verify if encoder cable has shielding layer	Replace with standard encoder cable		
Encoder cable wiring error		ring	Verify if encoder wiring is correct	Reconnect encoder wiring		
Encoder damaged			/	Replace motor		

Frror	Main	Sub	Display: "Er 152"		
code	15	2	Content: Encoder initial position en	rror	
Cause		[liagnosis	Solution	
Communication data abnormal		1 V 2 I 3 F	Verify if encoder power supply oltage is DC5V±5% ; . Verify if encoder cable and shielded ayer is not damaged; . Verify if encoder cable is close to igh-powered power supply cable	 Make sure encoder power supply voltage is stable Make sure encoder cable is not damaged. Make sure encoder cable shielded layer is grounded to frame Make sure encoder cable is away from high-powered power supply cable 	
Encoder damaged		d	/	Replace motor	
Encoder measuring circuit damaged		ng	/	Replace driver	

Error	Main	Sub	Display: "Er 153"		
code	15	3	Content: Multiturn enco	der error	
Cause			Diagnosis	Solution	
Initial use			Origin calibration not performed	Perform origin positioning and multiturn position initialization, calibrate the origin of coordinate system.	
Encoder without multiturn absolute function used		te	Verify if encoder has multiturn absolute function	 Replace the motor with a multiturn absolute encoder. Set Pr0.15 = 0 to deactivate multiturn absolute function. 	
Low battery power		er	Replace battery and restart driver to clear alarm	Replace battery	
Battery has no power or has been dismantled		ower nantled	Alarm not cleared after replacing battery and restart	Absolute position lost. Return to origin ar perform multiturn initialization, calibration the origin of coordinate system	



Error	Main	Sub	Display: "Er 154"			
code	15	4	Content: Encoder parameter settings error			
Cause			Diagnosis	Solution		
Absolute encoder mode is incorrectly set.			Verify if encoder has multi-turn absolute value function.	Modify absolute encoder mode settings		

Error	Main	Sub	Display: "Er 155"	
code	15	5	Content: Encoder data overflow	
Cause			Diagnosis	Solution
Encoder data overflow			Verify if encoder is not damaged	Initialize multiturn data
Absolute value applications, motor rotates in one direction			Verify if encoder is not damaged	Adjust absolute value application mode, set to turntable mode

Error Main Sub Display: "Er 156"						
code	15	6	Content: Encoder overheated			
Cause			Diagnosis	Solution		
The encoder temperature is too high.		oo high.	Verify if motor temperature is too high	Reduce encoder temperature.		

Error Main Sub Display: "E		Display: "Er 157"		
code	15	7	Content: Encoder counter error	
Cause			Diagnosis	Solution
Encoder data overflow			Verify if encoder is not damaged	Initialize multiturn data
Absolute value applications, motor rotates in one direction		or rection	Verify if encoder is not damaged	Adjust absolute value application mode, set to turntable mode

Error Main S		Su	b	Display: "Er 170"	
code	17		0	Content: Encoder data error	
Cause			Diag	nosis	Solution
Communication data abnormal			 Verify if encoder power supply voltage is DC5V±5%; Verify if encoder cable and shielded layer is not damaged; Verify if encoder cable is close to high-powered power supply cable 		 Make sure encoder power supply voltage is stable Make sure encoder cable is not damaged. Make sure encoder cable shielded layer is grounded to frame Make sure encoder cable is away from high-powered power supply cable
Encoder damaged		/		Replace motor	
Encoder measuring circuit damaged			/	Replace driver	



Error	Main	Sub	Sub Display: "Er 171"		
code	17	1	Content: Encoder parameter init	Content: Encoder parameter initialization error	
Cause Di		Dia	gnosis	Solution	
Driver and motor not matched		Ve	ify driver and motor models.	Replace with matching driver and motor	
Error while getting parameters from encoder		g 1. \ 2. \ ins im	erify if encoder cable is standard. erify if encoder has no peeled ulator, broken connection or proper contact.	Use standard encoder cable, verify the connection of both sides of driver and motor, change encoder cable if necessary	

Error	Main	Sub	Display: "Er 180"	Display: " <mark>Er 180</mark> "			
code	18	0	Content: Excessive position deviation				
Cause			Diagnosis	Solution			
lmproper p	osition		Verify if value of Pr_014 is too low	Increase value of Pr_014			
deviation se	ettings						
Position ga	in settin	g too	Verify if values of Pr1.00 & Pr1.05 are	Increase values of Pr1.00 &			
low			too low	Pr1.05			
Torque limit teo low		M	Verify if values of Pr0.13 & Pr5.22 are	Increase values of Pr0.13 &			
		v	too low	Pr5.22			
Excessive external load			1. Verify if acceleration and decelerationduration time is too low.2. Verify if rotational velocity is too	 Increase duration time for acceleration and deceleration Decrease rotational 			
Excessive external load			high 3. Verify if load is too large	velocity 3. Decrease load			

Error	Main	Sub	Display: "Er 181"				
code	18	1	Content: Excessive velocity deviation				
Cause			Diagnosis	Solution			
Deviation between set velocity and actual velocity is too great			is Verify if value of Pr6.02 is too low	 Increase value of Pr6.02; Set Pr6.02 to 0, position error detection off. 			
Acceleration and deceleration duration time for set velocity is too low			Verify if value of Pr3.12 and Pr3.13 are too low	 Increase value of Pr3.12, Pr3.13; Adjust velocity gain to reduce velocity lag error 			

Frror	Main	Sub	Display: "Er 190" Content: Motor vibration too strong		
code	19	0			
Cause			Diagnosis	Solution	
Motor velocity fluctuates		uctuates	Verify if Pr0.03 is too large	Decrease value of Pr0.03	
too much					



Error	Main	Sub	Display: "Er 1A0"			
code	1A	0	Content: Overspeed			
Cause		Diagno	osis	Solution		
Motor velocity exceeded first speed limit (Pr3.21)		1. Verif 2. Verif voltage 3. Verif 4. Verif freque 5. Verif	y if velocity command is too high; iy if simulated velocity command e is too high; iy if parameter value of Pr3.21 is too low; fy if input frequency and division ncy coefficient of pulse train is proper; fy if encoder is wired correctly	 Adjust velocity input command; 2. Increase Pr3.21 value; Adjust pulse train input frequency and division frequency coefficient; Verify encoder wiring; 		

Error Main		Sub	Display: "Er 1A1"			
code	1A	1	Content: Velocity out of control			
Cause Diagnosis		osis	Solution			
Motor velo	ocity	Verify encoder phase sequence; Verify if UVW		Reconnect UVW if wrongly		
out of control,		cable is connected to the right terminal		connected. If still remains		
Excessive				unsolved, please contact		
velocity er	rror			technical support.		

Error	Main	Sub	Display: "Er 1b0"		
code	1b	0	Content: Bus input signal dithering		
Cause			Diagnosis	Solution	
Controller synchronization dithering			/	Increase alarm threshold value	

Error	Main	Sub	Display: "Er 1b1"	
code	1b	1	Content: Incorrect electronic gear ratio	
Cause			Diagnosis	Solution
Values out of range		ige	Numerator or denominator is zero/Set values out of range	Reduce number of pulses per revolution

Error	Main	Sub	Display: "Er 1c0"		
code	1c	0	Content: Both STO failed		
Cause			Diagnosis Solution		
Both STO input signals			Verify if STO power supply is normal	Verify 24V STO power supply and power cable connection	
valid		-	Disconnect switch connected to STO	Close switch	



Error	Main	Sub	Display: "Er 1c1"		
code	1c	1	Content: 1 st STO failed		
Cause			Diagnosis Solution		
			Verify if STO power supply Verify 24V STO power supply and power		
1 st STO input signal		nal	is normal cable connection		
valid			Disconnect switch Close switch		
			connected to STO		

Error Main		Sub	Display: "Er 1c2"		
code	1c	2	Content: 2 nd STO failed		
Cause			Diagnosis	Diagnosis Solution	
			Verify if STO power supply	Verify 24V STO power supply and power	
2 nd STO input signal		nal	is normal cable connection		
valid			Disconnect switch	Close switch	
			connected to STO		

Error	Main	Sub	Display: <mark>"Er 210</mark> "		
code	21	0	Content: I/O input interface assignment error		
Cause			Diagnosis	Solution	
Input signal assigned with			Verify values of Pr4.00-Pr4.09,	Set proper values for Pr4.00-	
two or more functions.			Pr4.44-4.47	Pr4.09, Pr4.44-4.47	

Error	Main Sub Display: "Er 211"			
code 21		1	Content: I/O input interface function assignment error	
Cause			Diagnosis	Solution
Input signal assignment			Verify values of Pr4.00-Pr4.09,	Set proper values for Pr4.00-
error			Pr4.44-4.47	Pr4.09, Pr4.44-4.47

Error Main S		Sub	Display: "Er 212"				
code	21	2	Content: I/O output interface function assignment error				
Cause			Diagnosis	Solution			
Input signal assigned with		ned with	Verify values of Pr4.10-Pr4.15	Set proper values for Pr4.10-Pr4.15			
two or more functions.		ions.					
Input signal not assigned		ssigned	Verify values of Pr4.10-Pr4.15	Set proper values for Pr4.10-Pr4.15			

Error	Main	Sub	Display: "Er 240"		
code	24	0	Content: EEPROM parameters initialization error		
Cause			Diagnosis	Solution	
Error during initial		ıl	Restart after changing any	If parameter not saved after several	
reading of EEPROM			parameter. Verify if the	restarts, please change driver	
parameters			parameter is saved.		



Error	Main	Sub	Display: "Er 241"		
code	24	1	Content: EEPROM hardware error		
Cause			Diagnosis	Solution	
EEPROM damaged			Verify if multiple storages are the same	Replace driver/Upgrade software	

Error	Main	Sub	Display: "Er 242"				
code	24	2	Content: Error saving alarm history record				
Cause			Diagnosis	Solution			
Power-off during saving		saving	Verify alarm during power-off	Power lost after alarm appears			
Several different alarms			Vorify alarm codo	Figure out other alarm causes			
in a row			verify atalificode				
EEPROM damaged			Verify if it is the same over Replace driver/Upgrade software				
			several times				

Error Main Sub Display: "Er 243"		Display: "Er 243"			
code	24	3	Content: Error occurred when saving vendor parameters		
Cause			Diagnosis	Solution	
Power-off before data		data		Wait until data saved successfully	
saved				before powering off	
EEPROM damaged		1	Restart driver for a few times	Restart driver for a few times	

Error Main		Sub	Display: "Er 244"	
code	24	4	Error description: Error occu	irred when saving communication
Cause			Diagnosis	Solution
Power-off before data				Wait until data saved successfully
saved				before powering off
EEPROM damaged		4	Restart driver for a few times	Restart driver for a few times

Error Main Sub Display: "Er 245"					
code	24	5	Error description: Error occurred when saving parameter 402		
Cause			Diagnosis	Solution	
Power-off before data		data		Wait until data saved successfully	
saved				before powering off	
EEPROM damaged		4	Restart driver for a few times	Restart driver for a few times	

Error	Main	Sub	Display: <mark>"Er 246</mark> "		
code	24	6	Error description: Data saving error during power-off		
Cause			Diagnosis	Solution	
Power off too fast				Upgrade software	
EEPROM damaged		d	Restart driver for a few times	Restart driver for a few times	



Frror		Sub	Display: "Er 260"	
code	26	0	Error description: Positive/Negative position limit triggered un non-homing mode	
Cause			Diagnosis	Solution
Positive/negative position limit triggered			Verify position limit signal	/

Error	Main	Sub	Display: "Er 280" Error description: Output pulse frequency too high		
code	28	0			
Cause			Diagnosis	Solution	
Frequency divided pulse output exceeds 1MHz			Verify if motor rotational speed and the number of frequency	Reduce the number of frequency divided pulse output	
			divided pulse output are too high	or reduce rotational speed	

Error	Mai	Sub	Display: " <mark>Er 570</mark> "		
code 57		0	Error description: Forced alarm input valid		
Cause			Diagnosis	Solution	
Forced alarm input signal occurred		put	Verify forced alarm input signal	Verify if the input wiring connection is correct	

Error Main Sub			Display: "Er 5F0"		
code	5F	0	Content: Motor model no. detection error		
Cause			Diagnosis	Solution	
Automatically detected		tected		Please contact our technical	
motor doesn't match		atch	/	support	
set motor	-				

Error	Main	Sub	Display: "Er 5F1"		
code	5F	1	Error description: Driver power module detection error		
Cause			Diagnosis	Solution	
Driver power rating not within range.			Restart driver	Please contact our technical support	

Error code	Main	Sub	Display: "Er 600"		
	60	0	Error description: Main loop interrupted timeout		
Cause			Diagnosis	Solution	
The motor control loop calculation time			Check for interference from devices releasing electromagnetic field	Ground driver and motor to reduce interference	
overnow			Restart driver	Replace driver	



Error	Main	Sub	Display: "Er 601"	Display: "Er 601"		
code	60	1	Error description: Velocity loop interrupted timeout			
Cause			Diagnosis	Solution		
Motor control loop calculation time overflow			Verify if encoder connection is and that the encoder cable is too not long (more than 20 meters)	Replace encoder cable if necessary		
			Restart driver	Replace the drive with a new one		

Error	Main	Sub	Display: "Er 700"				
code	70	0	Error description: Encryption error				
Cause			Diagnosis	Solution			
Encryption error during initialization upon power-on.			Restart driver	Please contact our technical support			

7.3 CANopen Communication Alarm

CANopen communication related alarms are erasable and will not be recorded in alarm history. Clearing CANopen communication alarm is similar to clearing servo driver alarm. Please clear the alarm before switching to 402 machine state.

CANopen communication alarm however, relies on register clearance from the main station. Can be solved according to following steps:

1、Set bit 4 of ESC control register 0x120 (error responder) to 1.

2. The communication alarm can be cleared until the feedback of the ESC status code register 0x134~0x135 is 0.

3、By setting bit 7 of 6040h to 1, switches state machine from fault to initialization completion , No fault(Switch on disabled).

Error code	Main	Sub	Display: "Er 73A"	Display: "Er 73A"			
	73	Α	Error description: SyncManager2 lost				
Cause			Diagnosis Solution				
Poor master			Increase the alarm				
performa	nce			threshold			
Single-unit drive has			Is it a single unit or multiple units together	Switch drive			
problem			in the network				
interfore			Check the grounding and network wiring	Replace the network			
interfere			quality	cable			



Error code	Main	Sub	Display: "Er 73b"			
	73	В	Error description: SYNC0 lost			
Cause			Diagnosis	Solution		
Poor master performance				Increase threshold value limit		
Single-unit drive has			Is it a single unit or multiple units together	Switch drive		
Interfere			Check the grounding and network wiring guality cable			

Error	Main	Sub	Display: "Er 73c"		
code	73	С	Error description: Excessive Distributed Clock error		
Cause			Diagnosis	Solution	
Poor master device			Increase threshold value limit		
Single-unit drive has problem			Is it a single unit or multiple units together in the network	Replace driver	
Interfere			Check the grounding and network wiring quality	Replace network cable	

Error	Main	Sub	Display: "Er 801"		
code	80	1	Error description: Unknown communication error		
Cause			CANopen state machine transition failed		
The status of the			All ESM status		
error ca	n be de	tected			
The result status			The current state is maintained below the safe operation, and the operation state is switched to the safe operation state		
Solution			Verify network connection and master device CANopen state machine transition order		

Error	Main	Sub	Display: "Er 802"	
code	80	2	Error description: Memory overflow	
Cause			CPU failed to request memory	
The status of the		е	All ESM status	
error ca	n be de	tected		
The result status		IS	The current state is maintained below the safe operation, and the operation state is switched to the safe operation state	
Solution			Verify if ISV2-CAN hardware is faulty	



Error	Main	Sub	Display: "Er 803"	
code	80	3	Error description: RAM out of bound	
Cause			CANopen state machine memory address access request from master	
			device is out of bound	
The status of the		е	All communication status	
error can be detected		tected		
The result status		IS	NO	
Solution			Verify master device configuration or replace master device	

Error code	Main	Sub	Display: "Er 805"	
	80	5	Error description: FOE firmware upgrade failed	
Cause			Firmware burn error	
The status of the			ВООТ	
error can be detected		tected		
The result status			Remain in the detection state	
Solution	1		Replace firmware/driver	

Error	Main	Sub	Display: "Er 806"	
code	80	6	Error description: Saved ESI file does not match driver firmware	
Cause			ESI file does not match driver firmware	
The status of the		e	INIT	
error can be detected		tected		
The result status			Remain in the detection state	
Solution			Burn matching firmware to driver	
	•		J	

Error	Main	Sub	Display: "Er 811"	
code	81	1	Error description: Invalid CANopen transition request	
Cause			Driver received unconvertible request from CANopen state machine	
The status of the			All ESM Status	
error can be detected		tected		
The result status		IS	The current state is maintained below the safe operation, and the operation state is switched to the safe operation state	
Solutior	1		Verify if the transition information from master device is correct	

Error	Main	Sub	Display: "Er 812"		
code	81	2	Error description: Unknown CANopen state machine transition request		
Cause			Driver receives a transition request other than states of the CANopen		
			state machine		
The status of the			All ESM Status		
error can be detected		tected			
The result status		IS	The current state is maintained below the safe operation, and the operation state is switched to the safe operation state		
Solution			Verify transition information from master device		



Error	Main	Sub	Display: "Er 813"	
code	81	3	Error description: Protection request from boot state	
Cause			Driver receives a transition request to boot state	
The status of the		е	Initialize the conversion to a boot	
error can be detected		tected		
The result status		IS	initialization	
Solution			Verify if driver software version supports this state transition	

Error code	Main	Sub	Display: "Er 814"	
	81	4	Error description: Invalid firmware	
Cause			Firmware not matched with driver	
The status of the			BOOT/INIT	
error can be detected		tected		
The result status			Keeping in the detection status	
Solution			Return driver to supplier to update firmware	

Error code	Main	Sub	Display: "Er 815"
	81	5	Error description: Invalid mailbox configuration under boot state
Cause			Boot state action not supported under current configuration
The status of the			Initialize the conversion to a boot
error can be detected			
The result status			Initialization
Solution			Verify if ISV2-CAN software version supports action under this state.

Error code	Main	Sub	Display: "Er 816"
	81	6	Error description: Pre-Op status is invalid for the mailbox configuration
Cause			The synchronization manager configuration under Pre-Op is invalid
The status of the			pre-operation
error can be detected			
The result status			initialization
Colution			1. Verify if ESI file version is consistent with software version
Solution			2. CANopen slave controller error, please contact technical support

Error code	Main	Sub	Display: "Er 817"
	81	7	Error description: Invalid SyncManager configuration
Cause			Synchronization manager configuration is invalid
The status of the			Pre-op above
error can be detected			
The result status			Pre-op
Solution			Verify master device configuration/ESI file version



Error	Main	Sub	Display: "Er 818"
code	81	8	Error description: No valid input data
Cause			The input data is not updated for more than 1 second
The status of the error can be detected			All ESM status
The result status			The current state is maintained below the safe operation, and the operation state is switched to the safe operation state
Solution			 Verify if TxPDO is valid Verify master device synchronization settings

Error code	Main	Sub	Display: "Er 819"
	81	9	Error description: No valid output data
Cause			Output data is not updated for more than 1 second
The status of the			All ESM status
error can be detected			
The result status			The current state is maintained below the safe operation, and the operation state is switched to the safe operation state
Solution			1. Verify if RxPDO is valid
Solution			2. Verify master device synchronization settings

Error	Main	Sub	Display: "Er 81A"
code	81	Α	Error description: Synchronization error
Cause			RxPDO and DC update order failed or one of them is not updated in sync
The status of the			All ESM status
error can be detected			
The result status			The current state is maintained below the safe operation, and the operation state is switched to the safe operation state
Colution			1. Verify if PXPDO is valid
Solution			2. Verify master device synchronization settings

Error code	Main	Sub	Display: "Er 81b"
	81	b	Error description:SyncManager2 watchdog timer timeout
Cause			The RxPD0 update timeout in operational state
The status of the			operation
error can be detected			
The result status			Safe operation
Colution			1. Verify if ISV2-CAN network is connected
Solution			2. Verify RxPDO update time



Error	Main	Sub	Display: "Er 81c"	
code	81	С	Error description: Invalid SyncManager type	
Cause			Synchronization Manager configuration types other than the following:	
			1. Email output	
			2. Email input	
			3. Process data output	
			4. Process data input	
The status of the			Pre-operation	
error can be detected				
The result status			Initialize	
Solution			Verify if ESI file version is consistent with software version	

Error code	Main	Sub	Display: "Er 81d"
	81	d	Error description: Invalid output configuration
Cause			Process data output synchronization manager configuration is invalid
The status of the			Pre-operation
error can be detected		tected	
The result status			Initialize
Colution			1. Verify ISV2-CAN synchronization manager configuration
Solution			2. Verify if ESI file version is consistent with software version

Error	Main	Sub	Display: "Er 81E"
code	81	Е	Error description: Invalid input configuration
Cause			Process data input synchronization manager configuration is invalid
The status of the			Pre-operation
error can be detected		tected	
The result status		IS	Initialize
Solution			1. Verify ISV2-CAN synchronization manager configuration
Solution	Solution		2. Verify if ESI file version is consistent with software version

Error code	Main	Sub	Display: "Er 821"
	82	1	Error description: Waiting for CANopen state machine Init state
Cause			Driver waiting for master device to send Init request
The status of the			All ESM status
error can be detected		tected	
The result status			Keeping the current state
Solution			Verify transition request sent from master device



Error code	Main	Sub	Display: "Er 822"
	82	2	Error description: Waiting for the CANopen state machine Pre-Op state
Cause			Driver waiting for master device to send Pre-Op request
The status of the			Safe operation, operation
error can be detected		tected	
The result status			Keeping the current state
Solution			Verify transition request sent from master device

Error	Main	Sub	Display: "Er 823"
code	82	3	Error description: Waiting for master device for Safe-Op request
Cause			Process data output synchronization manager configuration is invalid
The status of the			Operation
error can be detected		tected	
The result status			Keeping the current state
Solution			Verify transition request sent from master device

Error code	Main	Sub	Display: "Er 824"
	82	4	Error description: Invalid process data input mapping
Cause			TxPD0 is configured with non-mappable objects
The status of the			Safe operation
error can be detected			
The result status			Pre-operation
Solution			Reconfigure the TxPDO mapping object

Error code	Main	Sub	Display: "Er 825"
	82	5	Error description: Invalid process data output mapping
Cause			RxPDO is configured with non-mappable objects
The status of the			Safe operation
error can be detected			
The result status			Pre-operation
Solution			Reconfigure the RxPDO mapping object

Error code	Main	Sub	Display: "Er 828"
	82	8	Error description: Sync mode not supported
Cause			Sync mode is not supported in the current configuration
The status of the			Safe operation
error can be detected			
The result status			Pre-operation
Solution			1. Verify ISV2-CAN software version
			2. Verify ESI version



Error	Main	Sub	Display: "Er 82b"	
code	82	b	Error description: Invalid inputs and outputs	
Cause			No RxPDO and TxPDO updates for more than 1 second	
The status of the			All ESM status	
error can be detected				
			The current state is maintained below the safe operation, and the	
The result status		15	operation state is switched to the safe operation state	
Colution			1. Verify if current RxPDO and TxPDO are invalid	
Solution			2. Verify master device synchronization settings	

Error code	Main	Sub	Display: "Er 82c"
	82	С	Error description: Fatal synchronization error
Cause			DC watchdog timer timeout
The status of the			Safe operation, operation
error can be detected			
The result status		IS	Safe operation
Solution			1. Verify if ISV2-CAN hardware is faulty
			2. Verify DC setting and delay

Error	Main	Sub	Display: "Er 82d"
code	82	d	Error description: No synchronization error
Cause			Synchronization is invalid
The status of the		e	operation
error can be detected		tected	
The result status		IS	Safe operation
Solution		olution 1. Verify if "fatal synchronization error" has occurred. 2. Verify master device synchronization settings	

Error code	Main	Sub	Display: "Er 82E"
	82	Е	Error description: Synchronization cycle time is too short
Cause			Master device synchronization cycle time is set to less than 125
			microseconds
The status of the			operation
error can be detected		tected	
The result status		IS	Pre-operation
Solution			Verify master device synchronization cycle time

Error code	Main	Sub	Display: "Er 830"
	83	0	Error description: Invalid Distributed Clock synchronization settings
Cause			Synchronization settings in sync mode are not valid
The status of the			Safe operation
error can be detected			
The result status			Pre-operation
Solution			Verify master device synchronization settings



Error code	Main	Sub	Display: "Er 832"
	83	2	Error description: Distribution Clock phase-locked loop failure
Cause			Distribution Clock phase-locked loop setting is invalid
The status of the			Safe operation, operation
error can be detected			
The result status			Safe operation
Colution			Verify master device Distribution Clock settings and network
Solution			transmission delay

Error code	Main	Sub	Display: "Er 835"
	83	5	Error description: Distribution Clock cycle time is invalid
Cause			Set synchronization cycle time is not proportional to drive position loop
The status of the			Safe operation
error can be detected			
The result status			Pre-operation
Solution			Refer to user manual to set a reasonable synchronization cycle time.

Error	Main	Sub	Display: "Er 836"				
code	83	6	Error description: Invalid Distribution Clock synchronization cycle time				
Cause			The synchronization cycle time setting is not as the following				
			1 : 125us 2 : 250us 3 : 500us				
			4 : 750us 5 : 1000us 6 : 2000us				
			7 : 4000us				
The stat	us of th	е	Safe operation				
error can be detected							
The result status Pre-operation			Pre-operation				
Solution	Solution Verify master device synchronization cycle time						

Error	Main	Sub	Display: "Er 850"						
code	85	0	Error description: EEPROM is inaccessible						
Cause			CANopen slave controller failed to access EEPROM						
The status of the		e	All ESM status						
error ca	in be de	tected							
The res	ult statu	IS	Keeping the current state						
Calatian			1. Verify if ISV2-CAN hardware is faulty						
Solution			2. Verify if master device released access						



Error	Main	Sub	Display: "Er 851"				
code	85	1	Error description: EEPROM error				
Cause			EEPROM operation of CANopen slave controller failed				
The stat	us of th	e	All ESM status				
error can be detected							
The result status		IS	Keeping the current state				
Solutior	1		Verify if master device released access				

Error	Main	Sub	Display: "Er 852"				
code	85	2	Error description: Hardware is not ready				
Cause			Data communication lost				
The status of the		е	All ESM status				
error ca	n be de	tected					
The result status			Keeping the current state				
Solution			Verify if ISV2-CAN hardware is faulty				

Error	Main	Sub	Display: "Er 860"				
code	86	0	Error description: CANopen frame lost per unit time exceeds limit				
Cause			CANopen frame lost per unit time exceeds the setting in 2635-00h				
The status of the		e	All states				
error ca	n be de	tected					
The result status		IS	Keeping the detection state				
Solution			Change to network cable with higher bandwidth / Replace driver				

Error	Main	Sub	Display: "Er 870"				
code	87	0	Error description: Driver can't be enabled under current control mode				
Cause			Enable driver under unsupported mode				
The stat	us of th	e	All status				
error ca	in be de	tected					
The result status		IS	Maintain status				
Solution			Switch to the correct control mode				



7.4 Alarm clearing

7.4.1 Servo Drive Alarm Clearing

Clearable Alarm

Please clear alarm using Motion Studio after solving the error by clicking on the "Clear" button. $_{\rm Alarm}$

Current	Current History Cause(s) of motor not rotating									
Device Axis1	Alarm Code Err0B2	Alarm label	Clearable No	Error Level 2	Clear					

Non-clearable Alarm

Please restart drive to clear alarm



Appendix A

Control word 6040H switching under different modes

PP mode (6060h=1)

6040h	15:9	8	7	6	5	4	3	2	1	0
Definition	Null	Stop	Error Reset	Absolute/ Relative Position	Immediate	New set point	Operation allowed	Quick stop	Output voltage	Enable

Control word 6040h under relative position:

$0x06 \longrightarrow 0x07 \longrightarrow 0x0F \longrightarrow 0x4F \longrightarrow 0x5F$											
Output voltage + + Enable + Operation + Relative + New se											
Quick stop		allowed Position				point					
Control word 6040h u	nder absolute	positior	1:								
0x06 ← 0x07 ← 0x0F ← 0x1F											
Output voltage + Quick stop + Enable + Operation allowed + New set point											

Using relative position as an example:

When control word 6040h bit 5 = 0, new set point modified during operation will not take effect immediately. It will only take effect on the next operation through changing control word 6040h bit 4 from 0 to 1.



After new motion parameter is saved and control word 6040h bit 5 = 1, new set point will take effect immediately, stacking the new command on previous command and new operation will be executed according to it.



Before an operation is completed, new motion command is sent to drive, control word 6040h bit 4 will change from 0 to 1 to initiate operation



PV mode (6060h=3)

ī									
	6040h	15:9	8	7	6:4	3	2	1	0
	Definition	Null	Stop	Error Reset	Null	Operation allowed	Quick stop	Output voltage	Enable

Control word 6040h under PV mode:

0x06 ← 0x07 ← 0x0F ← 0x10F ← 0x0F											
Output voltage + Quick stop	+ Enable	+ Operation allowed	+ Stop	Execute							

Homing mode (6060h=6)

6040h	15:9	8	7	6:5	4	3	2	1	0
Definition	NUI	Stop	Error	NUI	Homing	Operation	Quick	Output	Enablo
	Null	Stop	Reset	Null	starts	allowed	stop	voltage	Ellaple

Control word 6040h under homing mode:

0x06				
Output voltage +	+ Enable	+ Operation	+ Homing	Pause
Guick Stop		allowed	Starts	

When drive slave station is in error status, reset error control word 6040h can be sent to change to cancel enabling status:

0x80	
Cancel enabling	



Appendix B

PDO transmission type definition

Transmission code	PDO transmission				
	Cyclic	Non- cyclic	Sync	Not- sync	Remote frame
0		٧	٧		
1~240	V		V		
241~251	Reserved				
252			٧		٧
253				٧	V
254				٧	
255				٧	

Transmission code 1~240: Number of SYNC info between 2 PDO transmissions. Transmission code 252: Data immediately updates after receiving SYNC info

Transmission code 253: Data immediately updates after receiving RTR info

Transmission code 254: Not supported

Transmission code 254: Non-SYNC transmission

Note 1: When PDO transmission = 255 (Non-SYNC), please set suppression time.

When PDO transmission = 1^{240} (SYNC), please set SYNC window duration = SYNC cycle.

Note 2: PDO is used for real time data which needs quick responses, so please only use PDO when necessary; in principle, only 1 RPDO and 1 TPDO will be used in a control mode; Please deactivate PDO if not in used.

Appendix C

Emergency error code

Emergency error code	Description
0000H	No error
8110H	CAN overflow
8120H	Passive error mode
8130H	Lifespan/Heartbeat error
8140H	Forced offline recovery
8141H	Forced offline
8150H	Transmit COB-ID interruption
8210H	PDO exceeded length not processed
8220H	PDO exceeded length



Appendix D

SDO transmission termination code

Termination	Description	
0503 0000H	No alternating changes on trigger point	
0504 0000H	SDO protocol timeout	
0504 0001H	Illegal/unknown command word	
0504 0002H	Invalid module size	
0504 0003H	Invalid sequence no.	
0504 0004H	CRC error	
0504 0005H	RAM overflow	
0601 0000H	Object cannot be accessed	
0601 0001H	Try to read write only object	
0601 0002H	Try to write read only object	
0602 0000H	Object not exist	
0604 0041H	Object cannot be mirrored to PDO	
0604 0042H	Number and length of mirrored object exceed PDO length	
0604 0043H	Parameters not compatible	
0604 0047H	Device not compatible	
0606 0000H	Object access failed due to hardware error	
0606 0010H	Data type not compatible, service parameter length not compatible	
0606 0012H	Data type not compatible, service parameter length too long	
0606 0013H	Data type not compatible, service parameter length too short	
0609 0011H	Sub-index not exist	
0609 0030H	Exceed parameter set range	
0609 0031H	Parameter set value too large	
0609 0032H	Parameter set value too small	
0609 0036H	Max value smaller than min value	
0800 0000H	General Error	
0800 0020H	Data cannot be transmitted or saved to applications	
0800 0021H	Due to local control, data cannot be transmitted or saved to	
	applications	
0800 00224	Data cannot be transmitted or saved to applications due to current	
	device status	
0800 0023H	Object dictionary error or object dictionary doesn't exist	



Appendix E

Drive Function Object

Object dictionary index	Description
3000H	IO signal status
3001H	Status change
3002H	Write EEPROM trigger
3003H	Write EEPROM Status
3004H	Output channel settings
3010H	Servo alarm code
4000H	Clear alarm

Note 1: In PP mode: Send enable command (i.e. 2F/3F) 1st control word 2F to data object 6040h, data object 3001h turns to 0x0020; Drive enters curves planning ready status. Send 3FH to data object 6040h to start motion.

Note 2: Write 0x5A5A to 3002h to trigger EEPROM saving. Back to 0x0000 after saving completed. *Note 3:* Set 3003h to 0x0000 when writing 0x5A5A to 3002h to trigger EEPROM saving; status turns to 0x5A5A after saving completed.

Note 4: Write 0x0001 to 4000h to clear alarm.



Contact Us Leadshine Technology Co., Ltd.

Headquarters

Address: 15-20/F, Block B, Nanshan I Valley, No.3157, Nanshan District, Shenzhen City, Guangdong Province, China Tel: +86 755 26411692 Fax: +86 755 26402718 Website: www.leadshine.com Emails: sales@leadshine.com

Leadshine Global Retailers Network





Motion Control Products Ltd 11-15 Francis Avenue, Bournemouth, Dorset, UK, BH11 8NX Tel.: +44 (0)1202 599922 enquiries@motioncontrolproducts.com www.motioncontrolproducts.com