

UK & Ireland Official Distributor



Solutions in *motion*

FCT CODESYS series

User guide software

Intelligence Production Movement

Ed. 1.2 - English

User guide

FCT CODESYS series

User guide software

Doc. MS392007 Ed. 1.2 - English - 01 Oct 2021

IMPORTANT

Π

CMZ SISTEMI ELET TRONICI S.r.l. reserves the right to make changes to the products described in this document at any time without notice.

This document has been prepared by CMZ SISTEMI ELETTRONICI S.r.l. solely for use by its customers, guaranteeing that at the date of issue it is the most up-to-date documentation on the products.

Users use the document under their own responsibility and certain functions described in this document should be used with due caution to avoid danger for personnel and damage to the machines.

No other guarantee is therefore provided by CMZ SISTEMI ELETTRONICI S.r.l., in particular for any imperfections, incompleteness or operating difficulties.

This document contains confidential information that is proprietary to CMZ SISTEMI ELETTRONICI S.r.l.. Neither the document nor the information contained therein should be disclosed or reproduced in whole or in part, without express written consent of CMZ SISTEMI ELETTRONICI S.r.l..

Table of Contents

. Introduction	1
1.1. Symbols	1
1.2. Revisions	2
. Creation of the first program	3
2.1. Step 1: identify the controller type and its license	3
2.2. Step 2: connection of the supply to the controller	4
2.3. Step 3: installation of FCTTool	4
2.4. Step 4: check of the Ethernet connection with the controller	΄+ Γ
2.5. Step 5: Installation of the package file related to the controleur in	C
CODESYS	7
2.7. Step 7: installation of the package with the libraries	Ċ
2.8. Step 8: creation of the project 1	1
2.9. step 9: establish the communication between CODESYS and FCT 13	3
2.10. step 10: execution of the project on FCT1!	5
. FCT controller functionalities 17	7
FCT controller functionalities 1 3.1. Libraries manuals	7 Э
FCT controller functionalities 1 3.1. Libraries manuals	7 Э)
FCT controller functionalities 1 3.1. Libraries manuals 1 3.2. Controller cloning 20 3.3. Log file 2	7 9) 1
FCT controller functionalities 17 3.1. Libraries manuals 19 3.2. Controller cloning 20 3.3. Log file 21 3.4. Management of the IO modules on FCT640 21	7 9 0 1
FCT controller functionalities 12 3.1. Libraries manuals 14 3.2. Controller cloning 20 3.3. Log file 20 3.4. Management of the IO modules on FCT640 20 3.5. Meaning of the leds of the controller 20 2.5.1 FCT200 and FCT200 20	7 9 0 1 1
FCT controller functionalities173.1. Libraries manuals193.2. Controller cloning203.3. Log file213.4. Management of the IO modules on FCT640223.5. Meaning of the leds of the controller223.5.1. FCT200 and FCT300213.5.2. FCT64021	7 9 0 1 1 2 2
FCT controller functionalities173.1. Libraries manuals193.2. Controller cloning203.3. Log file203.4. Management of the IO modules on FCT640203.5. Meaning of the leds of the controller203.5.1. FCT200 and FCT300213.5.2. FCT640213.6. RESET button24	790111224
FCT controller functionalities173.1. Libraries manuals193.2. Controller cloning203.3. Log file213.4. Management of the IO modules on FCT640223.5. Meaning of the leds of the controller223.5.1. FCT200 and FCT300213.5.2. FCT640223.6. RESET button243.7. RECOVERY button21	7901112245
FCT controller functionalities173.1. Libraries manuals193.2. Controller cloning203.3. Log file213.4. Management of the IO modules on FCT640223.5. Meaning of the leds of the controller223.5.1. FCT200 and FCT300213.5.2. FCT640223.6. RESET button243.7. RECOVERY button21	7901112245
FCT controller functionalities173.1. Libraries manuals193.2. Controller cloning203.3. Log file213.4. Management of the IO modules on FCT640223.5. Meaning of the leds of the controller223.5.1. FCT200 and FCT300223.5.2. FCT640223.6. RESET button243.7. RECOVERY button24FCTTool descritpion	7901112245
FCT controller functionalities173.1. Libraries manuals193.2. Controller cloning203.3. Log file213.4. Management of the IO modules on FCT640223.5. Meaning of the leds of the controller213.5.1. FCT200 and FCT300213.5.2. FCT640223.6. RESET button243.7. RECOVERY button214.1. Installation21	7901112245 77
FCT controller functionalities173.1. Libraries manuals193.2. Controller cloning203.3. Log file213.4. Management of the IO modules on FCT640223.5. Meaning of the leds of the controller223.5.1. FCT200 and FCT300223.5.2. FCT640223.6. RESET button243.7. RECOVERY button244.1. Installation224.1. System requirements21	7901112245 777

4.2.1. Advanced settings for the Scan	30
4.3. Firmware database	
4.4. Firmware management	31

5. CODESYS Development System	35
5.1. Connection to FCT	. 35
5.2. Device FCT	. 37
5.3. The CMZ libraries in the Library manager	. 37
5.4. Driver SoftMotion for CMZ SISTEMI ELETTRONICI S.r.l. drives	. 38
5.5. Copy a file from the controller to the PC	. 39

6.	CMZ	Download	Area		4	1
----	-----	----------	------	--	---	---

7. Advanced functionalities by using Winter-s	43
7.1. Installed CODESYS license and firmware version reading	43
7.2. System log file reading	47
7.3. CMZ cloning procedure	47
7.4. Measurement of the controller free resources	54
7.5. Filesystem Commander	55
7.6. Management of the system in Boot	
	= -

8.	Frequent	questions	59
	8.1. Why is	the controller not visible in the network?	59
	8.2. Which	SD Cards are compatible with the FCT controllers?	59

Chapter 1 Introduction

This document describes the basic notions to develope and manage an application program written in IEC 61131-3 with the CODESYS Development System environment for the FCT cotrollers of CMZ (see *Chapter 5, CODESYS Development System*).

1.1. Symbols



Caution

It shows a dangerous situation, in case of failure to comply with safety rules it can lead to a serious or fatal accident or damage to the equipment.

Warning

It shows a potentially dangerous situation, in case of failure to comply with safety rules it can lead to a serious accident or damage to the equipment.



Important

It shows some important information on the mentioned topic.



Note

It shows some important information on the text about the mentioned topic.



It shows some useful information on the mentioned topic.

1.2. Revisions

	Revision History			
Revision 1.0.0	24/09/2020	Author:	CMZ	SISTEMI
		ELETTR	ONICI S	.r.l.
First revision of the do	cument.			
Revision 1.1.0	14/01/2021	Author:	CMZ	SISTEMI
		ELETTR	ONICI S	.r.l.
English version aligned				
Revision 1.2.0	01/10/2021	Author:	CMZ	SISTEMI
		ELETTR	ONICI S	.r.l.
• Section 8.2, "Which SD	Cards are compatible with the F	CT controlle	rs?": SD (Card model,
suggested by CMZ, ad	ded.			

Chapter 2

Creation of the first program

This chapter provides a guideline that starts with the first turn on of the FCT system and ends with the execution of a first simple application program in the controller, developed with CODESYS Development System (see *Chapter 5, CODESYS Development System*).

Important

During the procedure some softwares must be installed so it is necessary an internet connection in order to download the related installation files.

2.1. Step 1: identify the controller type and its license

Looking the controller from the front side, the one with the connectors, its name can be read, while on the left side face the following information can be found: product order code, serial number, hardware revision, MAC Address of the Ethernet ports.

The order code description is reported in the CMZ SISTEMI ELETTRONICI S.r.l. products catalogue, that can be downloaded from the download area in the Commercial documents section (see *Chapter 6, CMZ Download Area*).

The controller must have a CODESYS license.

Important

A FCT without a CODESYS license can work only in demo mode for a limited period of time. The license can be installed only in CMZ, not in remote mode.

A system with CODESYS license has a silver coloured sticker with a number and the written "CODESYS".

For the realization of a project it is important to be able to obtain 2 information from the order code: the controller type and if the installed CODESYS license if PLC or SoftMotion type:

FCTnnn.mmmm.XXX.aaa

• nnn: controller type: 200, 300, 640;

• mmmm: describes the hardware characteristics;

XXX	CODESYS license description
101	PLC
102	PLC and WebVisu
103	SoftMotion
104	SoftMotion and CNC
105	SoftMotion and WebVisu
106	SoftMotion, CNC and WebVisu

• XXX: CODESYS license type:

• aaa: this field is present only for FCT640. It represents the maximum SoftMotion drives axes number that can be used in the application (see the catalogue for the details).

2.2. Step 2: connection of the supply to the controller

The system is supplied with 24V. In order to select the suitable power supplier and for the connector description it is neccesary to read the hardware manual of the controller, or its short guide. These documents can be downloaded from the download area, in the FCT Series - Product Manuals section (see *Chapter 6, CMZ Download Area*).

2.3. Step 3: installation of FCTTool

FCTTool is a software developed by CMZ SISTEMI ELETTRONICI S.r.l. used find the controller in the network and to manage the firmware files. The installation program can be downloaded from the download area in the FCT series with CODESYS - Tools section (see *Chapter 6*, *CMZ Download Area*).

For further details about the system requirements required to the PC and about the functionalities provided by the tool, see *Chapter 4, FCTTool descritpion*.

2.4. Step 4: check of the Ethernet connection with the controller

In order to be able to program the controller it is necessary to connect to it via Ethernet.

To check that the connection has been properly made and to see the controller IP address, it is necessary:

• to connect the supply to the FCT;

- to connect the Ethernet cable to the controller in ETH for FCT200, ETH 0 for the others. The connection can be made in 2 ways:
 - connection to the company network: on the turn on the server will assign an address to the controller;
 - direct connection to the pc: if, after some minutes, the controller cannot find a server that assigns it an address, it auto-assigns itself the address 172.16.32.1, subnet mask: 255.255.0.0. In this second case the PC communication port must be configured so that it is compatible with the FCT address.
- turn on the FCT;
- launch FCTTool and in the Target locator page the FCT will appear after the button 'Scan' is pressed:



Figure 2.1. FCTTool scan of the network

Π

Important

If the connection is point-to-point between FCT and PC then the answer of the FCT to the network scan may require some minutes. Then it will appear in the list with IP 0.0.0.0 address, is means that it is searching for a server to obtain an address. After some minutes the IP 172.16.32.1 address will be automatically assigned with subnet mask 255.255.0.0. To work with this connection mode, it is advisable to set a static IP address to the controller (see *Section 4.2, "Target locator"*) so that to avoid this waiting time at the turn on.

2.5. Step 5: installation of CODESYS Development System

The CODESYS Development System software allows to program in IEC 61131-3 the FCT controller. The installation file can be directly downloaded from the *CODESYS Store: CODESYS Development System V3* (it will be necessary the registration to the store to download the file).



Figure 2.2. CODESYS Store

2.6. Step 6: installation of the package file related to the controlelr in CODESYS

To realize a program with CODESYS Development System for the FCT controller, the "package" file of the correspondent FCT must be installed. This installation will insert in the CODESYS Development System both the device descriptor file of the controller and the libraries that allow to use the FCT (*Chapter 3, FCT controller functionalities*).

The package file is distributed with the controller firmware, so the firmware file must be downloaded from the download area in the FCT series with CODESYS - Firmware section (see *Chapter 6*, *CMZ Download Area*).

In this section there are the firmwares for: FCT200, FCT300, FCT640. For each controller the last versions that have been distributed for each service pack are reported. Before to be delivered to the customer, the last firmware version of the last service pack is installed in the controller.

Once the firmware file has been downloaded it must be imported in the FCTTool in this way:

- launch FCTTool;
- enter the tab 'Firmware database' and click on the button 'Import' on the bottom:

CMZ Sistemi Elettronici srl - FCT	Tool - Ver. 1.2.0.108		-	- 🗆	
get locator (Firmware database	Firmware managme	nt			
Id	Version	Description			
FCT200					
FCT200_35SP10-0.0.002	0.0.002	Firmware for FCT200 target with 3S CODESYS	3.5.SP10		
FCT200_35SP11-0.0.001	0.0.001	Firmware for FCT200 target with 3S CODESYS	3.5.SP11		
FCT200_35SP7-0.0.003	0.0.003	Firmware for FCT200 target with 3S CODESYS	3.5.SP7		
FCT200_35SP7-0.0.007	0.0.007	Firmware for FCT200 target with 3S CODESYS	3.5.SP7		
FCT200_35SP11-3.5.11.3	3.5.11.3	Firmware for FCT200 target with 3S CODESYS	3.5.SP11		
FCT200_35SP11-0.0.002	0.0.002	Firmware for FCT200 target with 3S CODESYS	3.5.SP11		
FCT200_35SP11-3.5.11.4	3.5.11.4	Firmware for FCT200 target with 3S CODESYS	3.5.SP11		
FCT200_35SP11-3.5.11.5	3.5.11.5	Firmware for FCT200 target with 3S CODESYS	3.5.SP11		
FCT200_35SP11-3.5.11.6	3.5.11.6	Firmware for FCT200 target with 3S CODESYS	3.5.SP11		
FCT300 FCT300_35SP10-0.0.002	0.0.002	Firmware for FCT300 target with 3S CODESYS	3.5.SP10		
FCT300_35SP11-0.0.001	0.0.001	Firmware for FCT300 target with 3S CODESYS	3.5.SP11		
FCT300_35SP7-0.0.007	0.0.007	Firmware for FCT300 target with 3S CODESYS	3.5.SP7		
FCT300_35SP11-0.0.002	0.0.002	Firmware for FCT300 target with 3S CODESYS	3.5.SP11		
ECT300 355P8-0.0.004	0.0.004	Firmware for ECT300 target with 3S CODESVS	2 5 5 00		
		Import	Delete	Refre	sh
scovered 1 devices on 2 is	nterfaces				

Figure 2.3. firmware import

then select the just downloaded firmware file. After this operation the imported firmware will appear in the list;

• enter the 'Firmware management' tab and click on the '...' on the right of the 'Firmware' line (see *Section 4.4, "Firmware management"*):

CMZ Sistemi Elettronici srl - FCTTool - Ver. 1.2.0.108			
Target locator Firmware database Firmware managment			
irmware:			
System undate			
	 		_
Update			
			_
Other operation			
✓ Other operation			
✓ Other operation			
✓ Other operation		 	
✓ Other operation		 	
✓ Other operation			
✓ Other operation		 	
✓ Other operation		 	
✓ Other operation		 	
Other operation		 	
• Other operation			
• Other operation		 	
• Other operation		 	
• Other operation	 	 	
• Other operation		 	
• Other operation		 	
Other operation Observered 1 devices on 2 interfaces		 	

Figure 2.4. firmware selection

at this point the list of the firmwares that are available in the PC appears and, if it is the first installation, will be made only by the just imported firmware. Select the firmware;

• remaining in Firmware management, click on 'Other operation' and then on 'Get File':

🖊 CMZ Sistemi Elettronici srl	FCTTool - Ver. 1.2.0.108				_		>
Target locator Firmware data	oase Firmware managment						
Firmware: FCT640_35SP11-3.5.	1.6						_[
System update							
Target:							
Restart system							
Advanced							
		Update					
Other operation							_
			Get file	Info	Vie	w undat	to
File to extract				inio		.m upuu	iii.
CODESYS Firmware Libraries	Package getfile.codesys.pack	age					
	Ok	Cancel					
	OK	Cancel					

Figure 2.5. extract the package

select 'CODESYS Firmware Libraries Package' and then press OK, then save the file in a folder in the PC;

• in conclusion, execute (double click) the just extracted file that will have the extension *.package.* In the example of FCT640: FCT640_35SP11.package.

A wizard automatically starts: select 'Typical setup' and proceed.

Note

ſMŻ

The package installation can be made even by manually extracting from the .zip file of the firmware the eackage file and then executing it. The advantage to follow the described procedure is that it inserts the downloaded firmware in the FCTTool's database so that it can be easily recovered and used in the future.

2.7. Step 7: installation of the package with the libraries

These are the libraries that expand the CODESYS functionalities (see *Chapter 3, FCT controller functionalities*). Can be downloaded from the download area in the FCT series with CODESYS - Libraries section (see *Chapter 6, CMZ Download Area*):



Figure 2.6. libraries download

the downloaded file is a zip.

Launching the CMZ_Libraries.package file contained in the zip, the package installation procedure starts: select 'Typical setup' and execute it 'till the conclusion.





Lauch the CODESYS Development System program, normally the installation creates the icon directly on the desktop.

From the initial page click on 'New Project': it appears a window that requires to select the project type to be created. Select:

- Categories: Project;
- Templates: Standard project.

		<u>T</u> emplates				
Proj	iries ects	Empty project	HMI project	Standard project	Standard project wi	
A project co	ontaining one device, or	ne application, and an e	empty implement	tation for PLC	_PRG	
	Untitled1					
<u>N</u> ame						~
<u>N</u> ame <u>L</u> ocation	D:\Tests\					

Figure 2.7. Standard project

The a second window appears, that is used to select the device type for which the project has been creating. It must be searched in the list the one that corresponds to the FCT that is in use (*Section 2.1, "Step 1: identify the controller type and its license"*). there will be two possibilities (for example for FCT640):

- FCT640 Fieldbus Controller: Standard PLC (CMZ Sistemi Elettronici): select this option if in the FCT it is installed the PLC license (see *Section 2.1, "Step 1: identify the controller type and its license"*);
- FCT640 Fieldbus Controller: SoftMotion (CMZ Sistemi Elettronici): select this option if in the FCT it is installed the PLC SoftMotion license (see *Section 2.1, "Step 1: identify the controller type and its license"*).

EMZ

Standard	Project		2
	You are about within this pro - One program - A program Pl	to create a new standard project. This wizard will create the following objects oject: nmable device as specified below .C_PRG in the language specified below	
	- A cyclic task - A reference t Device	which Calls PLC_PRG o the newest version of the Standard library currently installed. FCT640 Fieldbus Controller: SoftMotion (CMZ Sistemi Elettronici)	~
	PLC_PRG in	Structured Text (ST)	~

Figure 2.8. select the FCT device

This procedure brings to the creation of a project with an empty application:

Untitled1.project* - CODESYS			-	
File Edit View Project Build Online Debug Tools Windo	w Help Automation Server			
自 🖻 🔲 🗠 🗠 🌡 🖻 🛍 🗙 🖪 🌿 📕 🧐 🦄 🦄	🖥 👘 📄 🛗 🛛 Application [De	evice: PLC Logic] 🝷 👒 🚳	- * (12 91 41 41 81	
Devices – A X				
Untitled1				
Device (FCT640 Fieldbus Controller: SoftMotio				
E B PLC Logic				
- O Application				
👘 Library Manager				
PLC_PRG (PRG)				
E 💹 Task Configuration				
🖮 🍪 Main Task				
PLC_PRG				
- 🍐 SoftMotion General Axis Pool				
HBUS_Master (HBUS Master)				
POUs				
Messages - Total 0 error(s), 0 warning(s), 0 message(s) S Cross Reference Lis	st 💹 Watch 1			
	Last build: 😳 0 😗 0	Precompile 🗸 🛛 🦓	Project user: (nobody)	

Figure 2.9. empty project

Select PLC_PRG that is the IEC 61131-3 program in structured text and insert the code as showed in the figure (a simple counter):



Figure 2.10. first project

2.9. step 9: establish the communication between CODESYS and FCT

In order to download the just written program in the FCT it has to be opened first the communication between CODESYS Development System and FCT. To do this, click on 'Scan Network' in the Communication Settings tab in Device:

Doc. MS392007 - Ed. 1.2 - 01 Oct 2021

ſMZ

Device x Communication Settings Communication Settin	<u>E</u> ile <u>E</u> dit <u>V</u> iew <u>P</u> roject 管 🚅 🔲 🖨 🗠 여 🐰 🐚	Build Online Debug Tools Wind 🗈 🗙 🏘 🎲 🐴 🏠 🚺 🗍 🧌 🕷 🦄 🎼	ow Help Automation Server Help <u>1</u> Application [Device: PLC Log	gic] • 👒 👒 🕞 🔳 🔏 🕻	11111111111111111111111111111111111111	#a ≓
	Devices • 4 × Devices • 4 × Outcled2 Device (FCT640 Field Device (FCT640	A value of the second se	twork Gateway • Device •	ateway		

a page is opened, where the FCT can be seen:

	Device Name:
Gateway-1	FCT640
ECT640[00:0D:E2:00:30:8D][0000.2192]	[00:0D:E2:00:30:8D] <u>W</u> ink
	Device Address: 0000.2192
	Block driver:
	Number of channels: 4
	Serial number: BOARDSN=105
	Target ID: 10F7 000D
	Target Name: CMZ target
	Target Type: 4102
	Target Vendor: CMZ Sistemi Elettronici
	Target Version: 3.5.11.7

Figure 2.12. network scan

Once the controller is selected ad 'OK' has been clicked, the communication is established:



Figure 2.13. communication established

2.10. step 10: execution of the project on FCT

At this point, to download the project in FCT, press Login:



The project is compiled and downloaded in the controller and at the end the controller will be in this situation:

Devices - II Y							
State Intitled 1	Device.Application.PLC_PRG						
응 · 이 데 Device [connected] (FCT640 Fieldbus C 응 데 PLC Logic · · · · · · · · · · · · · · · · · · ·	Expression	Type DINT	Value 0 0 + 1;RE	Prepared value	Address	Comment	
							1
	Watch 1 Expression	Application	Туре	Value	Prepared val	ue Execution point	

Figure 2.15. program in stop

By pressing Start (or F5) the program starts to be executed and the counter starts to increase:

Devices 👻 🕂 🕈	K Device PLC_PRG X			Start (F	5)		
Juntitled1	Device.Application.PLC_PRG						
 ⇒ ∰ Device [connected] (FCT640 Fieldbus ⇒ ∰ PLC Logic ⇒ Ø Application [run] 	C Expression Counter	Type DINT	Value Pr 61	repared value	Address C	omment	
Burger Manager DL2PRG (PRG) Set Start St	2 counter 61]:= counter 6	1 + 1;[RETU	ÎNN			
							100
	vvacch 1		_	Value	Prepared value	Execution point	
	Expression	Application	Type				



Chapter 3 FCT controller functionalities

The FCT controller is a device that can be programmed in IEC 61131-3 with the development environment CODESYS Development System (see *Chapter 5, CODESYS Development System*).

Important

FCT requires a CODESYS license. In *Section 2.1, "Step 1: identify the controller type and its license*" it is described how to verify the installed license from the order code.

The license in the controller can be read even from CODESYS Development System (see *Chapter 5, CODESYS Development System*) by reading the log in the device object.

Furthermore the license can be read with the advanced functionalities (see *Chapter 7, Advanced functionalities by using Winter-s*) in the *Section 7.1, "Installed CODESYS license and firmware version reading"*.

Some application programs can be realized to manage:

- devices connected to a CANopen network: input/output modules DS401, encoder DS406, drive DSP402 with the use of SoftMotion driver of CODESYS;
- devices connected to an EtherCAT network: input/output modules DS401, encoder DS406, drive DSP402 with the use of SoftMotion driver of CODESYS;
- serial and TCP communication protocols as Modbus for the data conversion and to use HMI.

CMZ SISTEMI ELETTRONICI S.r.l. provides even these libraries:

- libraries that allow to use the hardware and software peculiarities of FCT (for example to manage the modules connected to the HBUS of FCT640, or to manage the FTP server present in the controller);
- libreries to expand the functionalities provided by CODESYS.

The libraries that allow to use the hardware and software peculiarities of FCT are distributed with the firmware file (see *Section 2.6, "Step 6: installation of the package file related to the controlelr in CODESYS"*). The libraries are:

- CMZ Ftp Server: allows to enable and manage an FTP server connection in the controller. This allows to access to the controller memory for the exchange of files;
- FCT series utilities: it is a collection of functions that allow to manage special or specific modes of the controllers FCT.
- CMZ LBUS: on the FCT300 and FCT200 controllers allow to manage the communication with the LOCAL IO board that connects to the SMI port of the controller. The LOCAL IO board manages digital inputs and outputs;
- CMZ Ethernet Ip Slave: in the FCT300 controller allows to manage the EtherNet/IP Slave expansion module;
- CMZ Profibus DP Slave: in the FCT300 allows to manage the Profibus DP Slave expansion module;
- CMZ HBUS: on the FCT640 controller allows to manage the TB20 modules connected to the system.

The libraries to expand the CODESYS functionalities are distributed in a package (see *Section 2.7, "Step 7: installation of the package with the libraries"*). The libraries are:

- CMZ Axes Interpolation: it allows to realize synchronized movements of several axes SoftMotion that follow a profile developed on an XY or XYZ plane.
- CMZ Electronic Cams: it allows to realize synchronized movements of several slave axes SoftMotion that follow a master respecting a cam table.
- CMZ Flying Shear: it allows to manage the on-the-fly cut application;
- CMZ MACISO: it allows to manage the synchronized movement of more axes SoftMotion that follow a profile described with an ISO program;
- CMZ TSC: it allows to directly manage the TSC CANopen board for the motion of motors;
- CMZ Modbus: it manages the controller as a Modbus master or slave, both TCP and RTU;
- CMZ Node Utilities: it provides some functions to manage the firmware, parameters file and IEC application update in the CANopen nodes and EtherCAT slave of CMZ;
- CMZ Basic utilities: it provides some useful functions for the application development;
- CMZ_Fieldbus bridge: it provides some functions to manage the SDSetup tool directly with the Ethernet debug connection with the controller. It offers the possibility to access to all the devices that use SDSetup without the direct serial connection.

• CMZ WebServer: it provides some functions to manage a web server in the controller directly from IEC application.

Each library has its own manual (see Section 3.1, "Libraries manuals").

3.1. Libraries manuals

EMZ

Each library has its own manual that describes its functionalities, it can be found in two ways:

• in the Library manager: for example for the CMZ Electronic Cams si trova il pdf CMZ_Cam library



Figure 3.1. CMZ manuals

• in the help of CODESYS Development System (see *Chapter 5, CODESYS Development System*) installed in the PC, not in the web one. To access the help that is installed in the PC, from CODESYS Development System, access to Tools - Option - Help and deactivate the option 'Use Online Help if available'. After this operation, by lounching the CODESYS Help, in the chapter Libraries a section dedicated to the CMZ libraries can be found:



Figure 3.2. CMZ manuals



3.2. Controller cloning

This function allows to clone a system in another one of the same type.

There are two ways to do it::

- by using the functionality in the 'Device' tab -> 'Backup and Restore' of CODESYS Development System (see Chapter 5, CODESYS Development System);
- by using a functionality that is inserted in the controller by CMZ.

The main differences between the two modes are:

- the second mode allows to clone even the firmware that is installed in the controller, while the first one does the backup only of the files related to the application.
- the second mode allows to clone even without having a PC with CODESYS installed.

For the description of the first mode (CODESYS Backup and Restore procedure), refer to the environment manual of CODESYS Development System (see *Chapter 5, CODESYS Development System*).

For the description of the second mode, continue reading: Section 7.3, "CMZ cloning procedure".

3.3. Log file

CODESYS Development System (see *Chapter 5, CODESYS Development System*) provides an information report in the Log tab of the FCT device.

In the controller it is saved even a Log file that stores other information that can be useful to know the history and even to search eventual error situations. The file is PpcLog.txt and can be found in B:. It can be copied from CODESYS Development System as described in *Section 5.5, "Copy a file from the controller to the PC"*, or by using the advanced functionalities (see *Chapter 7, Advanced functionalities by using Winter-s* and *Section 7.2, "System log file reading"*).

3.4. Management of the IO modules on FCT640

The FCT640 controller is a modular system to which some modules with different functionalities can be connected: digital and analogic inputs and outputs, counters (see the Peripherals I/ O Modules section in the catalogue).

The management of the modules in a CODESYS program is described in the CMZ_HBUS library manual. This library is distributed with the formware of the FCT640 system.

The description of the modules is reported in the TB20_Modules_UserGuide manual that can be found in the download area of CMZ (*Chapter 6, CMZ Download Area*).

When the modules management is active, the OK/BF, SF leds take the meaning that is described in *Section 3.5, "Meaning of the leds of the controller"*.

3.5. Meaning of the leds of the controller

There are some differences between the controllers.



Refer even to the hardware manual of the controller or to the short guide.

3.5.1. FCT200 and FCT300

There are some leds that report some information about hte controller status.

- Rs:
 - green: the CPU is on and is working.
 - orange: the controller is in reset.
- FAULT: indicates if there is an error situation in the controller:
 - off: no problem;
 - orange: controller in Boot;
 - red on: system software update in progress;
 - blinking red: the number of blinks reports the error reason:
 - 2 blinks: RTC Clock internal not set or its backup battery out of power;
 - 3 blinks: HW initialization error (Ethernet and other);
 - 5 blinks: hardware error in a controller expansion board;
 - blinking green for as few seconds: controller identification in progress: in CODESYS Develop System the Wink button (*Section 5.1, "Connection to FCT"*) has been clicked, or in FCTTool has been clicked the Identify button (*Section 4.2, "Target locator"*).
- SD:
 - off: SDCard not inserted;
 - blinking red: the controller is accessing in reading or writing to the SDCard;
 - orange: it has been happened a current overload. Remove the SDCard.

Each Ethernet port has a led that indicates if the communication is active.

3.5.2. FCT640

There are some leds that report some information about hte controller status.

• OK/BF: its meaning changes according to the management of the modules that are connected to the controller. If the program does not manage the modules then the steady on blue light indicates that the cpu is correctly working. If the program manages the modules then:

- off: at the FCT start-up the light remains off for some seconds;
- blinking blue: the management of the modules is in initialization phase;



- red: at least one module is in error and has provided a diagnostic report;
- blue on: the management of the modules is correctly running.
- SF: it has meaning when the management of the modules that are connected to the controller is active:
 - off: no problem;
 - blinking yellow: in the bus a module is missing, compared to the configuration described in the project;
 - yellow on: in the bus a module is wrong, compared to the configuration described in the project, or a module is not CMZ SISTEMI ELETTRONICI S.r.l.;
- FAULT: indicates if there is an error situation in the controller:
 - off: no problem;
 - orange: controller in Boot;
 - red on: system software update in progress;
 - blinking red: the number of blinks reports the error reason:
 - 2 blinks: RTC Clock internal not set or its backup battery out of power;
 - 3 blinks: HW initialization error (Ethernet and other);
 - 4 blinks: overtemperature reached;
 - blinking green for as few seconds: controller identification in progress: in CODESYS Develop System the Wink button (*Section 5.1, "Connection to FCT"*) has been clicked, or in FCTTool has been clicked the Identify button (*Section 4.2, "Target locator"*).
- SD:

- off: SDCard not inserted;
- blinking red: the controller is accessing in reading or writing to the SDCard;
- orange: it has been happened a current overload. Remove the SDCard.
- Link2: communication status on ETH2. Off means no communication, while blinking green means that the communication is active;
- Link1: communication status on ETH1. Off means no communication, while blinking green means that the communication is active;
- Link0: communication status on ETH0. Off means no communication, while blinking green means that the communication is active;

3.6. RESET button

The RESET button allows to put the controller in Boot by stopping the execution of the program and of the firmware.

Note

This operation should never be necessary, but can be useful in extreme cases to stop critical error situations in which the controller continuously reboots. When the system is in Boot some advanced operations can be executed that allow, for example, to delete the application program: see *Chapter 7, Advanced functionalities by using Winter-s* in the *Section 7.6, "Management of the system in Boot*".

In the FCT200 and FCT300 controllers the button is above the RS, FAULT and SD leds and is indicated with RES.

In the FCT640 controller it is on the bottom between the connector X2 ETH0 and X1 24V, it is the button over, named RESET.

To push this button it has to be used a pointed tool (diameter < 0,8 mm) and, before to release it, wait that the FAULT led remains steady on. The button pushing is not easy in order to avoid that the controller is accidentally put in Boot.

Warning

If pushed during the functioning it interrupts any procedure/activity on FCT and on consequence on all the devices and I/O modules managed by it. Verify that the reset request does not determine a risk for the safety of the people or for the damaging of the machine or for the data loss.

3.7. RECOVERY button

This button is present only on the FCT640 controllers.

This button is used to delete the application (formatting the File System: application, parameters, user file, ...), while the firmware and the license are not deleted. This operation can be executed even by using CODESYS Development System, or with the advanced functionalities (see *Chapter 7, Advanced functionalities by using Winter-s*), eventually after the pushing of RESET button (see *Section 3.6, "RESET button"*).

The RECOVERY button allows to restore the controller to the initial status without the necessity of any connection with a PC.

The "RECOVERY" sequence, here after reported, is intentionally complicated, in order to avoid that the application deletion is made by error and/or in a not-awared way.

- 1. put the controller in the Boot status by pushing the RESET button and waiting that the third led "FAULT" remains steady on;
- 2. press and hold the button RECOVERY until all the leds turn on, then release it;
- 3. push the RECOVERY button 3 times with an interval of 2 seconds between every push (in this phase the lowest led corresponds to the button status: it turns on when the button is pushed. Wait the led light every time before to release the button);
- 4. push the RECOVERY button a fourth time an hold it down until all leds turn on, then release the button;
- 5. after about 10 seconds the installed application is deleted. The leds blinking will get faster, to indicate the deletion approaching. The procedure can be interrupted before the time elapses, by cutting the system supply (turn off).

Chapter 4 FCTTool descritpion

FCTTool is a program for Windows PC that provides the following functionalities:

- to find a FCT controller in the network;
- to set the Static IP address of the FCT controller;
- to create a CODESYS firmware database for the FCT controllers;
- to update the firmware FCT controllers;
- to extract from the firmware the package with the device descriptor of FCT and the libraries dedicated to the FCT in order to insert them in the CODESYS Development System (*Section 2.6, "Step 6: installation of the package file related to the controlelr in CODESYS"*).
- to execute some activities for expert users by starting the Winter-s terminal.

4.1. Installation

The installation program can be downloaded from the download area of CMZ (*Chapter 6, CMZ Download Area*) in the FCT series with CODESYS - Tools section.

4.1.1. System requirements

The software requires a PC with at least Windows 7 and the .Net Framework 4.5 software, if not already installed.

4.2. Target locator

By clicking on the **Scan** button the network scan to find the FCT controllers is started:

Name	Address	MAC	Switch	Interface	Serial number	HW revision	Erro
FCT640 1024MBR (FCT64	0) 172.16.34.220	00:0d:e2:00:30:7d	1	172.16.2.105	101	3	
🚖 1024MBR (FCT64	0) 172.16.33.146	00:0d:e2:00:30:8d	1	172.16.2.105	105	3	
1024MBR (FCT64	0) 172.16.33.100	00:0d:e2:00:30:b1	1	172.16.2.105	114	3	
854MBR (FCT300 854MBR (FCT300 FCT200 FCT200	172.16.2.72	00:0d:e2:00:0e:19	0	172.16.2.105	337043	10	
SZUMBR (FC1200	172,10,32,20	00:00:e2:00:00:ab	Scan	Identi	fy Config	gure Te	ermin
Discovered 7 devi	iscovered 7 devices on 2 interfaces						

Figure 4.1. Target locator

The FCT controllers are grouped by type and each line reports the following information:

• Name: the controller motherboard name is reported and, between barentheses, the commercial name. In this context, to refer to the FCT it is always used the commercial name;



- Address: IP address of the system;
- MAC: MAC address of the Ethernet port to which the controller is connected;
- Switch: it indicates if the FCT has a static IP address (value =1), or if its address is assigned on DHCP, that means by a server at the turn on (value =0);
- Interface: IP address of the PC on which the Scan is being executed;
- Serial number: serial number of the FCT;
- HW revision: hw revision of the FCT;
- Error: eventual error reports.

• In the window below the report of the information related to the Scan procedure is reported.

န Note

EMZ

Even in CODESYS Development System (*Chapter 5, CODESYS Development System*) in the Device - Communication Settings - Scan Network (see *Section 5.1, "Connection to FCT"*) it is possible to execute the network scan in order to search the FCT controllers. This network Scan, by default, reports only the ones that are compatible with the developing project, or rathed coherent with the Device, both for the FCT type and for the license.

The **Identify** button can be used to identify a particular FCT: select the controller in the list and click on the Identify button, in this way the correspondent controller will start to make the Fault led bilnking green. This allows to verify to be connected to the right controller before to execute any operation.



Even in CODESYS Development System (*Chapter 5, CODESYS Development System*) in Device - Communication Settings - Scan Network (see *Section 5.1, "Connection to FCT"*) by using the Wink button, it is possible to execute the same system identification.

The **Configure...** button allows to set the IP address assignment mode for the FCT. By selecting the controller and clicking on the button a new window opens:

IPAddressProperti	es	- 🗆 ×
○ Obtain an IP addr ● Use the followir	ess automatically g IP address	IP address can be obtained automatically using DHCP or specified explicitly. Using DHCP is preferred if it
IP address:	172.16.33.146	is available.
Subnet mask:	255.255.0.0	If after selecting DHCP mode, the IP
Default gateway:	0.0.0.0	address in the device list is 0.0.0
		then a DHCP server is not available.
		Ok Cancel

Figure 4.2. IP address configuration

By selecting *Obtain an IP address automatically* the IP address is assigned by the DHCP server at the turn on. Otherwise, if *Use the following IP address* is set, then IP address and Subnet mask have to be manually set and FCT, after a reboot, will take these settings in static mode. In this case even a gateway can be set.

Returning the scan page and clicking on the **Terminal** button, a new window opens: Winter-s, with the pages with a blue background. It allows to execute some advanced operations, only for expert users. See *Chapter 7, Advanced functionalities by using Winter-s*.

Ι Important Winter-s is correctly started if FCT and PC are on the same network: in other words, the IP address of the FCT and of the PC have the same numbers in the Subnet Mask. In case of problems one of the two addresses must be modified. Note If by clicking Terminal black page with on а coma mand prompt ('>') opens, it means that the system is in Boot. Contact support@cmz.it. See Chapter 7, Advanced functionalities by using Winter-s in the Section 7.6, "Management of the system in Boot".

4.2.1. Advanced settings for the Scan

In the Target locator tab, on the top, there is a menu **Advanced settings** that allows to modify the scanning mode:

🧈 CMZ Sistem	ni Elettronici srl - FCT	Fool - Ver. 1.2.0.108			_	\times
Target locator	Firmware database	Firmware managment				
Advanced	d settings					
Broadcast			Interface:			
O Direct bro	adcast with subnet ma	ask	Timeout (n	ns):		
O Direct bro	adcast with custom m	ask Mask:				



- Broadcast: (default setting) the controllers are searched in all the networks connected to the PC;
- Direct broadcast with subnet mask: only the controllers in the local subnet, that is the subnet mask of the local network, are searched;
- Direct broadcast with custom mask: only the controllers in the network with the subnet mask that is indicated in the Mask field are searched;
- Interface: it allows to specify the interface on which to do the controller research.
- Timeout (ms): how long to wait the controller answer.

4.3. Firmware database

In the Firmware database tab the firmwares that have been downloaded from the download area of CMZ (*Chapter 6, CMZ Download Area*) in the FCT series with CODESYS - Firmware section (see *Section 2.6, "Step 6: installation of the package file related to the controlelr in CODESYS"*) can be imported:

arget locator	Firmware database	Firmware managmen	t
Id		Version	Description
ECT200			
ECT200 355	P10-0.0.002	0.0.002	Firmware for ECT200 target with 3S CODESVS 3.5 SP10
ECT200_355	P11-0.0.002	0.0.002	Firmware for ECT200 target with 35 CODESVS 3.5.5P10
FCT200_355	P7-0.0.003	0.0.001	Firmware for FCT200 target with 35 CODESVS 3 5 SP7
FCT200_355	P7-0.0.007	0.0.007	Firmware for FCT200 target with 3S CODESYS 3.5.SP7
FCT200_35S	P11-3.5.11.3	3.5.11.3	Firmware for FCT200 target with 3S CODESYS 3.5.SP11
FCT200_355	P11-0.0.002	0.0.002	Firmware for FCT200 target with 3S CODESYS 3.5.SP11
FCT200 35S	P11-3.5.11.4	3.5.11.4	Firmware for FCT200 target with 3S CODESYS 3.5.SP11
FCT200 35S	P11-3.5.11.5	3.5.11.5	Firmware for FCT200 target with 3S CODESYS 3.5.SP11
FCT200_35S	P11-3.5.11.6	3.5.11.6	Firmware for FCT200 target with 3S CODESYS 3.5.SP11
ECT200			
ECT200 255	P10-0.0.02	0.0.002	Firmware for ECT200 target with 25 CODESVS 2.5 SD10
FCT200_255	P11-0.0.002	0.0.002	Eirmware for ECT200 target with 25 CODESYS 3.5.5PT0
ECT300_355	P7-0.0.007	0.0.007	Firmware for FCT300 target with 35 CODESVS 3 5 SP7
FCT300_355	P11-0.0.007	0.0.007	Firmware for ECT300 target with 35 CODESVS 3.5.57
FCT300_355	P8-0.0.004	0.0.002	Firmware for FCT300 target with 35 CODESVS 3 5 SP8
ECT300_355	P11-3 5 11 3	3 5 11 3	Firmware for FCT300 target with 35 CODESVS 3 5 SP11
FCT300 355	P11-3.5.11.4	3.5.11.4	Firmware for FCT300 target with 3S CODESYS 3.5.SP11
FCT300 355	P11-3.5.11.5	3.5.11.5	Firmware for ECT300 target with 3S CODESVS 3.5.SP11
FCT300_35S	P11-3.5.11.6	3.5.11.6	Firmware for FCT300 target with 3S CODESYS 3.5.SP11
FCT640			Ē
FCT640 355	P11-0.0.002	0.0.002	Firmware for FCT640 target with 3S CODESYS 3.5.SP11
FCT640_35S	P11-3.5.11.3	3.5.11.3	Firmware for FCT640 target with 3S CODESYS 3.5.SP11
FCT640_35S	P11-3.5.11.4	3.5.11.4	Firmware for FCT640 target with 3S CODESYS 3.5.SP11
FCT640_35S	P11-3.5.11.5	3.5.11.5	Firmware for FCT640 target with 3S CODESYS 3.5.SP11
FCT640_35S	P11-3.5.11.6	3.5.11.6	Firmware for FCT640 target with 3S CODESYS 3.5.SP11
		ł	
			Import Delete Re

Figure 4.4. Firmware database

4.4. Firmware management

In the Firmware management tab some operations with the CODESYS firmware it is possible:

• to extract the package to be installed in CODESYS, realized for the particular firmware (see *Section 2.6, "Step 6: installation of the package file related to the controlelr in*

CODESYS"). Once it has been extracted, to install it it is sufficient to launch the *.package file.

In this package there are:

- the device descriptor files that describe the FCT both with PLC and SoftMotion license;
- the system libraries developed to completely manage the FCT controllers, each one with its own personalizations.

After the package installation (see Section 2.6, "Step 6: installation of the package file related to the controlelr in CODESYS") it is possible to find the FCT (Section 5.2, "Device FCT") in the CODESYS Development System in the Device list and the installed libraries (Section 5.3, "The CMZ libraries in the Library manager") in the LibraryManager, in the Application - CMZ section.

• to install the firmware in the controller:

Important

Before to do this operation it is important to know that the CODESYS application program is developed for a particular Device and firmware version, so:

- if the firmware is changed before the application has been deleted, it may happen that at the end of the update the "old" application causes malfunctions in the machine or even that produces an error in the controller. It is so strongly recommended to delete the application from CODESYS CODESYS - Online - ResetOrigin before to update the firmware;
- if the project is under development, then once the firmware is updated in the controller the Device FCT version must be aligned in the project. It has to be used Updater Device (see help of CODESYS).

The firmware update procedure can be executed:

- to install the last firmware version;
- to install a particular firmware version that is required by the application, that will be downloaded in the controller, that is because the device descriptor version of the project Device must be the same of the firmware version in the controller.

Before to execute the procedure it is possible to check the version of the firmware installed in the controller in one of the following modes:

• from CODESYS Development System, after making the Scan Network (see *Section 5.1, "Connection to FCT"*), by selecting a FCT, in the box on the right of the window several characteristics are provided: **Target Version** id the firmware version;

• from Winter-s as described in *Section 7.1*, "Installed CODESYS license and firmware version reading".

The firmware installation procedure is the following:

ſMZ

• click the '...' button on the right of the Firmware line, so an imported firmware list will appear to select the desired one:

CMZ Sistemi Elettronici srl - FCTTool - Ver. 1.2.0.108		-	×
Target locator Firmware database Firmware managment			
Firmware:			
System update			
Target:			
✓ Restart system			
Advanced			
Update			
• Other operation			_
iscovered 1 devices on 2 interfaces			
Figure 4.5. firmware selection	ı		

- click the '...' button on the right of the Target line, so a window equal to the Target locator tab will appear, from here it is possible to select the controller to be updated;
- click on Update;
- during the procedure a bar that indicates the operation in progress appears, furthermore on the bottom of the FCTTool window it is possible to read the commands under execution;
- at the end of the procedure the system is rebooted;
- in case it is not already be done, install the package related to the firmware that is installed in the PC (see *Section 2.6, "Step 6: installation of the package file related to the controlelr in CODESYS"*).

Chapter 5 CODESYS Development System

CODESYS Development System is a software developed and distributed by *CODESYS*. This software allows to create a project with the programming language IEC 61131-3 and to download it in the FCT to be executed.

The software can be directly downloaded from the CODESYS store: *CODESYS Development System V3* (it will be necessary the registration to the store to download the file).

The installation and the execution are free and don't require any license.

In the Chapter 2, Creation of the first program it is described how to write the first program.

5.1. Connection to FCT

In Device - Communication Settings - Scan Network

elect the Network Path to the Controller	
= 🦂 Gateway-1	Device Name: Scan Network ECT640
FCT640 [00:0D:E2:00:30:7D] [0000.22DC]	[00:0D:E2:00:30:8D Wink
FCT640 [00:0D:E2:00:30:8D] [0000.2192]	
□ [1] FCT640[00:0D:E2:00:30:B1][0000.2164]	Device Address: 0000.2192
	Block driver: UDP
	Number of channels: 4
	Serial number: BOARDSN=105
	Target ID: 10F7 000D
	Target Name: CMZ target
	Target Type: 4102
	Target Vendor: CMZ Sistemi Elettronici
	Target Version: 3.5.11.7
	· · · · · · · · · · · · · · · · · · ·

Figure 5.1. Scan Network

This list, by default, reports only the FCT that are compatible with the developing project, or rathed coherent with the Device, both for the FCT type and for the license.

The information related to the selected FCT can be read. The most important are for sure:

• Device Name that reports even the MAC address of the port with which the controller is connected.



- Serial number: FCT serial number;
- Target Version: CODESYS firmware version that is running in the FCT.

The **Wink** button allows to execute a controller identification procedure: select the controller from the list and click the Wink button, the corresponding controller will start to make the Fault led bilnking green. In this way it is possible to verify to be connected to the correct FCT before to download the project.



Note

This procedure is the same that starts with the Identify button of Target locator (*Section 4.2, "Target locator"*).

5.2. Device FCT

After to have installed the package related to the desired FCT (see *Section 2.6, "Step 6: installation of the package file related to the controlelr in CODESYS"*) even the corresponding FCT will be present in the available Devices list. For example after the installation of the packages of FCT200, FCT300, FCT640 with firmware version 3.5.11.6 there will be:

Vendor		Version	Description
CMZ Sist	emi Elettronici	3.5.11.6	FCT200 Fieldbus Control
CMZ Sist	emi Elettronici	3.5.11.6	FCT300 Fieldbus Controll
CMZ Sist	emi Elettronici	3.5.11.6	FCT640 Fieldbus Control
CMZ Sist	emi Elettronici	3.5.11.6	FCT200 Fieldbus Control
CMZ Sist	emi Elettronici	3.5.11.6	FCT300 Fieldbus Control
CMZ Sist	emi Elettronici	3.5.11.6	FCT640 Fieldbus Control
	CMZ Sist CMZ Sist CMZ Sist CMZ Sist CMZ Sist	CMZ Sistemi Elettronici CMZ Sistemi Elettronici CMZ Sistemi Elettronici CMZ Sistemi Elettronici CMZ Sistemi Elettronici	CMZ Sistemi Elettronici3.5.11.6CMZ Sistemi Elettronici3.5.11.6CMZ Sistemi Elettronici3.5.11.6CMZ Sistemi Elettronici3.5.11.6CMZ Sistemi Elettronici3.5.11.6

Figure 5.2. Device repository with the different FCTs

5.3. The CMZ libraries in the Library manager

After the installation of the packages related to the firmware and to the libraries, the libraries that have been developed by CMZ can be used. In the Application - CMZ section can be found:

tring for a fulltext search	
Library	Company
Application	
E CMZ	
🕒 CMZ Axes Interpolation	CMZ Sistemi Elettronici
	CMZ Sistemi Elettronici
CMZ Electronic Cams	CMZ Sistemi Elettronici
	CMZ Sistemi Elettronici
CMZ FCT series Utilities	CMZ Sistemi Elettronici
	CMZ Sistemi Elettronici
🕒 CMZ Flying Shear	CMZ Sistemi Elettronici
	CMZ Sistemi Elettronici
CMZ HBUS	CMZ Sistemi Elettronici
CMZ LBUS	CMZ Sistemi Elettronici
CMZ MACISO	CMZ Sistemi Elettronici
CMZ Modbus	CMZ Sistemi Elettronici
CMZ Node Utilities	CMZ Sistemi Elettronici
	CMZ Sistemi Elettronici
🦰 CMZ TSC	CMZ Sistemi Elettronici
CMZ WebServer	CMZ Sistemi Elettronici
Composer	
Fieldbus	
🖲 📲 KEB - Karl E. Brinkmann GmbH	
Net Base Services	3S - Smart Software Solutions GmbH

Figure 5.3. CMZ libraries

5.4. Driver SoftMotion for CMZ SISTEMI ELETTRONICI S.r.l. drives

After the CODESYS Development System installation there is already the possibility to manage the following CMZ drives:

- IBD: both CANopen and EtherCAT;
- NBD: both CANopen and EtherCAT;
- ISD: CANopen;
- SVM: CANopen;
- LBD: both CANopen and EtherCAT.

Furthermore, by importing the EDS and ESI files other CMZ boards can be managed.

5.5. Copy a file from the controller to the PC

In Device - Files it is possible to copy a file from the controller to the PC and vice versa. Furthermore it is possible to delete a file from the controller.

Communication Settings	Host Location		- 🗎 🗙 🕂	·]	Runtime Location	i 🔁 /	- 🗀 🤇
Applications	Name	Size	Modified]	Name	Size	Modified
PLC Backup and Restore	Logic C:\				PlcLogic A:/		
Synchronized files	- M:\				🗀 B:/		
Synchronized nies	S:\				3S.dat	98 bytes	14/01/200
Files	Z:\						
Log							
PLCSettings							
PLC Shell				>>			
Users and Groups							
Access Rights				<<			
Symbol Rights							
TaskDeployment							
Status							
Information							

Figure 5.4. Device - Files

Chapter 6 CMZ Download Area

In the http://www.cmz.it website there is the Download section that allows the access to the technical and software documentation, and to the CMZ SISTEMI ELETTRONICI S.r.l. prod-ucts catalogues.

SCEGLI LA LINGUA 📓 🔲	Profilo Esci Amministra Cambio utente
EXAMPLE SISTEMI	
Benvenuto nell'area download.	
L'area download è divisa per argomenti in cartelle possibilità di selezionare la casella newsletter con u aggiornamento effettuato in quella cartella. Quando un file viene aggiornato, nelle cartelle che sua data di aggiornamento è successiva all'ultima v	e sottocartelle. Nel livello principale (MAIN) a fianco ad ogni cartella hai la n flag. Se la casella è selezionata, riceverai una e-mail di notifica ad ogni e lo contiene appare un'icona NEW. Un file viene marchiato come NEW quando la risita.
	MAIN
Cerca	
	New NFO series
	NF0 series controller (CTE158, CTE240, CTN230, CTN330, CTN560, TS1002). Tools, libraries, documentation.
Newsletter	Ultimo aggiornamento: 18 Febbraio 2019
	New FCT series
	 FCT series controller (FCT200, FCT241, FCT300). Tools, libraries, documentation.
Newsletter	Ultimo aggiornamento: 29 Luglio 2020
	FCT series with CODESYS FCT series controller (FCT200, FCT300) with CODESYS. Tools, libraries, documentation.
Newsletter	Ultimo aggiornamento: 16 Giugno 2020
	New Stepper and stepless series
<u> </u>	 Stepper (SDS, MDM) & Stepless (ISD, SVM) series drives and motors. Tools and documentation.
Newsletter	Ultimo aggiornamento: 18 Giugno 2020
	Brushless series
	Tools and documentation.
Newsletter	Ultimo aggiornamento: 15 Gennaio 2020
	New HMI Operator papel
	Tools and documentation.
Newsletter	Ultimo aggiornamento: 29 Giugno 2020
	Peripherals and accessories driver and documentation
	Ultimo aggiornamento: 18 Febbraio 2019
	Commercial documents
	Catalogues and presentations
Newsletter	Ultimo aggiornamento: 16 Luglio 2020

Figure 6.1. download area

Important

Ŧ

The access requires a registration.

Chapter 7 Advanced functionalities by using Winter-s

Before to use this functionality, always ask help to support@cmz.it or directly contact, by phone, the support department.

Important In this paragraph some advanced functionalities are described that, if not correctly executed, may irreparably damage the controller.

7.1. Installed CODESYS license and firmware version reading

The procedure is the following:

- connect to the controller via Ethernet by using FCTTool (see *Section 2.4, "Step 4: check of the Ethernet connection with the controller"*);
- after the execution of the Scan from the Target locator tab (*Section 4.2, "Target locator"*), select the FCT to be cloned and then click on the 'Terminal' button on lower right position. A new window called Winter-s will appear:

Cist Winter	-s	—		2
	RCCI		(0)	1
	F1 CODESYS SoftPLC			
	F2 List of installed libraries			
	F3 Menu Board Specific			
51-F3=S	172.16.33.146 - 10	24MBR (FCT	640) ==	

Figure 7.1. Winter-s

• in the editable line at the botton of the Winter-s write 'CDS' (or by following the menu: CODESYS SoftPLC -> Runtime Menu Info) in order to reach the menu:





Figure 7.2. Winter-s: Runtime Menu Info

• Select F1 to access the 'Software info page':

	CODESYS Info p	age				
Software Info ===========		:				-
				Rev	ision	
Firmware: FCT640 CODESYS (3	.5.SP11)				6	I
Dev.Type: SoftMotion				3.5.	11.6	I
RTS : 3S Runtime System				3.5.	11.40	I
License : CODESYS - (.105)	SoftMotion with WV	(Internal	test usage	only	1)	I
Axes : 8						
SystemID: 0x12e4ab9e / 105						
						1
License Info ============		:				-
Installed: 1/1						
Installed: 1/1						
Installed: 1/1 Name : CODESYS - (.)	105) SoftMotion wit	h WV				
Installed: 1/1 Name : CCDESYS - (. Product Code : 1022	105) SoftMotion wit (Internal test us	h WV age only)				
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active	105) SoftMotion wit (Internal test us (in use)	h WV age only)				
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active For Dev. Type: SoftMotion	105) SoftMotion wit (Internal test us (in use)	h WV age only)				11 11 11 11 11 11 11 11 11 11 11 11 11
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018	105) SoftMotion wit (Internal test us (in use) (By CMZ)	h WV age only)				
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018	105) SoftMotion wit (Internal test us (in use) (By CMZ)	h WV age only)				
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018	105) SoftMotion wit (Internal test us (in use) (By CMZ)	ch WV Mage only)				
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018	105) SoftMotion wit (Internal test us (in use) (By CMZ)	ch WV Mage only)				
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018	105) SoftMotion wit (Internal test us (in use) (By CMZ)	ch WV Mage only)				
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018	105) SoftMotion wit (Internal test us (in use) (By CMZ)	h WV Mage only)				
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018	105) SoftMotion wit (Internal test us (in use) (By CMZ)	ch WV Mage only)				
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018	105) SoftMotion wit (Internal test us (in use) (By CMZ)	ch WV Mage only)				
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018	105) SoftMotion wit (Internal test us (in use) (By CMZ)	ch WV Wage only)				
Installed: 1/1 Name : CODESYS - (. Product Code : 1022 Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018 	105) SoftMotion wit (Internal test us (in use) (By CMZ)	ch WV Mage only)				

Figure 7.3. Winter-s: Software info page

In the *Software Info* box there are the following information:

- Firmware: report the firmware service pack and, on the right, its version;
- Dev. Type: reports if the controller is PCL or SoftMotion type;
- Axes: reports the maximum SoftMotion axes number that can be used in the application. This number depends on the system order.
- the other information are for internal use.

In the *License Info* box there are the following information:

- Name: reports the license name;
- Product Code: reports an internal code;
- Status: indicates if the license is active;

- For Dev. Type: indicates for what device type the license is compatible;
- Created on: internal information.

7.2. System log file reading

After to have started Winter-s (see *Section 4.2, "Target locator"* Terminal button) it is possible to proceed in two ways:

- by visualizing the content of the log file: write *log* in the editable field;
- by copying the file in the PC: the file is in the partition B: of the system and is named PPCLOG.TXT. It can be copied from CODESYS Development System as described in *Section 5.5, "Copy a file from the controller to the PC"*, or by using Filesystem Commander (see *Section 7.5, "Filesystem Commander"*).

7.3. CMZ cloning procedure

This procedure creates a PPCCLONE.zip file with the files that are related to the application and even to the firmware that is installed in the controller.

Important Are not cloned: the values of the RETAIN and PERSISTENT RETAIN variables; the CODESYS license. Important

Even the configuration for the controlelr IP address assignment is copied (if it is static, then the cloned controller will have the same IP address of the initial controller).

The PPCCLONE.zip file can be used to replay in a second FCT of the same type the functioning of the FCT from which the PPCCLONE.zip file has been created.

The cloning procedure is the following:

• connect to the controller via Ethernet by using FCTTool (see *Section 2.4, "Step 4: check of the Ethernet connection with the controller"*);

• after the execution of the Scan from the Target locator tab (*Section 4.2, "Target locator*"), select the FCT to be cloned and then click on the 'Terminal' button on lower right position. A new window called Winter-s will appear:



Figure 7.4. Winter-s

• in the editable line at the botton of the Winter-s write 'CDS' (or by following the menu: CODESYS SoftPLC -> Runtime Menu Info) in order to reach the menu:





Figure 7.5. Winter-s: Runtime Menu Info

• Select F1 to access the 'Software info page':

CODESYS Info page			
Software Info ====================================			
		Rev	ision
Firmware: FCT640 CODESYS (3.5.SP11)			6
Dev.Type: SoftMotion		3.5.	11.6
RTS : 3S Runtime System		3.5.	11.40
License : CODESYS - (.105) SoftMotion with WV (Internal	test usage	only)
Axes : 8			
SystemID: 0x12e4ab9e / 105			
License Info ====================================			
Installed: 1/1			
Name : CODESYS - (.105) SoftMotion with WV			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only)			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use)			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ)			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ)			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ)			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ)			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ)			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ)			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ)			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ)			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ)			
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ) 	ors		

Figure 7.6. Winter-s: Software info page

• Push F10 to start the cloning operation. A window will appear to confirm to proceed. The operation can require even some minutes, during which this message will be displayed:





Figure 7.7. Winter-s: cloning in progress

• at the end, the information of the operation sucessfully ended and of the PPC-CLONE.ZIP file has been saved in the partition B:/ of the FCT appears:

ſMZ

Software Info Revision Firmware: FCT640 CODESYS (3.5.SP11) 6 Dev.Type: SoftMotion 3.5.11.6 RTS : 35 Runtime System 3.5.11.40 License :			CODESYS Info page			
Software Info Revision Firmware: FCT640 CODESYS (3.5.SP11) 6 Dev.Type: SoftMotion 3.5.11.6 RTS :35 Runtime System 3.5.11.40 License : Internet System 1.1.40 Axes : Internet System 1.1.40 License : Internet System 1.1.40 Name : CODESYS - (.105) SoftMotion with WV Installed Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CM2) Status : 19/10/2018 (By CM2) Status : SoftMotion Esc=Exit						
Revision Firmware: FCT640 CODESYS (3.5.SF11) 6 Dev.Type: SoftMotion 3.5.11.6 RTS : 3.5 Runtime System 3.5.11.40 License :	Software	Info ==========			:	7
Firmware: FCT640 CODESYS (3.5.SP11) 6 Dev.Type: SoftMotion 3.5.11.6 RTS : 3S Runtime System 3.5.11.40 License : nly) Axes : SystemID: Clone has been successfully created in B:\PpcClone.zip License Installed Press a key Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ)				Re	vision	
Dev.Type: SoftMotion 3.5.11.6 RTS : 3S Runtime System 3.5.11.40 License :	Firmware:	FCT640 CODESYS (3	3.5.SP11)		6	
RTS : 35 Runtime System 3.5.11.40 License :	Dev.Type:	SoftMotion		3.5	.11.6	
License : Axes : SystemID: License Installed Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (Ey CMZ) F1=Show next License Info F5=Show change Retain Selectors F10=Clone Application Esc=Exit	RTS :	3S Runtime System	0	3.5	.11.40	Ŀ
Axes : SystemID: Clone has been successfully created in B:\PpcClone.zip License Installed Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (Ey CMZ) F1=Show next License Info F5=Show change Retain Selectors F10=Clone Application Esc=Exit	License :] ^{nl}	у)	
SystemID: Clone has been successfully created in B:\PpcClone.zip License Press a key Installed Press a key Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018 By CMZ)	Axes :					Ŀ
B:\PpcClone.zip License Installed Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active For Dev. Type: SoftMotion Created on : 19/10/2018 By CMZ)	SystemID:	Clone h	has been successfully created in			Ŀ
License Press a key Installed			B:\PpcClone.zip			Ŀ
License Press a key Installed Installed Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ) Fl=Show next License Info F5=Show change Retain Selectors Fl0=Clone Application Esc=Exit						4
Installed Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ) F1=Show next License Info F5=Show change Retain Selectors F10=Clone Application Esc=Exit	T					
Name : CODESYS - (.105) SoftMotion with WV Product Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ) F1=Show next License Info F5=Show change Retain Selectors F10=Clone Application Esc=Exit	License	Press a key				1
Finduct Code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ) Final test usage only Fil=Show next License Info F5=Show change Retain Selectors F10=Clone Application Esc=Exit	Installed	Press a key]
Flocket code : 1022 (Internal test usage only) Status : Active (in use) For Dev. Type: SoftMotion Created on : 19/10/2018 (By CMZ)	Installed	Press a key				
Fl=Show next License Info F5=Show change Retain Selectors F10=Clone Application Esc=Exit	Installed Name	Press a key : CODESYS - (.	.105) SoftMotion with WV			
Created on : 19/10/2018 (By CMZ) F1=Show next License Info F5=Show change Retain Selectors F10=Clone Application Esc=Exit	License Installed Name Product Co	Press a key : CODESYS - (. de : 1022 · Active	.105) SoftMotion with WV (Internal test usage only) (in use)			
Fl=Show next License Info F5=Show change Retain Selectors F10=Clone Application Esc=Exit	Installed Name Product Co Status	Press a key : CODESYS - (. de : 1022 : Active wre: SoftMation	.105) SoftMotion with WV (Internal test usage only) (in use)	J==		
F1=Show next License Info F5=Show change Retain Selectors F10=Clone Application Esc=Exit	License Installed Name Product Co Status For Dev. T	Press a key : CODESYS - (. de : 1022 : Active 'ype: SoftMotion . 19/10/2018	.105) SoftMotion with WV (Internal test usage only) (in use) (By CM7)			
F1=Show next License Info F5=Show change Retain Selectors F10=Clone Application Esc=Exit	License Installed Product Co Status For Dev. T Created on	Press a key : CODESYS - (. de : 1022 : Active ype: SoftMotion : 19/10/2018	.105) SoftMotion with WV (Internal test usage only) (in use) (By CMZ)			
Fl=Show next License Info F5=Show change Retain Selectors Fl0=Clone Application Esc=Exit	License Installed Product Co Status For Dev. T Created on	Press a key : CODESYS - (. de : 1022 : Active ype: SoftMotion : 19/10/2018	.105) SoftMotion with WV (Internal test usage only) (in use) (By CMZ)			
Fl=Show next License Info F5=Show change Retain Selectors Fl0=Clone Application Esc=Exit	License Installed Product Co Status For Dev. T Created on	Press a key : CODESYS - (. de : 1022 : Active ype: SoftMotion : 19/10/2018	.105) SoftMotion with WV (Internal test usage only) (in use) (By CMZ)			
Fl=Show next License Info F5=Show change Retain Selectors Fl0=Clone Application Esc=Exit	License Installed Product Co Status For Dev. T Created on	Press a key : CODESYS - (. de : 1022 : Active ype: SoftMotion : 19/10/2018	.105) SoftMotion with WV (Internal test usage only) (in use) (By CMZ)			
Fl=Show next License Info F5=Show change Retain Selectors Fl0=Clone Application Esc=Exit	License Installed Product Co Status For Dev. T Created on	Press a key : CODESYS - (. de : 1022 : Active ype: SoftMotion : 19/10/2018	.105) SoftMotion with WV (Internal test usage only) (in use) (By CM2)			
Fl=Show next License Info F5=Show change Retain Selectors Fl0=Clone Application Esc=Exit	License Installed Product Co Status For Dev. T Created on	Press a key : CODESYS - (. de : 1022 : Active ype: SoftMotion : 19/10/2018	.105) SoftMotion with WV (Internal test usage only) (in use) (By CM2)			
Fl=Show next License Info F5=Show change Retain Selectors Fl0=Clone Application Esc=Exit	Installed Name Product Co Status For Dev. T Created on	Press a key : CODESYS - (. de : 1022 : Active ype: SoftMotion : 19/10/2018	.105) SoftMotion with WV (Internal test usage only) (in use) (By CMZ)			
F10=Clone Application Esc=Exit	Installed Name Product Co Status For Dev. T Created on	Press a key : CODESYS - (. de : 1022 : Active ype: SoftMotion : 19/10/2018	.105) SoftMotion with WV (Internal test usage only) (in use) (By CMZ)			
	Fl=Show n	Press a key : CODESYS - (. de : 1022 : Active ype: SoftMotion : 19/10/2018 ext License Info	<pre>.105) SoftMotion with WV (Internal test usage only) (in use) (By CMZ) F5=Show change Retain Selectors</pre>			

Figure 7.8. Winter-s: cloning succesfully completed

• the PPCLONE.ZIP file must be copied in an SDCard (recommended choice), or moved in the PC and then **must be deleted** from B:\.



To move the PPCCLONE.zip file from B:\ it is possible to follow different ways:

• if a PC is at disposal, with CODESYS Development System (*Chapter 5, CODESYS Development System*) installed, it is possible to use the Files tab of Device, (see *Section 5.5, "Copy a file from the controller to the PC"*):



Figure 7.9. Device - File

- it is possible to use the Filesystem Commander service of Winter-s (see *Section 7.5, "Filesystem Commander"*). If an SDCard is available the best solution is to insert it in the controller and then select C:, or select a disc on the PC @C, @D.... Then copy the file B:\PPCCLONE.ZIP in the new position and then delete it from B:\.
- if in the controller it is eventually already active the FTP server connection, it is even poissible to use this mode to move the file from B:\ to the PC.
- if the file has been copied in the SDCard, then it is sufficient to turn off the FCT on which the application has to be cloned, insert the SDCard that contains the PPCCLONE.ZIP and switch the controller on. It can be noticed that the FAULT led of the controller will have red light blinkings and then the system will be found with the firmware and the application cloned.

Warning

If the SDCard is left inserted with the PPCCLONE.ZIP, then at every reboot of the controller the cloning operation is performed.

Otherwise, if the file is in the PC, then the file has to be copied in B:\of the new controller by using CODESYS Device File (see *Section 5.5, "Copy a file from the controller to the PC"*), or Filesystem Commander (see *Section 7.5, "Filesystem Commander"*). After having copied th file, turn off and on the controller, so that the PPCCLONE.ZIP extraction

ſMZ

operation is executed, the FAULT led will have red light blinkings and then the system will be found with the firmware and the application cloned.

Warning

At the end of the operation the PPCCLONE.zip file must be deleted from B:\, otherwise the cloning operation will be executed at every reboot of the controller.

7.4. Measurement of the controller free resources

There is the possibility to have the information of the free resources in the FCT controller. Start Terminal Winter-s from FCTTool.

From the main page, type MQX in the editable field (or click on the function button Menu Board Specific - MQX) and then push F4 - Kernel Time:

រំរំតែ Winter-s		– 🗆 X
[<u>R</u>	Cernel Time
Current elapsed	time:	Offset time (POSIX 1/1/1970):
Seconds: Milliseconds:	0x00000067 0x00000146	Seconds: 0x5F2D6C62 Start: 14:59:46- 7/08/2020
Current localzon	e time:	Current attached Rtc callbacks:
Time: Date:	15:01:29 7/08/2020	Rtc : 3
DayLight Saving	Time (F9=Set):	Rsc performances
Status:	Disabled	Task status : Blocked Task priority: 285
Localzone offs Localzone peri Summer Start:	et: od:	Free cpu : 0.0 Free Min cpu : 0.0 Free Max cpu : 0.0
Summer End Dat Next Edge Date	e: :	
		= 172.16.33.146 - 1024MBR (FCT640)
Esc=Back F1/F2/F3	=Time/Date/PCSync	F4/F5,F6/F7=RscGo/Stop,+/-Prio F8=Rto > .

Figure 7.10. Kernel time

By pushing F4 the measurement of the free resources of the controller starts. Read the information in the lower right corner: Free cpu with the minimum and maximum values even reported.

7.5. Filesystem Commander

this functionality allows to copy and move files from the PC to the controller and vice versa. From the initial page of Winter-s, in the editable field, write FC. Then this is the page:



Figure 7.11. Winter-s FC

First the partition A: and B: of the controller are respectively on the left and on the right.

To change the selected partition on the left press Alt-F1 (Alt-F2 to change the one on the right). This window appears:

EMZ

ns vvint	er-s	constan Commandar		_		
	Drivers List		B:\			Ī
А	NAND FLASHO	bootlog txt	503	6/08/20	9:21	
в	NAND FLASH1	ppcclone zip	2559694	6/08/20	11:40	
с	NO NAME	ppclog txt	20918	6/08/20	9:21	
@C	localhost					
@D	localhost			e de la composition d	1. Sec. 1	
@M	localhost			e de la composition d	1. Sec. 1.	
@S	localhost			6 - C C C C C C C C		
@T	localhost			• • • • • • • • •		
@.Z	localhost		1	1. State 1.		
:						
:						
:		t state in the second state of the second stat				
:		e e				
		e e		• • • • • • • • • • •		
:				•		
:				•		
:				• •		
:				• •		
:						
:						
:						
:						
:						
:						
		U dir,	2520 1	on 31	ciles	
	EFECTIVE ECODORNAL EZONAL	172.16.33	.146 - 1024	IMBR (FCI)	540) ==	
-neip	ro-copy ro-kenmove r/=mak	Centrano-Delete ESC=E	XIC			

Figure 7.12. Winter-s FC driver list

The proposed partitions are:

- A and B: are the NAND memory partitions in the controller;
- C: SDCard of the controller, if inserted;
- The partitions preceded by the '@' are the ones that are present in the PC.

Once on the left and on the right have been prepared the desired folders, it is sufficient to select the file and push F5 to copy it from a folder the other. With F6, instead, it is moved.

Ŧ	Important Pushing Alt-F3 a new page opens that allows to verify the integrity of the partitions A: and B:.

7.6. Management of the system in Boot

If the system is in Boot, it can phisically seen because the FAULT led is steady on, but can be seen even through the target locator because in the devices list, in the column Name, beside the name, appears [0]. A controller in Boot cannot be seen in Scan Network of CODESYS Development System (see *Section 5.1, "Connection to FCT"*).

A controller normally does not remains in Boot, it pass through it at the turn on before the firmware starts. So if the system remains in Boot is because the RESET button (*Section 3.6, "RESET button"*) has been pressed,

Note

Due to an error in the firmware or in the application program, the controller, in extreme cases, it can continuously reboot. In other words, the program starts and causes the error that forces it to restart. In this situation it is not possible to communicate with the controller. The only way to stop this "loop" is to push the RESET button (*Section 3.6, "RESET button*"). This stops the controller in Boot, so that it is possible to communicate with it.

In this situation, by clicking on Terminal it is possible to open a command prompt from which it is possible to execute advanced operations.

Important

These operations may damage the system. Before to use them contact support@cmz.it.

There are some actions that are already been prepared: by clicking the right mouse button on the Winter-s window, a menu appears from which, by selecting Execute, a command list opens:



Figure 7.13. Terminal (debugger)

- Delete App.: it deletes the file with the application CODESYS (A:\CODESYS \PLCLOGIC\APPLICATION\Application.app) from the controller: this can be used in extreme situations when the application continuously gets the controller in Boot and it is not possible to take charge of the communication with the system;
- Format: it formats the syste, everything will be deleted including the firmware and all the files that have been saved in the controller. Furthermore, at the end of the operation, the FCT cannot communicate with CODESYS, it will be necessary to install a firmware;
- Restart: restarts the firmware;
- Rename App.OLD: renames the application file (A:\CODESYS\PLCLOGIC\APPLI-CATION\Application.app) to Application.old.

Chapter 8 Frequent questions

Here follow some frequent questions.

8.1. Why is the controller not visible in the network?

Repeat the procedure described in *Section 2.4*, *"Step 4: check of the Ethernet connection with the controller"*.

8.2. Which SD Cards are compatible with the FCT controllers?

In the FCT640 system only the SD Card that comply with the 2.0 (and newer) specifications can work, while in the FCT200 and FCT300 systems also the SD Card of 1.0 type can be used.

CMZ recommends to use the S-250 series of Swissbit SD cards, after having tested their compatibility with the controller and by recognizing a performance that is suitable with industry about temperature range and data retention reliability (SLC technology). The available sizes are 512 MB, 1 GB and 2 GB and it is possible to purchase the 1 GB version directly from CMZ.

In order to verify the type of an SD Card, it is necessary to follow these steps:



1 From FCTTool identify the controller (*Section 4.2, "Target locator"*) and open the Winter-s terminal. In the editable field write FC to enter in the Filesystem Commander (see *Section 7.5, "Filesystem Commander"*).

Exit ENTER=MoreInfo F1=Fo:

From the page that opens with the FC command, push ALT + F3 and then F3 "SD-Card-HW-info".

MBR (FCT200

From the page that opens, on the characteristic *Type* there is the inserted SD Card type written.

EMZ

FACTORY AND HEADQUARTERS

CMZ SISTEMI ELETTRONICI S.r.I. Via dell'Artigianato, 21 31050 Vascon (TV) - Italy Phone 39 (0)422 447411 Fax +39 (0)422 447444

e-mail: sales@cmz.it web site: www.cmz.it



RESEARCH LABORATORY SINCE 1992



Official UK & Ireland Distributor

Motion Control Products Ltd 11-15 Francis Ave, Bournemouth, Dorset, UK, BH11 8NX www.motioncontrolproducts.com Tel: +44(0)1202 599922